



USER GUIDE

60 GHz cnWave™

Release 1.5.1



Reservation of Rights

Cambium reserves the right to make changes to any products described herein to improve reliability, function, or design, and reserves the right to revise this document and to make changes from time to time in content hereof with no obligation to notify any person of revisions or changes. Cambium recommends reviewing the Cambium Networks website for the latest changes and updates to products. Cambium does not assume any liability arising out of the application or use of any product, software, or circuit described herein; neither does it convey license under its patent rights or the rights of others. It is possible that this publication may contain references to, or information about Cambium products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that Cambium intends to announce such Cambium products, programming, or services in your country.

Copyrights

This document, Cambium products, and 3rd Party software products described in this document may include or describe copyrighted Cambium and other 3rd Party supplied computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Cambium, its licensors, and other 3rd Party supplied software certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Cambium, its licensors, or the 3rd Party software supplied material contained in the Cambium products described in this document may not be copied, reproduced, reverse engineered, distributed, merged or modified in any manner without the express written permission of Cambium. Furthermore, the purchase of Cambium products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Cambium or other 3rd Party supplied software, except for the normal non-exclusive, royalty free license to use that arises by operation of law in the sale of a product.

Restrictions

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Cambium.

License Agreements

The software described in this document is the property of Cambium and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

High Risk Materials

Cambium and its supplier(s) specifically disclaim any express or implied warranty of fitness for any high-risk activities or uses of its products including, but not limited to, the operation of nuclear facilities, aircraft navigation or aircraft communication systems, air traffic control, life support, or weapons systems ("High Risk Use").

This product is not restricted in the EU. Any High Risk is unauthorized, is made at your own risk and you shall be responsible for any and all losses, damage or claims arising out of any High-Risk Use.

Contents

Contents	3
About This User Guide	10
Purpose	10
Cross-references	10
Feedback	10
Important regulatory information	10
Complying with rules for the country of operation	10
Application firmware	12
Ethernet networking skills	12
Lightning protection	12
Specific expertise and training for professional installers	13
Legal and Open-Source Software statements	13
Problems and warranty	13
Reporting problems	13
Repair and service	13
Hardware warranty	13
Security advice	14
Warnings, cautions, and notes	14
Caring for the environment	14
In the UK and EU countries	14
In non-EU countries	15
Product Description	16
Introduction	16
Frequency bands	16
Characteristics	17
802.11ay Standards and advantages	18
Terragraph	20
Theory of operation	21
Overview of cnWave family	22

Features	23
Wireless operation	24
Wireless topology	25
Modulation	27
Synchronization	28
Time-division duplexing access mechanism	29
Wireless encryption	29
Designing wireless networks	30
TDD synchronization	30
System management	30
Management agent	30
Network management	30
IPv6	30
System logging	31
Software upgrade	31
System Hardware	32
Wireless nodes	32
V1000 Client Node (CN)	32
V2000 Client Node (CN)	33
V3000 Client Node (CN)	34
V5000 Distribution Node (DN)	35
Radio mounting brackets	36
Radio accessories	41
Radio external interfaces	44
Radio specifications	47
Power supply units (PSU)	48
PSU Options	48
V1000 - Power over Ethernet (PoE)	49
V2000 - PoE	50
V3000/V5000 - PoE	52
Ethernet and DC cables	58

Maximum cable lengths	58
Outdoor copper CAT6A Ethernet cable	59
Cable accessories	60
SFP Module kits	61
Optical cable and connectors	61
System Planning	64
Site planning	64
Grounding and lightning protection	64
Lightning protection zones	64
Site grounding system	65
ODU location	65
Drop cable grounding points	65
ODU wind loading	66
PSU DC power supply	67
PSU AC power supply	67
PSU location	67
Outdoor AC/DC PSU	67
Lightning Surge Protection Units (LPUs)	67
Lightning Surge Protection Units location	67
Deployment Considerations	68
Key deployment guidelines	68
Sector and alignment	69
Minimum CN spacing	70
Near-far radio	71
Early weak interference	72
Avoiding the tight angle deployment	72
Avoiding the straight line interference	73
When two V5000 devices are co-located at a site	74
Polarity	74
Link Adaptation and Transmit Power Control (LATPC)	75
Radio spectrum planning	76

General wireless specifications	76
Regulatory limits	76
Link planning	77
LINKPlanner	77
Range and obstacles	77
Path loss	77
Planning for data networks	78
Point to Point-based single link Ethernet bridge	78
IPv4/L2 based PMP and mesh network planning	79
Support for dual networking (IPv4 and IPv6)	80
IPv6 Mode network planning	80
IPv6 Network design consideration	81
Reserved IPv6 address space	82
E2E and cnMaestro deployment consideration	82
Ethernet bridging	82
Layer 2 control protocols	84
IP Interface	84
Daisy-chaining 60 GHz links	84
Installation	85
Safety	85
Power lines	85
Working at heights	85
PSU	85
Grounding and protective earth	85
AC Supply	85
Powering down before servicing	85
Primary disconnect device	85
External cables	86
Drop cable tester	86
RF Exposure near the antenna	86
Minimum separation distances	86

Grounding and lightning protection requirements	86
Grounding cable installation methods	86
Siting radios	86
60 GHz cnWave radios and mounting bracket options	86
Installing the cnWave radio nodes	87
ODU Interface with LPU on the pole	92
Attach ground cables to the radio	96
Mounting the ODU	96
Connect to the PSU port of the radio	118
Using Power over Ethernet (PoE)	118
Using AC/DC PSU	121
Installing the PSU	124
Installing the 60W DC power injector	125
Installing the AC/DC PSU	126
Installing 15W or 30W power injector	128
Connecting to the SFP+ optical module or SFP+ to the copper module to ODU	129
Removing the cable and SFP module	135
Configuring 60 GHz cnWave™	137
Nodes deployment	137
Connecting to the unit	137
Configuring the management PC	137
Connecting to the PC and powering up	139
Using the web interface	139
Logging into the web interface	139
Enabling internal E2E Controller	145
Topology	147
Configuration	152
Operation	204
Software upgrade	204
Diagnostics	205
Statistics	207

Links	207
Ethernet	211
GPS	213
Radio	213
Performance	214
Prefix zone Statistics	219
Border Gateway Protocol (BGP)	219
Maps	220
Interference Scan	221
Tools	224
Factory reset	224
Field diags	225
Antenna alignment	226
Remote Command	233
Ping	237
Quick PTP setup	238
iPerf	239
cnMaestro support for Onboard Controller	241
Backup CN link	244
Auto Manage IPv6 Routes (External E2E Controller)	246
Unconnected PoPs	249
High Availability (HA) support for Onboard E2E Controller	250
Regulatory Information	254
Compliance with safety standards	254
Electrical safety compliance	254
Human exposure to radio frequency energy	255
Compliance with radio regulations	257
Type approvals	258
Federal Communications Commission (FCC) compliance	258
Innovation, Science and Economic Development Canada (ISED) compliance	258
60 GHz cnWave example product labels	259

Troubleshooting	262
Field diagnostics logs	262
Setup issues in IPv4 tunneling	264
Link is not established	266
PoP not online from E2E or cnMaestro UI	269
Link is not coming up	269
Link does not come up after some configuration change	270
Link is not having expected throughput performance	270
Factory reset	270
Cambium Networks	272

About This User Guide

This document provides detailed information about the 60 GHz cnWave™ products, hardware, and supported features. The guide also explains how to deploy the product along with important safety measures. It is intended for system designers, system installers, and system administrators.

Purpose

The 60 GHz cnWave product documents are intended to instruct and assist personnel in operation, installation, and maintenance of the equipment and ancillary devices. It is recommended that all personnel engaged in such activities must be properly trained.

Cambium Networks disclaims all liability whatsoever, implied or express, for any risk of damage, loss or reduction in system performance arising directly or indirectly out of the failure of the customer, or anyone acting on the customer's behalf, to abide by the instructions, system parameters, or recommendations made in this document.

Cross-references

References to external publications are shown in italics. Other cross-references, emphasized in blue text in electronic versions, are active links to the references.

This document is divided into numbered chapters that are divided into sections. Sections are not numbered but are individually named at the top of each page and are listed in the table of contents.

Feedback

We appreciate feedback from the users of our documents. This includes feedback on the structure, content, accuracy, or completeness of our documents. To provide feedback, visit our support website:

<https://support.cambiumnetworks.com>.

Important regulatory information

Complying with rules for the country of operation

USA specific information



Caution

This device complies with Part 15 of the Federal Communications Commission (FCC) Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.



Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Canada specific information



Caution

This device complies with Innovation, Science and Economic Development Canada (ISED) license-exempt RSSs. Operation is subject to the following two conditions:

- This device may not cause interference; and
- This device must accept any interference, including interference that may cause undesired operation of the device.

Renseignements spécifiques au Canada



Attention

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- l'appareil ne doit pas produire de brouillage, et
- l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

European specific information

Cambium Networks 60 GHz cnWave products are compliant with applicable European Directives required for CE marking:

- 2014/53/EU of the European Parliament and of the Council of 16 April 2014 on the harmonisation of the laws of the Member States relating to the making available on the market of radio equipment and repealing Directive 1999/5/EC; Radio Equipment Directive (RED).
- 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS Directive).

- Cambium Networks complies with the European Regulation 2023/988 of 10 May 2023 on General Product Safety. EU Authorized Representative: Cambium Networks Europe B.V., Muiderstraat 1, 1011PZ Amsterdam, Netherlands. Contact Information: GPSR@cambiumnetworks.com.

EU Declaration of conformity

Hereby, Cambium Networks declares that the Cambium Networks 60 GHz cnWave Series of Wireless Ethernet Bridge complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at https://www.cambiumnetworks.com/eu_dofc.

United Kingdom (UK) specific information

Cambium Networks 60 GHz cnWave products are compliant with applicable United Kingdom (UK) Regulations required for UKCA marking:

- Radio Equipment Regulations 2017 (SI 2017 No. 1206, as amended)
- Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 (SI 2012 No. 3032, as amended) (RoHS)

The 59-63.9 GHz frequency band is subject to specific exclusion zones. For more information, see the [59 - 63.9 GHz transmission exclusion zones](#) table.

UK Unmetered Supplies Operational Charge Codes:

- **V1000:** 8820008004100
- **V2000:** 8820011004100
- **V3000:** 8820022000100
- **V5000:** 8820029000100

For more details, check <https://www.elexon.co.uk/operations-settlement/unmetered-supplies/charge-codes-and-switch-regimes/>.

UK Declaration of conformity

Hereby, Cambium Networks declares that the Cambium Networks 60 GHz cnWave Series of Wireless Ethernet Bridge complies with the essential requirements and other relevant provisions of Radio Equipment Regulations 2017 (SI 2017 No. 1206, as amended) The declaration of conformity may be consulted at https://www.cambiumnetworks.com/ukca_dofc.

Application firmware

Download the latest 60 GHz products family software and install it in the Outdoor Units (ODUs) before deploying the equipment. Instructions for installing software are provided in this guide.

Ethernet networking skills

The installer must have the ability to configure IP addressing on a PC and to set up and control products using a web browser user interface (UI).

Lightning protection

To protect outdoor radio installations from the impact of lightning strikes, the installer must be familiar with the normal procedures for site selection, bonding and grounding. Installation guidelines for the 60 GHz platform of products are available in [System Hardware](#) and [System Planning](#) sections.

Specific expertise and training for professional installers

To ensure that the 60 GHz cnWave Series is installed and configured in compliance with the requirements of the EU, ISED and the FCC, installers must have the radio engineering skills and training described in this section.

The Cambium Networks technical training program details can be accessed from the following link:

<https://learning.cambiumnetworks.com/>

Legal and Open-Source Software statements

Refer to the *60 GHz cnWave™ Legal and Open-Source Guide* for:

- Cambium Networks end user license agreement
- Open-Source Software Notices.

Problems and warranty

Reporting problems

If any problems are encountered when installing or operating this equipment, follow this procedure to investigate and report:

1. Search this document and the software release notes of supported releases.
2. Visit the support website (<http://www.cambiumnetworks.com/support>).
3. Ask for assistance from the Cambium Networks product supplier.
4. Gather information from affected units, such as any available diagnostic downloads.
5. Escalate the problem by emailing or telephoning support.

Repair and service

If unit failure is suspected, obtain details of the Return Material Authorization (RMA) process from the support website (<http://www.cambiumnetworks.com/support>).

Hardware warranty

Cambium's standard hardware warranty is for one (1) year from the date of shipment from Cambium Networks or a Cambium distributor. Cambium Networks warrants that hardware will conform to the relevant published specifications and will be free from material defects in material and workmanship under normal use and service. Cambium shall within this time, at its own option, either repair or replace the defective product within thirty (30) days of receipt of the defective product. Repaired or replaced products will be subject to the original warranty period but not less than thirty (30) days.

To register positioner products or activate warranties, visit the support website. For warranty assistance, contact the reseller or distributor. The removal of the tamper-evident seal will void the warranty.



Caution

Using non-Cambium parts for repair could damage the equipment or void warranty. Contact Cambium for service and repair instructions.

Portions of Cambium equipment may be damaged from exposure to electrostatic discharge. Use precautions to prevent damage.

Security advice

Cambium Networks systems and equipment provide security parameters that can be configured by the operator based on their particular operating environment. Cambium recommends setting and using these parameters following industry-recognized security practices. Security aspects to be considered are protecting confidentiality, integrity, and availability of information and assets. Assets include the ability to communicate, information about the nature of communications, and information about the parties involved.

In certain instances, Cambium makes specific recommendations regarding security practices, however the implementation of these recommendations and final responsibility for the security of the system lies with the operator of the system.

Warnings, cautions, and notes

The following describes how warnings and cautions are used in this document and all Cambium Networks document sets:

Warnings

Warnings precede instructions that contain potentially hazardous situations. Warnings are used to alert the reader to possible hazards that could cause loss of life or physical injury. A warning has the following format:



Warning

Warning text and consequence for not following the instructions in the warning.

Cautions

Cautions precede instructions and are used when there is a possibility of damage to systems, software, or individual items of equipment within a system. However, this damage presents no danger to personnel. A caution has the following format:



Caution

Caution text and consequence for not following the instructions in the caution.

Notes

A note means that there is a possibility of an undesirable situation or provides additional information to help the reader understand a topic or concept. A note has the following format:



Note

Note text.

Caring for the environment

The following information describes national or regional requirements for the disposal of Cambium Networks supplied equipment and for the approved disposal of surplus packaging.

In the UK and EU countries

The following information is provided to enable regulatory compliance with the European Union (EU) directives and UK regulations identified and any amendments made to these directives and regulations when using Cambium equipment in the UK or EU countries:

Disposal of Cambium equipment

European Union (EU) Directive 2012/19/EU Waste Electrical and Electronic Equipment (WEEE) and UK Statutory Instrument The Waste Electrical and Electronic Equipment Regulations 2013 No. 3113.

Do not dispose of Cambium equipment in landfill sites. For disposal instructions, refer to <http://www.cambiumnetworks.com/support/weee-compliance>

Disposal of surplus packaging

Do not dispose of surplus packaging in landfill sites. In the EU and UK, it is the individual recipient's responsibility to ensure that packaging materials are collected and recycled according to the requirements of EU and UK environmental law.

In non-EU countries

In non-EU countries, dispose of Cambium equipment and all surplus packaging in accordance with national and regional regulations.

Product Description

This section provides information about the 60 GHz cnWave product from Cambium Networks. It also describes its features, characteristics, and other related concepts.

Introduction

The 60 GHz cnWave products support a wide spectrum of up to 9 GHz (57-66 GHz) that is typically divided into channels of 2 GHz each. The 60 GHz band is largely uncongested when compared to 2.5 GHz and 5 GHz public bands, which are currently used for Wi-Fi. The 60 GHz band is an unlicensed millimeter-wave band that can provide massive speeds and throughput with Line of Sight (LoS) applications.

The 60 GHz band is located in the millimeter-wave (30 GHz to 300 GHz) portion of the electromagnetic spectrum.

The millimeter-wave portion of the RF spectrum has been largely unexploited for commercial wireless applications. 60 GHz wireless products enable two-way wireless communications at data rates that was previously achieved using fiber optic cables.

In addition to the high data rates (accomplished in this spectrum), energy propagation in the 60 GHz band has benefits such as excellent immunity to interference, high security, and frequency reuse.

Frequency bands

The 60 GHz band is divided into 11 channels, each with a bandwidth of 2.16 GHz starting from **57.24** to **70.2 GHz**. Channels 1 to 6 support 2.16 GHz bandwidth and are defined in 802.11ad. Channels 9 to 13 support 4.32 GHz bandwidth and are added to 802.11ay.

Figure 1: Frequency bands




Table 1 lists the channels and the corresponding bandwidths supported by 60 GHz cnWave products:

Table 1: Channels and corresponding bandwidths

Channel	Bandwidth (GHz)	Center (GHz)	Minimum (GHz)	Maximum (GHz)
CH1	2.16	58.32	57.24	59.40
CH2	2.16	60.48	59.40	61.56
CH3	2.16	62.64	61.56	63.72
CH4	2.16	64.80	63.72	65.88
CH9	4.32	59.40	57.24	61.56
CH10	4.32	61.56	59.40	63.72
CH11	4.32	63.72	61.56	65.88

Characteristics

The following are the important characteristics of 60 GHz cnWave products:

- **High throughput capability**

CnWave products support 802.11ad Modulation and Coding Schemes (MCS) in a single channel (CB1) as well as 802.11ay Enhanced Directional multi-gigabit (EDMG) modes in dual Channel Bonding (CB2). This enables you to achieve Multi-Gigabit wireless rates. Refer to [Table 3](#) and [Table 4](#) for the supported CB1 and CB2 modes along with the expected throughput values.


- **Unlicensed and interference free**

Typically, the V band is either an unlicensed or lightly licensed band, which is relatively a new band. This band has limited interference when compared to 2.4 and 5 GHz bands.

- **Line of Sight (LoS)**

60 GHz is affected by oxygen absorption, it varies throughout the band. The absorption gets reduced if the frequency gets increased. For example, the absorption is 15 dB/km in 60 GHz frequency, 5 dB/km in 64 GHz, and 0.5 dB/km in 68 GHz. If the total channel is divided into 6 channels, then the mid-channel that is channels 2 and 3, has more absorption loss. From channel 4, the absorption level starts to drop. So only Line of Sight links are available and Near LoS or non LoS links do not work with 60 GHz.

Figure 2: Line of Sight



- **Rain fade**

You can view significant rain fade for 60 GHz links, particularly those pushing the longer distances. Attenuation depends on the rain rate which must be factored in while planning the network. Rain attenuation depends on the level of the rain. The following table describes the rain level and absorption loss.


Table 2: Rain and attenuation

Rain	Attenuation
Drizzle (0.25 mm/hr)	0.2 dB/km
Light Rain (2.5 mm/hr)	1.8 dB/km
Medium Rain (12.5 mm/hr)	5.6 dB/km

Rain	Attenuation
Heavy Rain (25 mm/hr)	9.5 dB/km
Downpour (50 mm/hr)	17 dB/km
Tropical (100 mm/hr)	28 dB/km
Monsoon (200 mm/hr)	38 dB/km

The following figure shows the absorption loss due to the rain level (seasons):

Figure 3: Variation in Loss/km with frequency and rain rate



Drizzle - 0.25 mm/hr; Light rain - 2.5 mm/hr; Medium rain - 12.5 mm/hr; Heavy rain - 25 mm/hr.

- **Short range**

The range of a 60 GHz cnWave link can be limited due to oxygen absorption and rain fade which needs to be factored in for link planning. One advantage of a shorter range is the frequent reusability and security (as the signal does not travel long distances).

802.11ay Standards and advantages

IEEE 802.11ay is an IEEE standard that covers 60 GHz cnWave. This standard is an amendment of the IEEE 802.11ad standard. IEEE 802.11ay is designed with a higher throughput capacity of over 10 Gbps data rate over distances of 200 to 500 meters. 802.11ay includes features such as Channel Bonding and Synchronization. 802.11ay based 60 GHz solution transforms fixed wireless access from a broadband option of last resort into a competitive alternative to fiber and cable-based solution.

802.11ay is WLAN type in the IEEE 802.11. It has a frequency of 60 GHz. It has mechanisms for channel bonding and MU-MIMO technologies. 802.11ad uses a maximum of 2.16 GHz bandwidth, whereas 802.11ay bonds four of those channels together for a maximum bandwidth of 8.64 GHz.

The 802.11ay standard has the following advantages with the Terragraph solution:

- **Channel Bonding**

The 802.11ay standard has channel bonding capability, allowing the combination of adjacent channels to form wider channels. In this case, wider channels combine to form 4.32 GHz channels. These additional wider channels provide double throughput capacity compared to the 802.11ad standard.

- **Network Synchronization**

Synchronization is used to control the transmit and receive signals to prevent self-interference. Radios assigned with the same polarity will be transmitting and receiving at the same time.

There are four types of polarity:

- Odd Polarity
- Even Polarity
- Hybrid odd Polarity
- Hybrid Even Polarity

- **Mesh Routing**

Mesh is an interconnection of devices that can have multiple paths between any two nodes, some advantages of using mesh are better connectivity, capacity sharing, load balancing, and re-routing in case of link failure.

- **Increased capacity**

802.11ay supports Channel Bonding which allows two immediate channels to be merged into a single wide-band channel, thereby doubling the channel bandwidth to 4.32 GHz.

- **Supports a greater number of client nodes**

802.11ay supports 15 client nodes per sector.

Advantages

- **802.11ay product, Terragraph certified**

The 60 GHz cnWave is an 802.11ay product and Terragraph certified.

- **Highest capacity**

It has the highest capacity in the industry, up to 5.4 Gbps per sector.

- **Low total cost ownership**


- cnWave V5000 is 280-degree coverage with dual-sector. Installation is simple, uses beam forming for installation. No need for a site router.
- cnWave V1000, V2000, and V3000 meet various range challenges.
- Using beam forming, the V3000 has a super long range.

- The cnMaestro panel is used for device management.
- cnHeat and LINKPlanner help with easy planning.
- **Unlicensed and interference-free**
This spectrum spans 57 - 66 GHz and is widely available, especially when compared to the 2.4 and 5 GHz bands. This 9 GHz of the spectrum can be divided up into channels ranging between 1 and 2 GHz wide.
- **Massive throughput**
This 60 GHz band can allow over 10 Gbps of throughput from some products on the market today.

Terragraph

Terragraph is a connectivity solution from Facebook. The mission of Terragraph is to bring more people online to a faster internet. It is freely licensed technology that is designed to deliver cost-effective and reliable fiber like connectivity over a wireless mesh network (as shown in Figure 4).

Figure 4: Terra graph



- 1- Controller
- 2- PoP (Fiber, RF)
- 3- Distribution Node
- 4- Client Node

Key components

Terragraph contains the following key components:

- **Distribution Node (DN)** - DN connects with other DN to form a mesh in a distribution network.
- **Client Node (CN)** - CN is a customer premise radio that connects with a DN node to provide high-speed connectivity.

- **E2E Controller** - The E2E Controller allows configuration, control, and monitoring of the nodes and network. Cambium Networks supports two methods to utilize the E2E Controller:
 - On-Premises installed as a VM and can be used for small or large deployment (limited to 500 nodes).
 - Onboard the PoP, for PTP, PMP, and small mesh networks the PoP can be configured to host the controller (limited to 31 nodes).

Features

The following are the features of Terragraph:

- **802.11ay** - Delivers multi-gigabit speeds over wide frequency bands.
- **Mesh** - Efficiently distributes capacity and improves availability, using Open/R.
- **Efficient MAC and PHY** - Scheduled MAC (TDD / TDMA) for scalability and dense deployments.
- **Cloud management** - Used for configuration, management, visualization, alarms, and monitoring.
- **Network planning** - Automated design and optimization using imagery, population, and optionally other data sources.

Responsibilities

The Terragraph software initializes and configures radios (DN and CN). It tracks and optimizes meshed routing paths. It also monitors and maintains Syslog, alarms, and Firmware upgrades.

Theory of operation

The 60 GHz cnWave devices support Facebook connectivity technology called **Terragraph**. cnWave devices implement IEEE 802.11ay WLAN standard and use 60GHz frequency band for wider spectrum and higher capacity. cnWave devices can provide multi-gigabit throughput from 100 M to 1.5 KM.


Deployment of the devices uses Open/R based layer3/IPv6 mesh for efficient distribution of traffic between the nodes and higher availability of the traffic. This also overcomes non-line of sight issues.

Devices use TDMA/TDD technology to achieve density deployment efficiency. Network and the nodes are configured, controlled, and monitored by a cloud-based E2E Controller.

The following terminologies are used for the network deployment:

- **Distribution Node (DN)** - DN connects with other DN for mesh network
- **Client Node (CN)** - CN connects to DN to provide high-speed connectivity
- **PoP** - DN connected to the back-haul
- **CPE** - Customer premises equipment devices like Wi-Fi router

Figure 5: *Deployment scenario*



Overview of cnWave family

The 60 GHz cnWave solution (from Cambium Networks) provides easy, fast, and cost-effective wireless Gigabit connectivity for edge access and/or high capacity backhaul for edge access solutions at a significantly lower cost than fiber infrastructure. Service providers and enterprises now have access to Gigabit for business and residential connectivity, backhaul for Wi-Fi access. Certified for Facebook Terragraph, 60 GHz cnWave Mesh solutions are highly efficient at handling high-density deployments in cities and suburban areas.

The 60 GHz solution consists of a Distribution Node (DN), which acts as an Access Point (AP), and a Client Node (CN) that acts as a cnWave client.

60 GHz cnWave consists of the following **four variants** (as shown in [Figure 6](#)):

- **V1000** : A **Client Node (CN)** that contains a wide range, 80 degrees beamforming for easy installation. This CN is powered by 802.3af PoE and supports up to 2 Gbps for PTP and PMP configurations.
- **V2000**: A CN that contains a 34.5 dBi antenna with beamforming. This client node can support up to 3.6 Gbps for PTP and PMP configurations.
- **V3000**: A **Client Node (CN)** is available in two sizes - 44.5 dBi high-gain antenna and 40.5 dBi lower gain antenna, both with beamforming. These client nodes can support up to 5.4 Gbps, with channel bonding for PTP configurations.

- **V5000:** A **dual-sector Distribution Node (DN)** that contains two sectors covering up to 280 degrees with beamforming. A single V5000 can connect up to four other distribution nodes or up to 30 client nodes. V5000 can be used for PTP, PMP, and Mesh configurations.

Figure 6: 60 GHz cnWave products



Features

This section lists the features of each product of 60 GHz cnWave.

V1000 CN

- Supports modulations BPSK to 16 QAM (MCS1 to MCS12)
- Integrated antenna with beam forming
- 38 dBm EIRP
- Gigabit Ethernet
- 1 Gbps UL/1 Gbps DL throughput
- Powered by passive PoE or 802.3af/at PoE
- IP66/67

V2000 CN

- Supports modulations BPSK to 16 QAM (MCS1 to MCS12)
- 34.5 dBi ultra-high gain antenna with beam forming, peak 49 dBm EIRP
- 2.5 Gigabit Ethernet Main interface
- 2.5 Gigabit Ethernet Auxiliary (Aux) interface
- 1.8 Gbps UL or 1.8 Gbps DL throughput
- 802.3at POE (2-pair or 4-pair for higher wattage) or a Passive PoE

- Supports Aux PoE out (802.3af/at PoE)
- IP66/67

V3000 CN

- Supports modulations BPSK to 16 QAM (MCS1 to MCS12)
- 44.5 dBi ultra-high gain antenna with beam forming 60.5 dBm EIRP
- 40.5 dBi ultra-high gain antenna with beam forming 54.5 dBm EIRP
- 10 Gigabit Ethernet
- Supports 10G SFP+ or 1G SFP
- 1.8 Gbps UL/1.8 Gbps DL throughput
- CB2 2.7 Gbps UL / 2.7 Gbps DL
- Gigabit Ethernet Auxiliary Interface
- 802.3at POE (2-pair or 4-pair for higher wattage) or a Passive POE
- Supports Aux PoE out (802.3af/at PoE)
- IP66/67

V5000 DN

- Supports modulations BPSK to 16QAM (MCS1 to MCS12)
- Dual sector - 280-degree antenna with beamforming
- 38 dBm EIRP
- 10 Gigabit Ethernet
- Supports 10G SFP or 1G SFP
- 1.8 Gbps UL/1.8 Gbps DL throughput per sector
- Gigabit Ethernet Auxiliary Interface
- 802.3at POE (2-pair or 4-pair for higher wattage) or a Passive POE
- Supports Aux PoE out (802.3af/at PoE)
- IP 66/67

Wireless operation

This section describes how the 60 GHz cnWave is operated, including topology, modulation modes, power control, and security.

Wireless topology


60 GHz cnWave supports operation in three topologies:

- [Point to point \(PTP\)](#)
- [Point to Multipoint \(PMP\)](#)
- [Mesh](#)

PTP

The PTP topology provides a point-to-point link using V1000, V2000, and V3000.


Figure 7: PTP Topology



PMP

The PMP topology provides a point to multi-point where a V5000 acts as a PoP DN and V5000, V3000, V2000, V1000 act as Clients.


Figure 8: PMP Topology



Mesh

Mesh efficiently distributes capacity and improves availability, using Open/R based layer 3 IPv6 meshing. It allows for route diversity which provides high network availability and supports up to 15 hops away from a PoP node. Network bandwidth is reduced at each hop, and the total bandwidth available in the network is limited to a PoP node's network reappearance. Mesh is a distributed network application platform that determines appropriate routes between the mesh nodes.

Figure 9: Mesh topology



Modulation

Following tables list modulation supported during L2 and L3 throughput:

Table 3: Modulation and coding rate for CB1

MCS	Modulation	Coding Rate	L2 Throughput (Mb/s) DMG-CB1 (2.16 GHz Channel)
2	$\pi/2$ BPSK	1/2	572
3	$\pi/2$ BPSK	5/8	800
4	$\pi/2$ BPSK	3/4	914
6	$\pi/2$ QPSK	1/2	1256
7	$\pi/2$ QPSK	5/8	1600
8	$\pi/2$ QPSK	3/4	1828
9	$\pi/2$ QPSK	13/16	1942
10	$\pi/2$ 16QAM	1/2	2400
11	$\pi/2$ 16QAM	5/8	3200
12	$\pi/2$ 16QAM	3/4	3656

Table 4: Modulation and coding rate for CB2


MCS	Modulation	Coding Rate	L2 Throughput (Mb/s) EDMG-CB2 (4.32 GHz Channel)
2	$\pi/2$ BPSK	1/2	1244
3	$\pi/2$ BPSK	5/8	1524
4	$\pi/2$ BPSK	3/4	1750
5	$\pi/2$ BPSK	13/16	1792
7	$\pi/2$ QPSK	1/2	2280
8	$\pi/2$ QPSK	5/8	2740
9	$\pi/2$ QPSK	3/4	3480
10	$\pi/2$ QPSK	13/16	3800
11	$\pi/2$ QPSK	7/8	4260
12	$\pi/2$ 16QAM	1/2	5000
13	$\pi/2$ 16QAM	5/8	5420

Link adaptation

Link adaptation is performed independently for each link for data traffic, and it is closed loop based. Adjusting the Tx modulation and coding scheme from MCS2 to MCS12 selected for transmission. It is adjusted based on the following:

- Packet Error Ratio (PER),
- SNR,
- local measurements of successful and unsuccessful frame transmissions (for example, count of frames Acknowledged (ACKed) or Not ACKed).

Figure 10: Adjusting links




Start from MCS2, adjust based on signal quality, when the session is idle, fall back to MCS-9 or any highest MCS achieved below MCS-9.

Synchronization

Synchronization is used to control the transmit and receive signals to prevent self-interference. Radios assigned with the same polarity will be transmitting and receiving at the same time. There are two types of polarities:


- Odd (if Odd nodes are Tx)
- Even (if Even nodes are Rx)

Figure 11: Odd and even polarities



The MAC synchronizes its timers to an external, accurate time source, such as GPS or IEEE 1588. A timing pulse that resets the Timing Synchronization Function (TSF) on the DN is repeated once every second. This timing pulse occurs exactly at the turn of each second.

Figure 12: The MAC synchronization



Time-division duplexing access mechanism

60 GHz cnWave uses a Time Division Duplex (TDD) channel access mechanism. All cnWave nodes are time-synchronized and this is achieved through internal GPS, IEEE 1588(roadmap), or Cambium Sync (roadmap), and each sector of a node is assigned specific times during which it can transmit or receive. A timing pulse that resets the Timing Synchronization Function (TSF) on the DN is repeated once every second (1PPS). This timing pulse occurs exactly at the turn of each second and Sub-Frames begin every 200 microseconds.

General operation of MAC layer

MAC is highly modified from that in IEEE 802.11-2016. Use TDD MAC by substituting TDD access for all other access. 60 GHz cnWave supports a fixed 50-50 up/down ratio.

60 GHz cnWave uses only the following frames:

- Data
- QoS-Null (frame does not carry any data)
- Management Action (for example, beamforming, and others.)
- Block ACK (used for sending an ACK to multiple nodes/packets at once)
- ACK

Frame types

Below are the types of frames in 60 GHz cnWave:

- **Management frames** - A node sends all management frames using the DMG control mode PHY, MCS 0.
- **Control frames** - A node sends the ACK frame using the DMG control mode PHY, MCS 0. A node sends the Block ACK frame using the DMG single carrier PHY, MCS 1.
- **Data frames** - A node sends data frames using MCS 2 through MCS 12 of the DMG single carrier PHY, as determined by the link adaptation algorithm.

Wireless encryption

60 GHz cnWave supports an optional encryption, for data transmitted over the wireless link, using the following options:

- Disabled wireless encryption (which is disabled).
- Pre-Shared Key (PSK) is set, where a pre-configured secret at both ends is configured. The derivation of shared secret is based on WPA2.
- With a configured Radius server IP, cnWave nodes do EAP-TLS using X.509 certificates.

Designing wireless networks

For designing wireless networks, refer to [LINKPlanner](#).

TDD synchronization

V2000, V3000, and V5000 have built-in GPS receivers. The E2E Controller manages the TDD synchronization.

System management

This section introduces the 60 GHz cnWave management system, including the web interface, installation, configuration, alerts, and upgrades.

Management agent

The 60 GHz cnWave equipment is managed through an embedded management agent. Management workstations, network management systems, or PCs can be connected to this agent using a choice of in-band or out-of-band network management modes.

The management agent includes an IPv4/IPv6 interface at the management agent. The IP interface operates in the following modes:

- IPv4 only
- IPv6 only
- Dual IPv4/IPv6

Network management

cnMaestro is a Cambium Network Management System (NMS). This is a single plane to manage the complete Cambium product portfolio. It uses secure WebSocket for management traffic to manage all Cambium products on the same system. Configurations can be pushed from the cnMaestro through the E2E Controller to the end devices.

cnMaestro NMS is used to:

- Manage cnWave network including E2E, CN, and DN.
- Show the connection topologies.
- Collect KPIs/statistics, alarms, logs (via the E2E device agent).
- Perform software upgrade.

IPv6

IPv6 address is 128 bits (16 Bytes) address. The subnet ID in IPv4 is called a prefix in IPv6. In IPv6, Neighbor Discovery Protocol (NDP) is used with ICMPv6 to resolve the MAC address. IPV6 does not have broadcast but only has multicast.

60 GHz cnWave products get assigned with a unique IP in mesh, either from Controller (CPA) or PoP (DPA), known as loopback address (lo). In Layer 3 mode, nodes can also send Router Advertisement(RA) for all its downstream devices to acquire an IPv6 address. Prefix for RA can either be configured or device from lo.

System logging

For information on logging into the system using user interface (UI), refer to [Logging into the web interface](#).

Software upgrade

Refer to [Software upgrade](#) for more information.

System Hardware

This topic provides information about the hardware of 60 GHz cnWave.

Wireless nodes

The 60 GHz cnWave solution includes three types of wireless nodes:

- V1000 Client Node
- V2000 Client Node
- V3000 (44.5 dBi and 40.5 dBi) Client Node
- V5000 Distribution Node

V1000 Client Node (CN)

V1000 is an outdoor CN that can be connected to a distribution node wirelessly. V1000 supports a Gigabit Ethernet interface and is powered by 802.3af/at PoE compliant power supply or a passive PoE.

Figure 13: V1000 CN's front and rear views



V1000 CN - Part numbers

Order the V1000 CN from Cambium Networks (as listed in [Table 5](#)). Each V1000 CN is supplied with a mounting bracket for wall mount or pole mount, and an indoor power supply.

Table 5: V1000 CN part numbers

Product description	Part number
60GHz cnWave V1000 Client Node with US cord	C600500C001B
60GHz cnWave V1000 Client Node with EU cord	C600500C003B
60GHz cnWave V1000 Client Node with UK Cord	C600500C004B

Product description	Part number
60GHz cnWave V1000 Client Node with ANZ Cord	C600500C008B
60GHz cnWave V1000 Client Node with Brazil Cord	C600500C009B
60GHz cnWave V1000 Client Node with Argentina Cord	C600500C010B
60GHz cnWave V1000 Client Node with China Cord	C600500C011B
60GHz cnWave V1000 Client Node with South Africa Cord	C600500C012B
60GHz cnWave V1000 Client Node with India Cord	C600500C013B
60GHz cnWave V1000 Client Node with no Cord	C600500C014B
60GHz cnWave V1000 Client Node with Israel cord - for Israel Only	C600500C016B
60GHz cnWave V1000 Client Node with no Cord and no Power supply	C600500C017B

V2000 Client Node (CN)

V2000 is an outdoor CN that can be connected to a DN. This CN can also act as a DN for PTP deployments. It supports a 2.5 Gigabit Ethernet Main interface and 2.5 Gigabit Ethernet Auxiliary (Aux) interface. The V2000 CN can support a single wireless link and therefore, it can be used as a CN in all topologies or POP in a PTP topology.

A V2000 CN can be powered using 30W passive POE or using 802.3at compliant POE switch. For more information about the supported power supply and cable lengths, refer to the [Power supply units \(PSU\)](#) section. A V2000 CN can also power 802.3af/at compliant auxiliary device through the Aux Ethernet interface. For more information about Aux PoE interface, refer to the [Aux PoE - Powering options](#) section.

Figure 14: V2000 CN's front and rear views



V2000 CN - Part numbers

Order the V2000 CN from Cambium Networks (as listed in [Table 6](#)). A V2000 CN radio is supplied without a mounting bracket and with or without a power supply.

Table 6: V2000 CN part numbers

Product description	Part number
60GHz cnWave V2000 Client Node 30W with Israel Cord	C600500C026B
60GHz cnWave V2000 Client Node 30W with South Africa Cord	C600500C027B
60GHz cnWave V2000 Client Node 30W with India Cord	C600500C028B
60GHz cnWave V2000 Client Node 30W with no Cord	C600500C029B
60GHz cnWave V2000 Client Node no power supply, no power cord	C600500C030B
60GHz cnWave V2000 Client Node 30W with US cord	C600500C020B
60GHz cnWave V2000 Client Node 30W with EU cord	C600500C031B
60GHz cnWave V2000 Client Node 30W with UK Cord	C600500C032B
60GHz cnWave V2000 Client Node 30W with ANZ Cord	C600500C033B
60GHz cnWave V2000 Client Node 30W with Brazil Cord	C600500C034B
60GHz cnWave V2000 Client Node 30W with Argentina Cord	C600500C035B

V3000 Client Node (CN)

V3000 is an outdoor CN that can be connected (wireless) to a DN or another V3000 DN. V3000 supports a 10 Gigabit Ethernet interface, a 10G SFP+ interface port, and a Gigabit Ethernet Aux interface.

V3000 can be powered using 60W passive POE or using an AC/DC PSU through a mini adapter (for more information, refer to the power supply and cable lengths supported in the [Power supply units](#) section). V3000 DN can also power 802.3af/at compliant auxiliary device through the Gigabit Aux interface.

For more information about Aux PoE interface, refer to the [Aux PoE - Powering options](#) section.

Figure 15: V3000 Client Node without antenna assembly and with 44.5 dBi and 40.5 dBi antenna assemblies



V3000 Part numbers

Order the V3000 CN from Cambium Networks ([V3000 CN part numbers](#)). The V3000 CN radio is supplied without an antenna assembly, bracket, or power supply. Refer to the [Precision brackets](#) section for details of suitable brackets.

**Note**

Use a dedicated antenna assembly for V3000 CN.
Order the antenna assembly required for each CN radio.

Table 7: V3000 CN part numbers

Cambium description	Cambium part number
60 GHz cnWave V3000 CN radio only	C600500C024B
60 GHz cnWave V3000 CN antenna assembly, 44.5 dBi	C600500D001B
60 GHz cnWave V3000 CN antenna assembly, 40.5 dBi, 4 Pack	C600500D002B
60 GHz cnWave V3000 CN antenna assembly, 44.5 dBi, 4 Pack	C600500D003B
60 GHz cnWave V3000 CN Radio only - Israel Only	C600500C025B

V5000 Distribution Node (DN)

V5000 is an outdoor DN that can be connected to multiple V1000 or V3000 CNs wirelessly. V5000 supports a 10 Gigabit Ethernet interface, a 10G SFP+ interface port, and a Gigabit Ethernet Aux interface.

V5000 can be powered using 60W passive POE or using an AC/DC PSU through mini an adapter (for more information, refer to the power supply and cable lengths supported in the [Power supply units](#) section). V5000 DN can also power 802.3af/at compliant auxiliary device through the Gigabit Aux interface.

For more information about Aux PoE interface, refer to the [Aux PoE - Powering options](#) section.

Figure 16: V5000 Distribution Node front and rear views

V5000 Part numbers

Order the V5000 Distribution Node (DN) from Cambium Networks (as shown in the table below). The V5000 DN is supplied without a mounting bracket or power supply.

Table 8: V5000 DN part numbers

Cambium description	Cambium part number
60GHz cnWave V5000 Distribution Node	C600500A004B
60GHz cnWave V5000 Distribution Node - Israel Only	C600500A005B

Radio mounting brackets

V1000 Wall and pole mount

The V1000 CN is supplied with a mounting plate and a band clamp. The mounting plate can be used for mounting the V1000 on a wall, or it can be used with the supplied band clamp to mount the V1000 on a pole with a diameter in the range of 25 mm to 70 mm (1 inch to 2.75 inches). Note that the larger diameters can be accommodated with the customer supplied clamps.

Figure 17: V1000 mounting plate and band clamp



V1000 Adjustable pole mount (N000900L022A)


The adjustable pole mount is used to provide elevation adjustment when a V1000 CN is mounted on a pole. The adjustable pole mount works with poles with diameters in the range of 25 mm to 70 mm (1 inch to 2.75 inches).



Note

The adjustable pole mount does not come with a clamp. You can use the one that is supplied with the V1000 box. Larger diameter poles can be accommodated with the customer supplied clamps.


Figure 18: V1000 adjustable pole mount



V2000 Adjustable pole mount

The V2000 CN is supplied with adjustable pole mounting accessories such as mounting plate, a hose clamp, and four screws (as shown in [Figure 19](#)). These mounting accessories can be used to mount the V2000 CN on a vertical pole.

[Figure 19](#): V2000 and pole mounting accessories



The adjustable pole mount bracket (as shown in [Figure 20](#)) is used to mount the V2000 CN on a vertical pole with a diameter in the range of 25 mm to 70 mm (1 inch to 2.75 inches). The bracket provides a fine adjustment of up to $\pm 20^\circ$ in elevation for accurate alignment of V2000.

[Figure 20](#): V2000 Adjustable pole mount




V3000 Precision bracket (C000000L125A)


The precision bracket (as shown in [Figure 21](#)) is used to mount the V3000 CN on a vertical pole with a diameter in the range of 25 mm to 70 mm (1 inch to 2.75 inches). It accepts band clamps for larger diameter poles.

The precision bracket provides fine adjustment of up to 18° in azimuth and $\pm 30^\circ$ in elevation for accurate alignment of the V3000.

[Figure 21](#): Precision bracket



[Figure 22](#): Precision bracket components



Bracket body




Azimuth arm




Long (120 mm) M8 screws and flange nuts



40 mm M8 screws, plain washers, and Nyloc nuts



28 mm M6 screws, M8 spacers, and pole mount clamp



Bracket base



V3000 mount

V3000 Tilt bracket (N000045L002A)

The tilt bracket (as shown in [Figure 23](#)) is used to provide elevation adjustment when a V3000 CN or V5000 DN is mounted on a pole. The tilt bracket works with poles with diameters in the range of 25 mm to 70 mm (1 inch to 2.75 inches).

The tilt bracket assembly may be used with third-party band clamps to mount the ODU on a larger pole (the diameter range depends on the clamps used).

Figure 23: Tilt bracket assembly



V5000 Pole mount (C000000L137A)

The pole mount (as shown in [Figure 24](#)) is used to mount a V5000 DN on a vertical pole with a diameter in the range of 25 mm to 70 mm (1 inch to 2.75 inches). It provides coarse azimuth (but not elevation) adjustment. Band clamps can be used for V5000 pole mount to accommodate the larger diameter poles.


Figure 24: Pole mount



V5000 Wall mount (C000000L136A)

The wall mount ([Wall mount](#) figure below) is used to mount a V5000 DN on a vertical wall. It does not provide azimuth or elevation adjustment. The wall mount requires additional fixing hardware suitable for the type of wall.

Figure 25: Wall mount



Bracket part numbers

Order mounting brackets by using the Cambium part numbers listed in the table below.

Table 9: Radio mounting bracket part numbers

Bracket	Radio nodes	Cambium Part Number
Adjustable pole mount	V1000	N000900L022A
Tilt bracket assembly	V3000	N000045L002A
Wall mount bracket	V5000	C000000L136A
Pole mount bracket	V5000	C000000L137A
Precision bracket	V3000	C000000L125A

Radio accessories


Telescope mounting kit for precision brackets

The Precision bracket and an alignment telescope provide the most accurate option for aligning the radio during installation. The telescope is temporarily mounted on the bracket using the telescope mounting kit for precision brackets.

The telescope mounting kit consists of a mounting plate, a knurled screw, and two rubber O-rings.

Order the telescope mounting kit from Cambium Networks.

Figure 26: Telescope mounting kit



Order a suitable telescope from a specialist supplier specifying the following details:

Right angle, erecting, 9x50 mm alignment scope with 5° field of view

Figure 27: Typical alignment telescope



Alignment Tube

The Alignment tube (as shown in [Figure 28](#)) is designed to be used with V3000 when setting up a Point-to-Point link. It is ideal for aligning a Point-to-Point link that spans up to 600 m.

Figure 28: Alignment Tube



For longer links up to 3 km, Cambium Networks suggests using the telescopic mounting kit (C000000L139) and a finder scope.



Note

For details on how to fit the Alignment tube for V3000, refer to [Fixing the alignment tube](#).

Radio accessory part numbers

Order radio accessories using the Cambium Part Number in the [Radio accessory part numbers](#) table below.

Table 10: Radio accessory part numbers

Accessory	Radio nodes	Cambium Part Number
Telescope mounting kit	V3000	C000000L139A
Alignment Tube	V3000	C000000L190A
Radome for 44.5 dBi antenna	V3000	C600500D004A



Note

For more information on the radome for a V3000 44.5 dBi antenna, refer to the 60 GHz cnWave Quick Start Guide.

Radio external interfaces

V1000 CN

Figure 29: External interfaces for V1000 CN



Table 11: External interfaces V1000 CN

Port name	Connector	Interface	Description
PSU	RJ45	PoE input	Standard 802.3af/at PoE
		100/1000 BASE-T Ethernet	Data and management

V2000 CN

Figure 30: External interfaces for V2000 CN




Table 12: External interfaces - V2000 CN

Port name	Connector	Interface	Description
PSU	RJ45	POE Input	Passive PoE or 802.3at (two pairs or four pairs for higher wattage)
		100m/1000m/2.5G BASE-T Ethernet	Data and management
AUX	RJ45	POE Output	IEEE 802.3af/at compliant, higher wattage supported (For more information, refer to the Aux PoE - Powering options section.)
		100m/1000m/2.5G BASE-T Ethernet	Data and management

V3000 CN

Figure 31: External interfaces for V3000 CN




Table 13: External interfaces V3000 CN

Port name	Connector	Interface	Description
SFP+	SFP	10G BASE-SR/10G BASE-LR/1G Base-SX using optional SFP+/SFP optical or copper module SFP-1G-SX / SFP-1G-LX using optional SFP optical or copper module	Data and management
PSU	RJ45	PoE input	Passive PoE or 802.3at (two pairs or four pairs for higher wattage)
		100m/1000m/2.5G BASE-T/5G BASE-T/ 10G BASE-T Ethernet	Data and management

Port name	Connector	Interface	Description
AUX	RJ45	PoE output	IEEE 802.3af/at compliant, higher wattage supported for specific cases (For more information, refer to the Aux PoE - Powering options section.)
		100/1000 BASE-T Ethernet	Data and management

V5000 DN

Figure 32: External interfaces for V5000 DN




Table 14: External interfaces V5000 DN

Port name	Connector	Interface	Description
SFP+	SFP	10G BASE-SR/10G BASE-LR/1G Base-SX using optional SFP+/SFP optical or copper module	Data and management
		SFP-1G-SX / SFP-1G-LX using optional SFP optical or copper module	
PSU	RJ45	PoE input	Passive PoE or 802.3at (two pairs or four pairs for higher wattage)
		100m/1000m/2.5G BASE-T/5G BASE-T/ 10G BASE-T Ethernet	Data and management
AUX	RJ45	PoE output	IEEE 802.3af/at compliant, higher wattage supported for specific cases (For more information, refer to the Aux PoE - Powering options section.)
		100/1000 BASE-T Ethernet	Data and management

Radio specifications

The 60 GHz cnWave Radios conform to the specifications listed in [Radio node specifications](#).

Table 15: Radio node specifications

Category	Specification	
Dimensions	V1000 Client Node	169 mm × 100 mm × 54 mm (6.6 in × 3.9 in × 2.1 in)
	V2000 Client Node	250 mm × 166 mm × 220 mm (9.8 in × 6.5 in × 8.6 in)
	V3000 Client Node (44.5 dBi)	421 mm × 347 mm × 349 mm (16.5 in × 13.6 in × 13.7 in)
	V3000 Client Node (40.5 dBi)	343 mm × 198 mm × 251 mm (13.5 in × 7.7 in × 9.8 in)
	V5000 Distribution Node	280 mm × 186 mm × 103 mm (11.0 in × 7.3 in × 4.0 in)
Weight	V1000 Client Node	0.46 kg (1.01 lbs)
	V2000 Client Node	1.9 kg (4.18 lbs)
	V3000 Client Node (44.5 dBi)	4.17 kg (9.1 lbs) including big antenna dish 6.12 kg (13.4 lbs) = radio with dish + precision bracket
	V3000 Client Node (40.5 dBi)	3.2 kg (7.05 lbs) including small antenna dish 5.15 kg (11.3 lbs) = radio with dish + precision bracket
	V5000 Distribution Node	3.12 kg (6.8 lbs) including antenna dish 3.76 kg (8.2 lbs) = radio with dish + universal pole bracket
Temperature	-40°C (-40°F) to +60°C (140°F)	
Wind survival	200 kph (124 mph) maximum	
Humidity	100% condensing	
Liquid and particle ingress	IP66, IP67	
Power consumption	V1000 Client Node	10 W
	V2000 Client Node	18W, up to 48W with POE Out enabled
	V3000 Client Node	30 W, up to 60 W with PoE Out enabled
	V5000 Distribution Node	35 W, up to 65 W with PoE Out enabled

Category	Specification	
Power input interface	V1000 Client Node	IEEE 802.3af
	V2000 Client Node	Passive PoE or 802.3at (two pairs or four pairs for higher wattage)
	V3000 Client Node	Passive PoE or 802.3at (two pairs or four pairs for higher wattage)
	V5000 Distribution Node	Passive PoE or 802.3at (two pairs or four pairs for higher wattage)
Power output interface	V2000 Client Node	IEEE 802.3af/at, 30 W maximum
	V3000 Client Node	IEEE802.3af/at, 25 W maximum
	V5000 Distribution Node	IEEE 802.3af/at, 25 W maximum

Power supply units (PSU)

PSU Options

Order PSUs from Cambium Networks. The power supply component and the part numbers are described in the following table.

Table 16: Power supply components and part numbers

Product description	Radio node	Cambium part number
Outdoor AC/DC PSU, 100W, 54V DC	V2000, V3000, and V5000	N000000L179B
Waterproof PSU Cable Joiner 14-16 AWG	V2000, V3000, and V5000	N000000L180A
DC to RJ45 Plug Power Adaptor	V2000, V3000, and V5000	C000000L184A
Cable Gland, Long, M25, Qty 5	V2000, V3000, and V5000	C000000L124A
PoE, 60W, 56V, 5GbE DC Injector, Indoor, Energy Level 6 Supply	V2000, V3000, and V5000	N000000L142A
PoE, 60W, 56V, 10GbE DC Injector, Indoor, Energy Level 6 Supply	V2000, V3000, and V5000	C000000L141A
PoE, 30W, 56V, 5GbE DC Injector, Indoor, Energy Level 6 Supply	V1000 and V2000	N000000L034B
PoE Gigabit DC Injector, 15W Output at 56V, Energy Level 6, 0C to 50C	V1000	N000900L017A N000900L017B (main PoE)
AC power Injector 56V, 60W	V2000, V3000, and V5000	N000065L001C
CABLE, UL POWER SUPPLY CORD SET, 720mm, AUS/NZ	V1000, V2000, V3000, and	N000900L011A

Product description	Radio node	Cambium part number
	V5000	
CABLE, UL POWER SUPPLY CORD SET, INDIA	V1000, V2000, V3000, and V5000	N000900L012A
CABLE, UL POWER SUPPLY CORD SET, ARGENTINA	V1000, V2000, V3000, and V5000	N000900L013A
CABLE, UL POWER SUPPLY CORD SET, CHINA	V1000, V2000, V3000, and V5000	N000900L015A
CABLE, UL POWER SUPPLY CORD SET, 720mm, US	V1000, V2000, V3000, and V5000	N000900L031A
CABLE, UL POWER SUPPLY CORD SET, 720mm, EU	V1000, V2000, V3000, and V5000	N000900L032A
CABLE, UL POWER SUPPLY CORD SET, 720mm, UK	V1000, V2000, V3000, and V5000	N000900L033A
CABLE, UL POWER SUPPLY CORD SET, 720mm, Brazil	V1000, V2000, V3000, and V5000	N000900L034A
CABLE, UL POWER SUPPLY CORD SET, 720mm, Israel	V1000, V2000, V3000, and V5000	N000900L037A

Refer to [Maximum cable lengths](#) for details of the maximum cable lengths and the maximum PoE output power for different powering options.

V1000 - Power over Ethernet (PoE)

The V1000 CN is always powered using Power over Ethernet (PoE) at a nominal 56V, as shown in the [PoE power supply to V1000](#) figure using the Gigabit power injector supplied with the radio, or using an IEEE 802.3af PoE output from an Ethernet switch.

Figure 33: PoE power supply to V1000



Table 17: PoE, 15W 56V, 1 Gigabit DC injector

Category	Specification
Dimensions	118 mm (4.64 in) x 43 mm (1.69 in) x 32.4 mm (1.27 in)
Weight	0.18 Kg (0.39 lbs)
Temperature	0°C (32°F) to +50°C (140°F)
Humidity	10% to 95 % non-condensing
AC Input	90-264V AC, 47-63 Hz
DC Output Voltage	56V
DC Output current	0.25A
Efficiency	Better than 84% at full load
Over Current Protection	Hiccup mode, recovers automatically after the fault condition is removed
Hold up time	At least 10 milliseconds
RJ45 POE Port	7,8 ----- DC V- 5,6 ----- DC V+



Note

The Gigabit power injector is supplied with the cnWave V1000 CN. Order part N000900L017B to obtain spares.



Warning

Always use an appropriately rated and approved AC supply cord-set in accordance with the regulations of the country of use.

V2000 - PoE

The V2000 CN is always powered using POE at a nominal 56V using 5GbE POE Injector, which is optional (Cambium part number: N000000L034B), or using an IEEE 802.3at POE output from an Ethernet Switch.

Figure 34: PoE power supply to V2000



Figure 35: Power supply to V1000 or V2000




Table 18: PoE, 30W 56V, 5GbE DC injector (N000000L034B)

Category	Specification
Dimensions	140 mm (5.5 in) x 53 mm (2.08 in) x 35 mm (1.37 in)
Weight	0.24 Kg (0.5 lbs)
Temperature	0°C (32°F) to +50°C (140°F)
Humidity	10% to 95 % non-condensing
AC Input	90-264 V AC, 47-63 Hz
DC Output voltage	56V
DC Output current	0.54 A
Efficiency	Better than 88% at full load
Over Current Protection	Hiccup mode, recovers automatically after the fault condition is removed
Hold up time	At least 10 milliseconds
RJ45 POE Port	1,2,7,8 ----- DC V- 3,4,5,6 ----- DC V+

V3000/V5000 - PoE

The V3000 CN and V5000 DN can be powered using DC power at a nominal 54V, using 14 AWG or 16 AWG cable, as shown in [Figure 38](#).

[Figure 36](#): PoE power supply to V3000 or V5000



[Figure 37](#): 10 GbE PoE (C000000L141A)



Note

These PoEs (as shown in [Figure 36](#) and [Figure 37](#)) can also be used to power up V2000.





Table 19: PoE, 60W, 56V, 10 GbE DC injector (C000000L141A)

Category	Specification
Dimensions	140 mm (5.5 in) x 53 mm (2.08 in) x 35 mm (1.37 in)
Weight	0.24 Kg (0.5 lbs)
Temperature	0°C (32°F) to +50°C (140°F)
Humidity	10% to 95 % non-condensing
AC Input	90-264 V AC, 47-63 Hz
DC Output voltage	56V
DC Output current	1.07 A
Efficiency	Better than 88% at full load
Over Current Protection	Hiccup mode, recovers automatically after the fault condition is removed
Hold up time	At least 10 milliseconds
RJ45 POE Port	1,2,7,8 ----- DC V- 3,4,5,6 ----- DC V+

V2000/V3000/V5000 - Outdoor AC/DC power supply unit

The outdoor DC PSU can be used for V2000, V3000, or V5000.

Figure 38: DC power supply to V2000, V3000, or V5000



The outdoor PSU can be installed indoors, in an outdoor cabinet, or inside street furniture.

Figure 39: Outdoor AC/DC PSU, 100 W, 54V DC (N000000L179B)



Table 20: Outdoor AC/DC PSU, 54V DC


Category	PSU	Specification
Part number and dimensions	N000000L179B (100W)	220 mm (8.7 in) x 68 mm (2.7 in) x 39 mm (1.5 in)
Power	100W	
Temperature	-40°C (-40°F) to +60°C (140°F)	

Category	PSU	Specification
Humidity	20 to 95 % non-condensing	
Waterproofing	IP65/IP67	
AC Input	90-305 V AC, 47-63 Hz	
DC Output Voltage	54V	
DC Output current	60W	1.15 A
	100W	1.77 A
Efficiency	Better than 90% at full load	
Over Current Protection	Hiccup mode, recovers automatically after the fault condition is removed	
Hold up time	At least 16 milliseconds	
Power factor	Better than 0.95	

Figure 40: Cable joiner



Figure 41: DC to RJ45 plug power adapter



Cable joiners and DC to RJ45 cable adapters are used to connect to outdoor AC/DC PSU. Refer to [Maximum cable lengths](#) for details of the maximum cable lengths and the maximum PoE output power for different powering options.



Note

If you are using the mini RJ45 power adapter, you must use the cable gland (C000000L123A) to ensure that the cable is protected. This cable gland comes in the radio box. For more details about the cable gland, refer to [Table 28](#).

If the cable is ≤ 6 mm, you must use the gland (C000000L176A).

Aux PoE - Powering options

V2000, V3000, and V5000 devices support 802.3at compliant Aux POE output, using which these devices can power each other. This section lists and describes the supported cable lengths and maximum power available on the Aux port of these devices.

Table 21 provides details of the power consumption of the devices without Aux PoE enabled.

Table 21: Power consumption without Aux PoE enabled

ODU	In typical cases	In maximum (worst) case
V2000	20W	22W
V3000	24W	27W
V5000	28W	32W

The Aux PoE output power depends on:

- Voltage of the PoE injector used to power on the main ODU and
- Cable length from the PoE injector to the main ODU.

Table 22 lists the different PoE injector voltages used and the Aux power output available for the various ODUs.

Table 22: Aux power output for the different ODUs

ODU	ODU PoE voltage	Minimum Aux power available	ODU PoE Voltage	Maximum Aux power available
V2000	48	30W	56	36W
V3000	48	25W	56	30W
V5000	48	25W	56	30W

Table 23 provides information on cable lengths of main PSU and Aux PoE for powering each ODU with other devices.

Table 23: Details of cable lengths of main PSU and Aux PoE - powering

ODU	Aux Device	Main PSU cable length (Max)	Aux PoE cable length (Max)	Feasible (Yes/No)
Using V2000 and powering V2000/V3000/V5000:				
V2000	V2000	0m to 100m	0m to 100m	Yes
	V3000	0m to 100m	0m to 100m	Yes
	V5000	0m to 100m	0m to 100m	Yes
Using V3000 and powering V2000/V3000/V5000:				

ODU	Aux Device	Main PSU cable length (Max)	Aux PoE cable length (Max)	Feasible (Yes/No)
V3000	V2000	100m	100m	Yes
	V3000	100m	100m	Yes
	V5000	100m	100m	Yes, only when 56V PoE is used
Using V5000 and powering V2000/V3000/V5000:				
V5000	V2000	100m	100m	Yes
	V3000	100m	100m	Yes
	V5000	100m	100m	Yes, only when 56V PoE is used

Table 24 lists the possible and feasible combinations of devices (V1000, V2000, V3000, V5000) and power injectors.

Table 24: Possible combinations of devices, voltage, and PoE injector

ODU/Aux device	V1000	V2000	V3000	V5000
56V, 60W PoE:				
V1000	Not applicable	Not applicable	Not applicable	Not applicable
V2000	Yes	Yes	Yes	Yes
V3000	Yes	Yes	Yes	Yes
V5000	Yes	Yes	Yes	Yes
48V, 60W PoE:				
V1000	Not applicable	Not applicable	Not applicable	Not applicable
V2000	Yes	Yes	Yes	Yes
V3000	Yes	Yes	Yes	No
V5000	Yes	Yes	Yes	No



Note

Consider the following key points:

- It is recommended using 56V PoE Injector to achieve the described powering options. Powering options vary depending on the PoE Injector's voltage rating.
- For V3000 and V5000, the main PoE cable can be CAT6/6A and Aux PoE cable can be CAT5/5e for powering V3000, V5000, or V2000.

- For V2000, the main PoE cable can be CAT5e and Aux PoE cable can be CAT5e for powering V2000, V3000, or V5000.

Ethernet and DC cables

Maximum cable lengths

Ethernet

For all cnWave radios, the maximum cable length for data transmission over copper Ethernet (100BASE-TX, 1000BASE-T, 2.5GBASE-T, 5GBASE-T, 10GBASE-T) is 100 m (328 ft) from the radio to the connected equipment.

Cambium Networks recommends using outdoor braided **CAT6A** cable for V2000, V3000, and V5000, and outdoor braided **CAT5e** cable for V1000.

For installations where the auxiliary device is powered using ODU Aux POE port, refer to the [Maximum cable lengths supported](#) table.

The maximum cable length for fiber Ethernet (10GBASE-SR, 10GBASE-LR) connections depends on the fiber used. Refer to the [SFP module kits](#) section for details of the Ethernet standards supported and maximum permitted cable lengths.

Power over Ethernet (PoE)

The maximum length for supplying power from a 60 W DC injector over a CAT6A Ethernet cable is shown in the [Maximum cable length for Power over Ethernet](#) table. A 60W DC injector is used to power the V2000, V3000, or V5000.

The maximum length for supplying power from a 30 W DC injector over a CAT6A Ethernet cable is shown in the [Maximum cable length for Power over Ethernet](#) table. A 30W DC injector is used to power V2000.

Table 25: Maximum cable length for PoE supported

Radio	PoE enabled	Maximum cable length
V2000	-	390m
	25W	100m
V3000	-	390m
	25W	72m
V5000	-	330m
	25W	0m to 5m

The available output power for the auxiliary PoE in V2000, V3000, and V5000 is reduced to longer cable lengths, as shown in [Table 26](#).

Table 26: Maximum PoE output power

Radio	Cable length	Maximum Aux PoE output
V2000	0m to 20m	36W
	20m to 70m	30W
	70m to 100m	30W

Radio	Cable length	Maximum Aux PoE output
V3000	0m to 20m	25W
	25m	24.6W
	100m	23.6W
V5000	0m to 5m	25W
	10m	23.1 W
	20m	22.6W
	30m	22.1W
	40m	21.6W
	60m	20.6W
	80m	19.6W
	100m	18.6W



Note

The maximum PoE output power is based on the IEEE 802.3af/at compliant PoE requirements. The power ratings are different for 56V PoE. For more details on the Aux PoE - powering options, refer to the [Aux PoE - Powering options](#) section.

Using AC/DC PSU with a DC power feed

The maximum length for supplying power over a CAT6A Ethernet cable is shown in the [Maximum cable length for DC power](#) table.

Table 27: Maximum cable length for DC power

Radio	PSU	PoE enabled	Maximum cable length 14 AWG	Maximum cable length 16 AWG
V3000	60W	-	780m	490m
		25W	140m	90m
	100W	-	780m	490m
		25W	390m	250m
V5000	60W	-	660m	410m
		25W	Not supported	
	100W	-	660m	410m
		25W	360m	220m

Outdoor copper CAT6A Ethernet cable

Select an outdoor-rated CAT6A cable, ready with RJ45 connectors in one of the following lengths:

- 25m
- 50m
- 100m



Note

Cambium Networks offers the following cable bundles as accessories:

- 305m (N000082L172B - which can be used to make 25m, 50m, 100m, or any other length cables depending on the requirement at the time of installation)
- 100m (N000000L155A)

Alternatively, terminate bulk CAT6A cable with RJ45 connectors at a length to suit each installation.



Attention

Always use CAT6A or better cable that has an overall copper braid shield, is outdoor rated with a UV-resistant sheath.

Table 28: Ethernet cable part numbers

Cambium description	Cambium part number
CAT6A outdoor cable, 305m	N000082L172B
RJ45 connector for CAT6A cable	N000082L174B
CAT6A outdoor cable, 100m	N000000L155A
CAT5E Outdoor Cable, 100m drum	N000082L016A

Cable accessories

This section provides information about the required cable accessories.

Figure 42: Standard cable gland




Figure 43: Long cable gland (C000000L124A)



Cable accessories available from Cambium Networks are listed in the [Cable accessory part numbers](#) table below.

Table 29: Cable accessory part numbers

Cambium description	Cambium part number
Cable gland for 6-9mm cable, M25, Qty 10	C000000L123A
Cable gland Long, M25, Qty 5	C000000L124A
Grounding cable, 0.6m with M6 ring to M6 ring	C000000L138A
Standard cable gland for 4-6mm cable, M25, Qty 10	C000000L176A
DC to RJ45 plug power adapter	C000000L184A
Grounding cable, 1m with M6 ring to M6 ring	N000082L116A



Note

One cable gland for 6-9mm cable size is included with each cnWave radio. Order additional cable glands as spares, where smaller cable size is to be used, or where the V3000 or V5000 Aux port is to be used.

SFP Module kits

SFP Module kits allow the connection of a V3000 CN or V5000 DN radio to a network over a 10 Gigabit optical Ethernet interface in one of the following full-duplex modes:

- 10GBASE-SR
- 10GBASE-LR

Order SFP+ module kits from Cambium Networks ([SFP module part numbers](#)).

The SFP+ module must be used with the long cable gland.

Table 30: SFP module part numbers

Cambium description	Cambium part number
10G SFP+ MMF SR Transceiver, 850nm. -40C to 85C	SFP-10G-SR
10G SFP+ SMF LR Transceiver, 1310nm. -40C to 85C	SFP-10G-LR
1G SFP MMF SX Transceiver, 850nm. -40C to 85C	SFP-1G-SX
1G SFP SMF LX Transceiver, 1310nm. -40C to 85C	SFP-1G-LX
10G SFP+ BaseT (RJ45), -40C to 85C	SFP-10G-Cu-EXT
1000Base-T (RJ45) SFP Transceiver. -40C to 85C	SFP-1G-Copper

Optical cable and connectors

Order an optical cable with LC connectors from a specialist fabricator, quoting the specification shown in the [Optical optic cable and connector specification](#). It must be the correct length to connect the ODU to the other device. LC connectors should be supplied with dust caps to prevent dust build-up.

Figure 44: Optical optic cable and connector specification




Table 31: Optical cable part numbers

Cambium description	Cambium part number
Optical CABLE,MM, 1m	N000082L215A
Optical CABLE,MM, 2.2m	N000082L191A
Optical CABLE,MM, 10m	N000082L192A
Optical CABLE,MM, 20m	N000082L193A
Optical CABLE,MM, 30m	N000082L194A
Optical CABLE,MM, 50m	N000082L195A
Optical CABLE,MM, 80m	N000082L196A
Optical CABLE,MM, 100m	N000082L197A
Optical CABLE,MM, 150m	N000082L198A
Optical CABLE,MM, 200m	N000082L199A
Optical CABLE,MM, 300m	N000082L200A
Optical CABLE,SM, 2.2m	N000082L186A
Optical CABLE,SM, 10m	N000082L187A
Optical CABLE,SM, 20m	N000082L188A
Optical CABLE,SM, 30m	N000082L139A

Cambium description	Cambium part number
Optical CABLE,SM, 50m	N000082L140A
Optical CABLE,SM, 80m	N000082L141A
Optical CABLE,SM, 100m	N000082L142A
Optical CABLE,SM, 150m	N000082L143A
Optical CABLE,SM, 200m	N000082L189A
Optical CABLE,SM, 300m	N000082L190A

System Planning

Site planning

This section describes factors to be considered when planning the proposed link end sites, including grounding, lightning protection, and equipment location for Outdoor Units (ODUs) and power supply units (PSU).

Grounding and lightning protection



Warning

Electro-magnetic discharge (lightning) damage is not covered under warranty. The recommendations in this guide, when followed correctly, give the user the best protection from the harmful effects of EMD. However, 100% protection is neither implied nor possible.

Structures, equipment, and people must be protected against power surges (typically caused by lightning) by conducting the surge current to the ground via a separate preferential solid path. The actual degree of protection required depends on local conditions and applicable local regulations. To adequately protect a 60 GHz cnWave installation, both ground bonding and transient voltage surge suppression are required.

Full details of lightning protection methods and requirements can be found in the International Standards **IEC 61024-1** and **IEC 61312-1**, the U.S. National Electric Code ANSI/NFPA No. 70-1984, or section 54 of the Canadian Electric Code.




Note

International and national standards take precedence over the requirements in this guide.

Lightning protection zones

Use the rolling sphere method (Rolling sphere method to determine the lightning protection zones) to determine where it is safe to mount equipment. An imaginary sphere, typically 50 meters in radius, is rolled over the structure. Where the sphere rests against the ground and a strike termination device (such as a finial or ground bar), all the space under the sphere is in the zone of protection (Zone B). Similarly, where the sphere rests on two finials, the space under the sphere is in the zone of protection.

Figure 45: Rolling sphere method to determine the lightning protection zones





Warning

Never mount equipment in Zone A. Mounting in Zone A may put equipment, structures and life at risk.

Site grounding system

Ensure that the site has a correctly installed grounding system on a common ground ring with access points for grounding ODU.

If the outdoor equipment is to be installed on the roof of a high building, refer to the [Installation](#) section.

Ensure that the system meets the following additional requirements:

- A grounding conductor is installed around the roof perimeter to form the main roof perimeter lightning protection ring.
- Air terminals are installed along the length of the main roof perimeter lightning protection ring, typically every 6.1 m (20 ft).
- The main roof perimeter lightning protection ring contains at least two down conductors connected to the grounding electrode system. The down conductors should be physically separated from one another, as far as practical.

ODU location

Find a location for the ODU (and external antenna for connectorized units) that meets the following requirements:

- The equipment is high enough to achieve the best radio path.
- People can be kept a safe distance away from the equipment when it is radiating.
- The equipment is lower than the top of the supporting structure (tower, mast, or building) or its lightning air terminal.
- If the ODU is connectorized, select a mounting position that gives it maximum protection from the elements, but still allows easy access for connecting and weather proofing the cables. To minimize cable losses, select a position where the antenna cable lengths can be minimized. If diverse or two external antennas are being deployed, it is not necessary to mount the ODU at the mid-point of the antennas.

Drop cable grounding points

To estimate how many grounding kits are required for each drop cable, refer to site installation and use the following criteria:

- The drop cable shield must be grounded near the ODU at the first point of contact between the drop cable and the mast installation, tower or building.
- The drop cable shield must be grounded at the building entry point.

For mast or tower installations installation, use the following additional criteria:

- The drop cable shield must be grounded at the bottom of the tower, near the vertical to the horizontal transition point. This ground cable must be bonded to the tower or tower ground bus bar (TGB) if installed.
- If the tower is greater than 61 m (200 ft) in height, the drop cable shield must be grounded at the tower midpoint, and at additional points as necessary to reduce the distance between ground cables to 61 m (200 ft) or less.
- In high lightning-prone geographical areas, the drop cable shield must be grounded at the spacing between 15 to 22 m (50 to 75 ft). This is especially important for towers taller than 45 m (150 ft).

For roof installations, use the following additional criteria:

- The drop cable shield must be bonded to the building grounding system at its top entry point (usually on the roof).
- The drop cable shield must be bonded to the building grounding system at the entry point to the equipment room.

ODU wind loading

Ensure that the ODU and the structure on which it is mounted are capable of withstanding the prevalent wind speeds at a proposed site. Wind speed statistics should be available from national meteorological offices.

The ODU and its mounting bracket are capable of withstanding wind speeds of up to 325 kph (200 mph).

Wind blowing on the ODU subjects the mounting structure to significant lateral force. The magnitude of the force depends on both wind strength and the surface area of the ODU. Wind loading is estimated using the following formulae:

- Force (in newtons) = $0.5 \times \rho \times V^2 \times A \times C_d$
 - “ ρ ” is the density of air (1.225 kg/m³)
 - “ V ” is the wind speed in meters per second
 - “ A ” is the projected surface area of the ODU in square meters
 - “ C_d ” is the drag coefficient = 1.385.

The drag co-efficient has been measured when the cover plate or antenna is perpendicular to the air flow.

Applying these formulae to the cnWave ODU at different wind speeds, the resulting wind loadings are shown in the following [ODU wind loading \(newtons\)](#) table:

Table 32: ODU wind loading (newtons)

Type of ODU	Max surface area (square meters)	Wind speed (km/h Newtons)					
		200*	225	250	275	300	325
V1000	0.017544	44	56	69	83	99	116
V2000	0.0368	61	78	96	116	138	162
v3000**	0.1764	462	583	719	871	1036	1216
V5000	0.052597188	118	148	185	224	266	312

Equivalent results in US customary units are shown in following [ODU wind loading \(pounds force\)](#) table:

Table 33: ODU wind loading (pounds-force)

Type of ODU	Max surface area (square meters)	Wind speed (km/h lbf)					
		200*	225	250	275	300	325
V1000	0.017544	10	13	16	19	23	26
V2000	0.0368	14	18	22	26	31	36
v3000**	0.1764	104	131	162	196	233	273
V5000	0.052597188	27	33	42	50	60	70

* 200 km/h is from measured data and used to calculate the remaining figures.

** Worst case setup with the product in -30° tilt position.

PSU DC power supply

Use Cambium Networks recommended DC PSU for wireless nodes and ensure the power cords and cables are appropriately rated and in accordance with the regulations of the country of use.

PSU AC power supply

Use Cambium recommended AC power supply for wireless nodes and ensure the power cords and cables are appropriately rated and in accordance with the regulations of the country of use.

PSU location

Find a location for the PSU that meets the following requirements:

DC PoE power injector

- DC power injectors can be mounted on a flat surface.
- PSU is installed in a dry location where no condensation, flooding or rising damp is possible.
- The PSU is located in an environment where it is not likely to exceed its operational temperature rating, allowing for natural convection cooling and placed not close to any fire source.
- PSU can be connected to the ODU drop cable and network terminating equipment.
- PSU can be connected to a compatible power supply.

Outdoor AC/DC PSU

Find a location for the PSU that meets the following requirements:

- The PSU is installed in a dry location where no flooding or rising damp is possible.
- The PSU is located in an environment where it is not likely to exceed its operational temperature rating, allowing for natural convection cooling and placed not close to any fire source.
- The PSU is not stacked and placed adjacent to the heat-generating equipment.
- The PSU should be connected to protective earth.
- The PSU should be connected to ODU drop cable using cable joiner and appropriately rated cables should be used.

Lightning Surge Protection Units (LPUs)

All drop cables connected to the ODU (for example, PSU and AUX drop cables) require their own Lightning Protection Unit (LPU) or Gigabit Surge Suppressor installed close to the ODU and close to the enclosure/building entry point. The copper SFP drop cable also requires surge protection. Optical cables do not require lightning surge protection or ground cables. Guidance on the positioning of required lightning surge protection is given in the [Lightning Surge Protection Units Location](#).

Lightning Surge Protection Units location

Lightning Surge Protection Units or Gigabit Surge Suppressors must be installed at two points on drop cables:

- There is room to mount the LPU, either on the ODU mounting bracket or on the mounting pole below the ODU.
- The drop cable length between the ODU and top LPU must not exceed 600 mm.
- There is access to a metal grounding point to allow the ODU and top LPU to be bonded in the following ways: top LPU to ODU; ODU to a grounding system.

Find a location for the bottom LPU that meets the following requirements:

- The bottom LPU can be connected to the drop cable from the ODU.
- The bottom LPU is within 600 mm (24 in) of the point at which the drop cable enters the building, enclosure or equipment room within a larger building.
- The bottom LPU can be bonded to the grounding system.

Deployment Considerations

This section provides brief information specific to the deployment of 60 GHz cnWave series of products. This section covers the following topics:

- [Key deployment guidelines](#)
- [Sector and alignment](#)
- [Minimum CN spacing](#)
- [Near-far radio](#)
- [Early weak interference](#)
- [Avoiding the tight angle deployment](#)
- [Avoiding the straight line interference](#)
- [When two V5000 devices are co-located at a site](#)
- [Polarity](#)
- [Link Adaptation and Transmit Power Control \(LATPC\)](#)

Key deployment guidelines

The following are some of the key guidelines that you must consider for the deployment of 60 GHz cnWave series of products:

- **Mounting accuracy:** Cambium Networks has different Stock Keeping Units (SKU) models. These three SKUs have different requirements in terms of alignment coverage, as shown in [Table 34](#).

Table 34: Details of alignment coverage - 60 GHz cnWave products


60 GHz cnWave product version	Azimuth (in degrees)	Elevation (in degrees)
V5000	+/-70 per sector	+/-20
V3000	+/-2	+/-1
V2000	+/-10	+/-4.5
V1000	+/-40	+/-20

- **Minimum deployment distance:** A typical minimum deployment distance is based on the maximum receive signal strength of -40 dBm, as listed:
 - 25 meters for V1000 and V5000
 - 150 meters for V3000
 - 60 meters for V2000
 - In deployments where the range is less than 25 meters (for V1000 and V5000), 150 meters (for V3000), or 60 meters (for V2000) a short range or long range specific check box is provided in the user interface (UI) to allow this.
- **Deployment frequency range:** 60 GHz cnWave products support the use of CH1 to CH4 (channels). Deployment in these channels depends on the allowed channels in that region. Each channel is 2.16 GHz wide, and the raster frequencies supported are - 58.32 GHz, 60.48 GHz, 62.64 GHz, and 64.8 GHz.

Sector and alignment

Each sector is an independent radio or a baseband unit. Each sector has 2 RF tiles connected to provide extended azimuth scan range, as shown in [Figure 46](#).


Figure 46: *The sector diagram*



Maximize the pole or box height during the deployment. This action minimizes the ground bounce and avoids channel fluctuations, especially for links with long distances. The suggested height is >5m.

You must consider the orientation of a DN node in P2MP. For example, orient the V5000 to the boresight of the RF tile to the longest link (where possible). The optimal beam angle to achieve the maximum antenna gain is at boresight of the active tile face (as shown in Figure 47 using the Red dotted line).

Figure 47: Optimal beam angle



Consider the following deployment specific points:

- Avoid sticking any metallic labels on the radome.
- The 60 GHz cnWave antenna tiles are located on the four marked faces.
- The GPS antenna is located at the middle of the top face of the radome that is pointed to the sky.

Minimum CN spacing


Consider the following key points for the minimum CN spacing at a sector intersection:

- Up to 15 CNs can be installed in a single sector. Time Division Multiple Access scheme (TDMA) dynamically schedules the time slots for each wireless link on an access point, such that they do not interfere with one another.
- When CNs are installed in multiple sectors, more than one CN can be talking at a given time as the sectors have independent schedulers.

If both CNs installed in different sectors are located within the highlighted 20 degree range, then configure the two sectors to be on different channels to avoid interference.

Figure 48 shows the minimum CN spacing at a sector intersection.

Figure 48: Minimum CN spacing



Near-far radio


The near-far ratio for links from different sectors on the same pole is based on the following factors:

- **Scenario:**
 - One wireless link on DN sector 1 at long range, link 2
 - One wireless link on DN sector 2 at short range, link 1
 - Narrow angular separation between link1 and link2 (less than 20 degrees)
 - Configured for the same channel
- **Problem:**
 - The TG system utilizes active Transmit Power control.
 - The transmit power for link 1 is automatically set to a low level.
 - The transmit power for link 2 is automatically set to a high level.
 - Due to narrow angular separation, the sidelobe of link 2 is interfered with link 1. As a result, the Signal-to-Noise Ratio (SNR) of link1 could degrade and this might cause the transmit power of link 1 to be boosted to a much higher level. This problem ends up in a cycle resulting in both links eventually transmitting at full power by causing network interference.
- **Solution:**

- Perform a traffic test on one link at a time and then simultaneously.
- If the simultaneous traffic results show degradation along with transmit power that is railed high to maximum, consider the following tasks:
 - Setting the two sectors on different channels or
 - Capping the maximum power of the short range link.

Figure 49 illustrates the problem and the solution for near-far radio.

Figure 49: Near-far radio - Problem and solution



Early weak interference

Early weak interference occurs when the receiver correlates to a preamble from an unwanted node, with the same Golay code (as desired). If the receiver starts decoding the preamble from the wrong node, it may be too late to recover the preamble from the correct node for that cycle.

Terragraph has four Golay codes to mitigate this interference. Users can select the Golay codes {1,2,3}.



Note

Golay 0 is used for another purpose. Therefore, avoid selecting the Golay 0 (The use of Golay 0 has been deprecated in System Release 1.2).

Consider the following points specific to the Golay codes in 802.11ad/ay:


- The 802.11ad/ay frame consists of PHY preamble, which consists of short training frame (STF) and Channel Estimation Symbol (CES).
- The STF and CES are made up of complimentary Golay codes. Due to the repetition of the Golay codes, the signal can be correlated with even low SNRs.
- This PHY preamble is used for frequency synchronization, timing synchronization, and channel estimation.

Avoiding the tight angle deployment

Avoid tight P2MP angles in the deployment for the following reasons:

- In Figure 50 (shown as an example), a downlink data transmission from the DN1 to CN1 can interfere with the uplink data reception at CN2 to DN2. This interference can be both down to the main lobe in very tight angles or sidelobes with up to 20 degrees delta between two CNs.
- The level of interference depends on the link distances between DN1->CN1 versus DN->DN2 versus CN2->DN2.
- In most cases, the main interference is due to the early weak interference.
- To mitigate this early-weak interference, different Golay code assignment could be used. This issue only relates to the two links transmitting at the same time in the same physical direction.


Figure 50: Tight angle deployment



Avoiding the straight line interference


It is recommended to avoid the straight line interference. When the desired link and interference link angles are the same, there is no assistance from the beamforming interference suppression.

Figure 51: Representation of straight line interference



It is recommended to assign appropriate Golay codes to mitigate early-weak interference. In Figure 52, the red and orange arrows show the possible weak interference. The code assignment must be in the form of 2-2-1-1 or 1-1-2-2 but not in the 1-2-1-2 form.

Figure 52: Assigning Golay codes




When two V5000 devices are co-located at a site

When two V5000 devices are co-located at the same site, it is recommended that one must use different channels on the two V5000 devices to start with.

Evaluate the issues specific to near-far radio and Tight Angle deployment. Then, you have to configure two different channels for the two sectors or consider option 2, as shown in [Figure 53](#).

Figure 53: When two V5000 devices are co-located at the same site



Where local regulations allow the usage of four channels, it is advisable to choose CHA and CHB such that there are two channels apart. Example: Consider that CHA = 1 or 2 CHB = 3 or 4. The reason is that it may be easier to upgrade to Channel bonding (CB2) in the future and still experience channel isolation.



Note

It is important to use the same polarity at the same site. For more details about the polarity, refer to the [Polarity](#) section.


Polarity

60 GHz CnWave uses TDD, which is synchronized across the network. As one sector is in the transmit phase, the neighbor sector is in the receive phase. The transmit and receive phases of the sectors are determined by the EVEN or ODD polarity.

All sectors with a common polarity in a network could be transmitting or receiving at the same time.

Hybrid polarity is when a node uses an EVEN polarity on one sector and an ODD on another sector. Although hybrid polarity is possible through configuration, you must avoid this unless the installer is sure that the two links on the sectors are orthogonal. Figure 54 shows an example of hybrid polarity.

Figure 54: Hybrid polarity



Link Adaptation and Transmit Power Control (LATPC)

The modulation and code scheme (MCS) rate and transmit power are both adaptive values. These values are set at the transmitter, independently, for every link and for both directions. The adaptive MCS selection procedure is referred to as link adaptation (LA) and the transmit power procedure as transmit power control (TPC).

The following are the two versions of this adaptation, data traffic, and standby:

- When there is data traffic, adaptation is driven by block error rate (BLER) reported every SF (1.6ms). A lower BLER causes the algorithm to adapt the transmit power or MCS.
- When there is no data traffic, the algorithm is driven by the short training frame (STF) SNR as reported by each management packet. The SNR is compared to an MCS table. If the SNR is greater or lesser than table value, the transmit power or the MCS rate is adapted accordingly.

There is a maximum TX power per MCS mode (which is defined in the configuration section).

During the adaptation process, the transmit power is either increased or decreased first to:

- increase the power till the maximum per MCS power is reached or
- reduce the power if there is enough headroom.

If the maximum power for the MCS mode has been reached, the MCS mode is reduced.

Radio spectrum planning

General wireless specifications

The following [60 GHz cnWave wireless specifications \(all variants\)](#) table lists the wireless specifications that apply to all 60 GHz cnWave frequency bands:

Table 35: 60 GHz cnWave wireless specifications (all variants)

Item	Specification
Channel selection	Open/R protocol or manual selection
Manual power control	Supports ATPC automatic transmit power control and maximum EIRP can be set lower than the default power limit.
Integrated antenna type	<ul style="list-style-type: none">• V1000 - 22.5 dBi gain• V2000 - 34.5 dBi gain• V3000 - 44.5 dBi gain and 40.5 dBi gain• V5000 -22.5 dBi gain
Duplex schemes	Symmetric 50:50 fixed and asymmetric fixed
Range	100 m to 2 KMs, depends on the following factors: <ul style="list-style-type: none">• Frequency selected• Rain condition• Availability• EIRP limitation
Over-the-air encryption	AES 128-bit
Weather sensitivity	Highly sensitive due to rain range conditions. For more information in range, refer Rain and attenuation table.

Regulatory limits

Many countries impose EIRP limits (allowed EIRP) on products operating in the bands used by the 60 GHz cnWave. These are commonly identified by limitations on conducted transmit power or by antenna gain. For example:

Table 36: ERC recommendation (70-03)

Frequency Band		Power / Magnetic Field
c2	57 - 71 GHz	40 dBm E.I.R.P., 23 dBm/MHz E.I.R.P. density and maximum transmit power of 27 dBm at the antenna port/ports.
c3	57-71 GHz	55 dBm E.I.R.P., 38 dBm/MHz E.I.R.P. density and transmit antenna gain ≥ 30 dBi.

CFR47 Part 15.255(c)(ii):

For fixed point-to-point transmitters located outdoors, the average power of any emission shall not exceed 82 dBm and shall be reduced by 2 dB for every dB that the antenna gain is less than 51 dBi. The peak power of any emission shall not exceed 85 dBm and shall be reduced by 2 dB for every dB that the antenna gain is less than 51 dBi.

Link planning

This section describes factors that must be considered when planning links, such as range, obstacles path loss, and throughput. It is highly recommended to use Cambium LINKPlanner software when planning the links.

LINKPlanner

The Cambium LINKPlanner software and user guide may be downloaded from the support website (see <https://support.cambiumnetworks.com/files/linkplanner/>).

LINKPlanner imports path profiles and predicts data rates and reliability over the path. It allows the system designer to try different antenna heights and RF power settings. It outputs an installation report that defines the parameters to be used for configuration, alignment, and operation. Use the installation report to compare predicted and actual link performance.

Exclusion zones for the 59 - 63.9 GHz band

In the three geographical areas outlined in [59 - 63.9 GHz Transmission Exclusion Zones](#) (UK IR 2078 Section 4 and IR 2030 IR2030/7/4 (2018/316/UK)), no transmissions are permitted.

Table 37: 59 - 63.9 GHz transmission exclusion zones

Site Name	Site Location	Radius of exclusion zone from the center of site location
Site 1	07° 23' 36.6" W, 57° 21' 3.6" N	6 Km
Site 2	04° 58' 21" W, 51° 37' 16.8" N	6 Km
Site 3	00° 36' 22.8" W, 52° 38' 1.8" N	6 Km

Range and obstacles

Calculate the range of the link and identify any obstacles that may affect radio performance.

Perform a survey to identify all the obstructions (such as trees or buildings) in the path and to assess the risk of interference. This information is necessary to achieve an accurate link feasibility assessment. The 60 GHz cnWave radios are designed to operate in Line-of-Sight (LoS) environments.

The 60 GHz cnWave radios operate at ranges from 15 m (49 ft) to 2000 m (1.2 miles). The operation of the system depends on the frequency channel chosen.

Path loss

Path loss is the amount of attenuation the radio signal undergoes between the two ends of the link. The path loss is the sum of the attenuation of the path if there were no obstacles in the way (Free Space Path Loss), the attenuation caused by obstacles (Excess Path Loss) and a margin to allow for possible fading of the radio signal (Fade Margin). The following calculation needs to be performed to judge whether a particular link can be installed:

$$L_{free_space} + L_{excess} + L_{fade} + L_{seasonal} < L_{capability}$$

Table 38: Input details for the link calculation

Where:	Is:
L_{free_space}	Free Space Path Loss (dB)
L_{excess}	Excess Path Loss (dB)
L_{fade}	Fade Margin Required (dB)
$L_{seasonal}$	Seasonal Fading (dB)
$L_{capability}$	Equipment Capability (dB)

At 60 GHz cnWave, oxygen absorption is a key component of the free space path loss and varies substantially depending on the frequency channel selected. Use LINKPlanner to calculate the oxygen absorption component for the required path and frequency channel.

Planning for data networks

This section describes factors to be considered when planning 60 GHz cnWave data networks.

60 GHz cnWave network can be deployed as point-to-point backhaul-bridge, Point-to-Multipoint coverage network and mesh network that provide network rebound.

By default, cnWave radios operate in IPv6 layer 3 network mode, requiring IPv6-based routing gears. The network can be designed to operate in pure IPv4 network mode, transporting layer 2 traffic (VLAN tagged and untagged) with GRE tunnels built-in by the system.

There is no fundamental difference between configurations of PTP vs. PMP vs. Mesh because the underlying routing mechanism of the cnWave network is always IPv6-based OpenR routing.

In a PTP network, you have one PoP DN and a CN to form a link. In a PMP network, you have one PoP DN and multiple CNs (up to 30 CNs if V5000 is used) to form a PMP cluster. You can have multiple PMP clusters to form a coverage area network.

You can have one PoP node with multiple DNs or CNs. If DNs are connected, the user gets a mesh network. Users can them have multiple PoPs and DNs and if the link with each other and form a complex mesh network.

Point to Point-based single link Ethernet bridge

A Point to Point cnWave link can be configured to work as an Ethernet bridge. The operator needs to configure one end as PoP DN, and the other end as CN.

Enable Layer 2 Bridge. While the radios still run on IPv6, the Layer 2 Bridge configuration allows user Layer 2 data (VLAN tagged and untagged) to be transmitted transparently through the link.

IPv6 address of the PoP and CN can be automatically generated and they do not need to be routable through the external network as long as the E2E is collocated with the PoP DN or within the same VLAN of the PoP DN. The operator can assign IPv4 addresses to the radios for management purposes.


Figure 55: Point to Point cnWave link



IPv4/L2 based PMP and mesh network planning

You can build a complete IPv4-based network without the need for any IPv6 routers. The following figure shows the network:

Figure 56: Example of IPv4-based network



60 GHz cnWave IPv6 IP address is generated automatically by the system.

1. Single PoP, E2E resides in the PoP DN.

When configuring the PoP E2E, the operator can configure the IPv6 address to be generated automatically.

2. Multiple PoPs, E2E controls all PoPs.

cnMaestro generates the IPv6 configuration for all the PoPs. The user can download the config file from cnMaestro. This configuration file contains all the PoPs IPv6 configuration. The IPv6 configuration is associated with the MAC address of each PoP DN. When loading the config file to the PoP DN during initial configuration, the PoP DN chooses the IPv6 address by matching its MAC address, so there is no IPv6 address conflict.

The PoP DNs automatically use the E2E controller as the default gateway of IPv6 traffic. Since IPv6 traffic is used only for management purposes, there may be no concern about overloading the E2E. (IPv6 payload traffic should be disabled in the radio configuration).

The E2E chooses any one of the active PoP DN as the IPv6 default gateway. If the E2E detects that the default gateway PoP DN is down, it selects another PoP DN as a default gateway.

Control traffic from E2E to all cnWave radios will be sent to the default gateway PoP, which relies on OpenR to route through correlated POP to the target radio.

Select the **Relay Port Interface** for the PoP DN's Ethernet interface for inter-PoPs OpenR routing to work.



Note


IPv6 routers in the network are not required. Ensure that the PoP DNs and the E2E be in the same VLAN.

Configure the IPv4 address of the radios manually. The CPE IPv4 address can be manually configured or use a DHCP server sitting in the core network. Depending on the complexity of the network, IPv4 based router may be required to route the IPv4 traffic from the CPEs.

Support for dual networking (IPv4 and IPv6)

The operator can design the network so that both IPv4 and IPv6 user data are supported. In this case, an IPv6 router is required at the core network. Ensure that if Layer 2 Bridge is enabled, by default all the user traffic including IPv6 is encapsulated in the GRE tunnel. The IPv6 user traffic is passed through the cnWave network in the GRE tunnel so that it does not be routed by the cnWave radios, but rather by an external IPv6 router.

Figure 57: Example of an IPv4 and IPv6 supported network




The operator can choose certain of the radio Ethernet port to be SLAAC based port or (CPE interface), user traffic from this port is only IPv6 based and does not be encapsulated into the GRE Layer 2 bridge when transmitted over the wireless network. Although this reduces overhead, it is not recommended since this adds complexity to the network design (the operator may need to add a BGP router to the network).

IPv6 Mode network planning

If the operator chooses to have the network completely run on IPv6 mode, then GRE Layer 2 Bridge is not required and a BGP router is usually required to route traffic between the wireless network and the external network.

Figure 58: Example of IPv6 mode network




IPv6 Network design consideration

There are two sets of networks when designing the IPv6 network. one set is for the OpenR subnets (e.g. prefix of 56 bits and partition into multiple 64 bits subnet).

Each PoP node, besides being part of the OpenR mesh network, has a subnet assigned to it and has an IPv6 address assigned to it as PoP interface IPv6 address.

If you let the system automatically generate an IP address configuration, the IP address is always in the format of `FD00:xxxxxxx`, which is a standard routable private IPv6 address.

Figure 59: Example of an IPv6 network design



Reserved IPv6 address space

If the operator allows the system to automatically generate IPv6 addresses for the network, the following private IPv6 address spaces are reserved:

- FD00:CEED::0/32 for seed prefix of the mesh network
- FD00:BA5E::0/32 for all the PoP nodes and the E2E Controller

E2E and cnMaestro deployment consideration

While the E2E and cnMaestro are two separate entities, they can be hosted on separate computers or the same computer. While the E2E communicates with the cnMaestro using IPv4, the E2E communicates with the cnWave radios using IPv6.

Ethernet bridging

Layer 2 (L2) bridging

L2 Bridge employs Ethernet over GRE (EoGRE) to carry the customer traffic across the Terragraph network. When L2 Bridge is enabled, all CNs and DNs automatically create an EoGRE tunnel with their PoP node and the PoP node creates a tunnel back to each of those CNs/DNs. The tunnel is capable of carrying both IPv4 and IPv6 customer traffic between CN and PoP. The IPv6 over the tunnel can be optionally disabled from the UI.

An ingress Ethernet frame from a customer's network must not exceed 1942 bytes. On top of this, the device (CN, DN, or PoP) adds 58 bytes of tunnel headers. Hence, the maximum size of an encapsulated Ethernet frame is 2000 bytes.

If the device nodes are configured to insert VLANs (native Q or native QinQ), additional room must be left free for that in the ingress Ethernet frame.

Broadcast/Multicast control

The downstream broadcast can be controlled by explicitly disabling it from UI. Disabling IPv6 over the tunnel also reduces the downstream multicast traffic.

Limitations

- In bridge mode, the V5000 PoP node can forward 1.8 Gbps of TCP traffic and 2.0 Gbps of UDP traffic in the down-link direction.

Layer 2 Bridge support in multi-PoP deployments

This feature applies to Layer 2 bridging and Deterministic Prefix Allocation (DPA) are configured to be used in the network.

In the Terragraph network, CNs and DNs are allocated prefixes from a seed prefix. There are various ways for allocating prefixes. In DPA, the controller assigns prefix zones to PoPs based on the network topology to allow PoP nodes to take advantage of summarizing the route and helps in load balancing ingress traffic.


CNs and DNs get prefixes from the respective PoP zone, which are allocated by the controller. CNs and DNs see multiple PoP nodes in the mesh, they select PoP to form GRE tunnel, by matching their lo IPv6 address with PoPs lo IPv6 address. The longest prefix match is selected as the best PoP for L2 GRE Tunnel establishment. The multi-PoP setup gives the advantage that user data traffic can take alternate routes if the best route is unavailable for some reason. Open/R makes this selection to route the traffic. If PoP is unavailable, CNs and DNs switch to the next best PoP. They however keep track of their primary PoP availability and switch to it once it becomes online.

External Layer 2 Concentrator support

The external device can be used as an L2 GRE Concentrator. Concentrator could be a Linux server or any router or switch supporting IPv6 L2 GRE tunnels. Example: Juniper MX 100.

Select the **Static** tunnel concentrator option and provide an IPv6 address to configure the external concentrator IPv6 address.

Figure 60: Layer 2 Tunnel Concentrator



☒ **Layer 2 Bridge**

☒ **Enable Layer 2 bridge**
By selecting this checkbox, you will be enabling Layer 2 network bridging (via automatically created tunnels) across all nodes connected to a PoP. This will facilitate bridging of IPv4 traffic across the wireless networks.

Tunnel Concentrator
☐ Best PoP ☒ Static

Tunnel Concentrator IPv6 Address

Concentrator can be a PoP device or an external switch/router

Multi-PoP deployments

You must take care of the following aspects in the multi-PoP deployments:

- [Layer 2 domain](#)
- [Open/R on the PoP interface port](#)
- [MTU of upstream switch ports](#)
- [Prefix allocation](#)

Layer 2 domain


All cnWave PoP nodes must be connected to the same Layer 2 broadcast domain. PoP nodes learn about other PoP nodes using IPv6 multicast packets, which do not cross broadcast domain.

This allows cnWave PoP nodes to forward traffic to other cnWave PoP nodes via a wired connection when the routing path of the other PoP node is closer to the traffic's destination. This concept is called Tromboning, as the traffic enters one PoP node and then leaves to another PoP node.

Open/R on the PoP interface port

PoP interface port must be configured to run the Open/R protocol. To enable this option, select **Multi-PoP/ Relay port Interface**.

Figure 61: Multi-PoP/Relay Port Interface



Multi-PoP / Relay Port Interface
☐ Aux ☐ Main ☒ SFP ☐ Disabled

Wired interfaces on which OpenR is run. Should be used when DNs are connected back to back and on PoPs in a multi PoP network.

MTU of upstream switch ports


PoP ports use a 2000 MTU size. So, all the switch ports must be at least 2000 MTU size. Even if the user traffic is limited to 1500 sized packets, switch ports should allow higher MTU size. The following packets exchanged between the PoPs that can be of higher size:

- Open/R packets,
- L2GRE packets (in Layer 2 mode), and
- Software download packets.

Prefix allocation

It is recommended to select the Deterministic Prefix Allocation option for multi-PoP deployments.

Figure 62: The prefix allocation options



Layer 2 control protocols

60 GHz cnWave identifies layer 2 control protocols (L2CPs) from the Ethernet destination address or Ethertype of bridged frames.

IP Interface

Select the IP version for the IP interface of the ODU management agent. 60 GHz cnWave can operate in IPv4 mode (via L2 tunneling), IPv6 mode. Choose one IPv4 address and/or one IPv6 address for the IP interface of the ODU management agent. The IP address or addresses must be unique and valid for the connected network segment and VLAN.

Find out the correct subnet mask (IPv4) or prefix length (IPv6) and gateway IP address for this network segment and VLAN.

Ensure that the design of the data network permits bidirectional routing of IP datagrams between network management systems and the ODUs. For example, ensure that the gateway IP address identifies a router or another gateway that provides access to the rest of the data network.

Daisy-chaining 60 GHz links

When connecting two or more 60 GHz cnWave links together in a network (daisy-chaining), do not install direct copper CAT5e connections between the PSUs. Each PSU must be connected to the network terminating equipment using the LAN port. To daisy-chain 60 GHz cnWave links, install each ODU-to-ODU links using one of the following solutions:

- A copper CAT5e connection between the Aux ports of two ODUs.
- A copper CAT5e connection between the Aux port of one ODU and the SFP port of the next ODU (using a copper SFP module).
- Optical connections between the ODUs (SFP ports) using optical SFP modules at each ODU.



Note

Wherever CAT5e is applicable, you can use CAT5e or better category cables. Similarly, you can use CAT6 or better category cables wherever CAT6 is applicable.

Installation

Safety



Warning

To prevent loss of life or physical injury, observe the following safety guidelines. In no event shall Cambium Networks be liable for any injury or damage caused during the installation of the Cambium 60 GHz cnWave radio nodes. Ensure that only qualified personnel install 60 GHz cnWave radios.



Attention

Pour éviter toute perte de vie ou blessure physique, respectez les consignes de sécurité suivantes. En aucun cas Cambium Networks ne pourra être tenu responsable des blessures ou dommages causés lors de l'installation des nœuds radio Cambium 60 GHz cnWave. Assurez-vous que seul du personnel qualifié installe les radios cnWave 60 GHz.

Power lines

Exercise extreme care when working near power lines.

Working at heights

Exercise extreme care when working at heights.

PSU

Always use one of the approved power supply options. Failure to use the Cambium supplied PSUs can result in equipment damage and will invalidate the safety certification and may cause a safety hazard.

Grounding and protective earth

The cnWave radios must be properly grounded to protect against lightning. It is the user's responsibility to install the equipment in accordance with national regulations. In the USA, follow the requirements of the National Electrical Code NFPA 70-2005 and 780-2004 *Installation of Lightning Protection Systems*. In Canada, follow Section 54 of the *Canadian Electrical Code*. These codes describe correct installation procedures for grounding the outdoor unit, mast, lead-in wire, and discharge unit, size of grounding conductors, and connection requirements for grounding electrodes. Other regulations may apply in different countries and therefore it is recommended that installation of the outdoor unit be contracted to a professional installer.

AC Supply

Always use an appropriately rated and approved AC supply cord set in accordance with the regulations of the country of use.

Powering down before servicing

Before servicing 60 GHz cnWave equipment, always switch off the power supply and unplug it from the PSU.

Do not disconnect the RJ45 drop cable connectors from the radio while the PSU is connected to the power supply. Always remove the AC or DC input power from the PSU.

Primary disconnect device

The primary disconnect device is the main power supply.

External cables

Safety may be compromised if outdoor rated cables are not used for connections that are exposed to the outdoor environment.

Drop cable tester

The PSU output voltage may be hazardous in some conditions such as wet weather. Do not connect a drop cable tester to the PSU, either directly or via LPUs.

RF Exposure near the antenna

Strong Radio Frequency (RF) fields are present close to the antenna when the transmitter is ON. Always turn off the power to the radio before undertaking maintenance activities in front of the antenna.

Minimum separation distances

Ensure that personnel is not exposed to unsafe levels of RF energy. The units start to radiate RF energy as soon as they are powered up. Never work in front of the antenna when the radio is powered. Install the radios to provide and maintain the minimum separation distances from all people. For minimum separation distances, see [Calculated distances and power compliance margins](#).

Grounding and lightning protection requirements

Ensure that the installation meets the requirements defined in the [Installation](#) section.

Grounding cable installation methods

To provide effective protection against lightning-induced surges, observe these requirements:

- Grounding conductor runs are as short, straight and smooth as possible, with bends and curves kept to a minimum.
- Grounding cables must not be installed with drip loops.
- All bends must have a minimum radius of 200 mm (8 in) and a minimum angle of 90°. A diagonal run is preferable to a bend, even though it does not follow the contour or run parallel to the supporting structure.
- All bends, curves and connections must be routed towards the grounding electrode system, ground rod/ground bar.
- Grounding conductors must be securely fastened.
- Braided grounding conductors must not be used.
- Approved bonding techniques must be used for the connection of dissimilar metals.

Siting radios

Radios are not designed to survive direct lightning strikes. For this reason, they must be installed in Zone B as defined in *Lightning protection zones*. Mounting in Zone A may put equipment, structures, and life at risk.

60 GHz cnWave radios and mounting bracket options

The 60 GHz cnWave series supports eight mounting bracket options. Select the optimum mounting bracket arrangement based on the ODU type and the choice of wall or pole mounting. The wall mount plate for V1000 and V5000 are included with the ODU. Order the remaining brackets separately.

Table 39: ODU mounting bracket part numbers

Bracket	Pole diameter	ODU variants	Bracket part number
V1000 pole mount	25 mm to 70 mm (1 inch to 2.75 inches)	V1000	Included with V1000
V1000 wall mount	Wall mount	V1000	Included with V1000
V1000 adjustable pole mount	25 mm to 70 mm (1 inch to 2.75 inches)	V1000	N000900L022A
V2000 Adjustable pole mount	25 mm to 70 mm (1 inch to 2.75 inches)	V2000	Included with V2000
V3000 precision bracket	25 mm to 70 mm (1 inch to 2.75 inches)	V3000	C000000L125A
V3000 tilt bracket assembly	25 mm to 70 mm (1 inch to 2.75 inches)	V3000, V5000	N000045L002A
V3000 tilt bracket assembly with band clamps	The diameter range depends on the clamps used.	V3000, V5000	N000045L002A + third-party band clamps
V5000 pole mount	25 mm to 70 mm (1 inch to 2.75 inches)	V5000	C000000L137A
V5000 wall mount	Wall mount	V5000	C000000L136A

Installing the cnWave radio nodes

To install the radio, use the following procedure and guidelines:

1. [Typical installation](#)
2. [ODU interface with LPU on the pole](#)
3. [SFP and Aux Ethernet interfaces](#)
4. [Attach ground cables to the radio](#)
5. [Mounting the ODU](#)

Typical installation


V1000

Consider the following key points when installing V1000:

1. Use the recommended grounding and surge suppressor connections.
2. Use the recommended cables for interfacing ODU (refer to the supported power supply and cable length details in the [Power supply units \(PSU\)](#) section).
3. Always install the ODU 0.5 meters below the tip of the pole.

Figure 63 shows a typical installation of V1000 CN on a mast and powered through PoE power injector.

Figure 63: Typical installation - V1000 CN




V2000

Consider the following key points when installing V2000:

1. Use the recommended grounding and LPU connections.
2. Use the recommended cables for interfacing ODU (refer to the supported power supply and cable length details in the [Power supply units \(PSU\)](#) section).
3. Always install the ODU 0.5 meters below the tip of the pole.

Figure 64 shows a typical installation of V2000 CN on a mast and powered through outdoor AC/DC PSU.

Figure 64: Typical installation - V2000 CN




V3000

Consider the following key points when installing V3000:

1. Use the recommended grounding and LPU connections.
2. Use the recommended cables for interfacing ODU (refer to the supported power supply and cable length details in the [Power supply units \(PSU\)](#) section).
3. Always install the ODU 0.5 meters below the tip of the pole.

Figure 65 shows a typical installation of V3000 CN on a mast and powered through outdoor AC/DC PSU.

Figure 65: Typical installation - V3000 CN




V5000

Consider the following key points when installing V5000:

1. Use the recommended grounding and LPU connections.
2. Use the recommended cables for interfacing ODU (refer to the supported power supply and cable length details in the [Power supply units \(PSU\)](#) section).
3. Always install the ODU 0.5 meters below the tip of the pole.

Figure 66 shows a typical installation of cnWave DN on a mast and powered through outdoor AC/DC PSU.

Figure 66: Typical installation - V5000 DN




ODU Interface with LPU on the pole

V1000:

You can install the V1000 CN on a pole. During the installation, use the 56V Gigabit Surge Suppressor for lightning protection. Ensure that the cable glands and grounding connections are made, as shown in [Figure 67](#).


Figure 67: *Installing the V1000 CN on a pole*



V2000:

During the installation of V2000 CN on a pole, use the 56V Gigabit surge suppressor for lightning protection. Ensure that the cable glands and grounding connections are made, as shown in [Figure 68](#).


[Figure 68](#): Installing the V2000 CN on a pole



V3000:

You can install the V3000 CN on a pole using a precision bracket. During the installation, Use a recommended LPU for surge protection. Ensure glands and grounding connections are made, as shown in [Figure 69](#).


Figure 69: *Installing the V3000 CN on a pole*



V5000:

You can install the V5000 DN on a pole using a tilt bracket. Use the recommended LPU for surge protection. Ensure glands and grounding connections are made, as shown in [Figure 70](#).

Figure 70: *Installing the V5000 DN on a pole*



Attach ground cables to the radio

1. Fasten the ground cable to the radio grounding point using the M6 lug.

Figure 71: Radio grounding point



2. Tighten the ODU grounding bolt to a torque of 5 Nm (3.9 lb-ft).

Mounting the ODU

Select the most appropriate bracket mounting arrangement from the options listed in the [Mounting bracket options](#). Refer to individual procedures below for each of the options:


- [V1000 Pole mount](#)
- [V1000 Wall mount](#)
- [V1000 Adjustable pole mount](#)
- [V2000 Adjustable pole mount](#)
- [V3000 Precision bracket](#)
- [V3000 Tilt bracket assembly](#)
- [V3000 Tilt bracket assembly with band clamps](#)
- [V5000 Pole mount bracket](#)
- [V5000 Wall mount bracket](#)

V1000 Pole mount

The V1000 CN can be installed to a pole using the supplied mounting plate and jubilee clip. Follow the instructions given below to mount V1000 to the pole:

1. Insert the hose clamps through the mounting plate and clamp to the pole by applying 3.0 Nm torque.

Figure 72: Inserting the hose clamps



2. Insert the radio into the mounting plate on the pole.

Figure 73: Inserting the radio



V1000 Wall mount

Follow the instructions given below to mount V1000 on the wall:

1. Fix the mounting plate (supplied with the V1000 ODU) securely to a vertical wall, using suitable fixings.




Note

Fixing hardware is not supplied with the V1000.

2. Slide the V1000 ODU onto the mounting plate from above, ensuring that the spring clip in the mounting plate clicks into place on the radio.

Figure 74: Fixing the mounting plate and the spring clip




V1000 Adjustable pole mount

Follow the instructions given below to mount V1000 to the adjustable pole:

1. Insert the hose clamps through the adjustable pole mount bracket and clamp to the pole by applying 3.0 Nm torque.

Figure 75: Fixing hose clamps through adjustable pole mount bracket



2. Insert the radio into the adjustable pole mount bracket on the pole.

Figure 76: Fixing the radio on the pole



The adjustment can be made up to maximum ± 30 degrees and each serration movement is 5 degrees.

V1000 Alignment

The V1000 CN requires minimal effort to align as the internal antenna can beam steer ± 40 degrees in azimuth and ± 20 degrees in elevation from boresight. If the unit is installed with the remote node visible within this range, no further adjustment is required.

V2000 Adjustable pole mount

You can install the V2000 CN on a pole using a jubilee clip (hose clamps). Perform the following steps to mount the V2000 CN on a pole:


1. Insert the two hose clamps through the adjustable mounting bracket and clamp it to the pole by applying 5.0 Nm torque, as shown in [Figure 77](#).

Figure 77: Fixing V2000 to a pole



2. Align the device by viewing through the eye piece and the notch on radome, as shown in Figure 78.

Figure 78: Aligning the V2000 device



3. Use the bracket knob (as shown in Figure 80) to rotate fine adjustable bracket until the alignment is complete in the elevation plane.

The adjustable bracket supports fine adjustment of up to $\pm 20^\circ$ in elevation for an accurate alignment.

Figure 79: Aligning V2000





Figure 80: Using the adjustable bracket knob for alignment



V2000 Antenna alignment


The V2000 CN requires minimal effort to align as the internal antenna can beam steer ± 10 degrees in azimuth and ± 4.5 degrees elevation from boresight. If the unit is installed with the remote node visible within this range, no further adjustment is required.

V3000 Precision bracket

The precision bracket is used to mount the cnWave V3000 CN on a vertical pole, providing fine adjustment up to 18° in azimuth and $\pm 30^\circ$ in elevation for accurate alignment of the V3000. The precision bracket is compatible with pole diameters in the range of 25 mm to 70 mm (1 inch to 2.75 inches). Note that the Jubilee clamp allows for larger diameter poles and the range depends on the clamps used.


These instructions illustrate the procedure for assembling and using the precision bracket. The mounting of the optional alignment telescope also explained.

Figure 81: *V3000 Precision bracket*




1. Insert two long (120 mm) screws through the azimuth arm and the bracket body. The screws are located in the slots in the azimuth arm.

Figure 82: *Two screws in the slots of the azimuth arm*




2. Fit two flanged M8 nuts to the long screws on the back of the bracket. Tighten using a 13 mm spanner.

Figure 83: *Two MB nuts on the back of bracket*




3. Insert the three medium-length (40 mm) M8 screws through the bracket base and the V3000 mount. The screws are located in the slots in the bracket base.

Figure 84: *MB Screws in the slots in the bracket base*




You must ensure that the pivot pin in the elevation adjuster is located in the circular hole in the V3000 mount.

Figure 85: The pivot pin in the circular hole of mount




4. Fit plain washers and M8 Nyloc nuts to the screws on the back of the bracket base. Tighten using a 13 mm spanner.

Figure 86: Plain washers and M8 Nyloc nuts on the back of the bracket




5. Insert the two remaining long (120 mm) M8 screws through the bracket body and the azimuth arm. The screws must be located in the slots in the bracket body.

Figure 87: MB Screws located in the slots in the bracket body




You must ensure that the pivot pin in the azimuth adjuster is located in the circular hole in the bracket body.

Figure 88: The pivot pin in the circular hole of bracket body




6. Fit three sets of spacers, plain washers and M8 Nyloc nuts to the screws on the underside of the bracket base. Tighten using a 13 mm spanner.

Figure 89: Fixing pacers, plain washers and M8 Nyloc nuts




7. Attach the V3000 mount to the radio using the four short M6 bolts. Tighten the four bolts to a torque setting of 5.0 Nm (3.7 lb-ft) using a 13 mm spanner or socket.

Figure 90: *Attaching the V3000 mount*




8. Attach the precision bracket to the pole using the clamp and the remaining flanged nuts. Adjust azimuth approximately and tighten the nuts to 10 Nm (7.4 lbft) using a 13 mm spanner.

Figure 91: *Attaching the precision bracket*



9. Lock the antenna alignment by tightening the five Nyloc nuts (see [step 5](#) and [step 8](#)) to 10 Nm (7.4 lb-ft) using a 13 mm spanner or socket.

Figure 92: Locking the antenna alignment




Note

Visit the [Cambium Learning website](#) to learn more about the precision bracket assembly.

Precision bracket alignment

1. Ensure that the three Nyloc screws for securing the bracket in elevation are loose and the fine elevation adjuster is holding the weight of the unit.

Figure 93: Three Nyloc screws on the unit




2. Ensure the two Nyloc screws securing the bracket in the azimuth are loose.

Figure 94: Two Nyloc screws in the azimuth



3. Before starting the mechanical alignment, move the fine elevation adjuster 2/3 of the way across the screw until the unit is sitting at approximately 0 degrees in elevation.

Figure 95: Moving the elevation adjuster



4. Move the fine azimuth adjuster to approximately the center of the available range and lock it in position.

Figure 96: Moving the azimuth adjuster



5. Loosen the clamp which attaches the bracket to the pole until there is enough freedom to rotate the unit in azimuth.
6. From behind the unit, using the sight to aim towards the remote node, rotate the unit until it is approximately aligned in azimuth. Tighten the clamp.
7. While looking for the far node through the site, rotate the fine elevation adjuster until the alignment is complete in the elevation plane. One turn of the adjustment wheel is equivalent to approximately one degree of elevation. Lock the fine elevation adjuster screws in place.

Figure 97: Locking the fine elevation adjuster



You can use the **alignment tube** for adjustment, as described in [Fixing the alignment tube](#).

8. While looking for the far node through the site, rotate the fine azimuth adjuster until the alignment is complete in the azimuth plane. One turn of the adjustment wheel is equivalent to approximately one degree of azimuth. Lock the fine azimuth adjuster screws in place.
9. Make any remaining adjustments to the elevation and azimuth as required. Once complete, tighten the three Nyloc screws in place to fix the elevation alignment and do the same for the two Nyloc screws for azimuth alignment to 10 Nm (7.4 lbft) using a 13 mm spanner or socket.

Precision bracket alignment - optional telescope

1. Attach the telescope mount to the V3000 radio using the knurled screw.
2. Attach the telescope by looping the two elastic O-rings over the ears of the mount, ensuring that the telescope is located securely in the mount.

Figure 98: *Attaching the telescope*




3. If a telescope with a smaller body is used, shorten the O-rings by twisting.
4. Following the previously described precision bracket alignment method, align the radio starting with the site, and fine-tune using the scope for increased accuracy.

Fixing the alignment tube for V3000

Perform the following steps to fix the alignment tube for V3000:

1. Slide the alignment tube through the alignment slot, as shown in [Figure 99](#).


[Figure 99](#): *Sliding the alignment tube*



2. Tighten the screw to fix the alignment tube in place, as shown in [Figure 100](#).

The tube fits into the circular area.

[Figure 100](#): *Fixing the alignment tube*



3. Align the device by viewing through the eyepiece, as shown in [Figure 101](#).


Figure 101: *Aligning the device*



V3000 Tilt bracket assembly


1. Fix the mounting plate of the tilt bracket to the back of the radio using four of the short bolts, ensuring that the arrow in the plate points towards the top of the radio. Tighten the four bolts to a torque setting of 5.0 Nm (3.7 lb-ft) using a 13 mm spanner or socket.

Figure 102: *Fixing the mounting plate of the tilt bracket*




2. Fit the two long bolts through the bracket body so that the bolt heads engage in the slots as shown. Fit two of the short bolts into the side of the bracket body but do not tighten.

Figure 103: Fixing two long and short bolts




3. Thread two of the nuts to the long bolts and tighten against the bracket body using a 13 mm spanner. Fit the bracket strap and thread the remaining nuts onto the long bolts.

Figure 104: Fixing the bracket strap




4. Fix the assembled bracket body to the pole, adjust the azimuth angle, and tighten the nuts to a torque setting of 10.0 Nm (7.4 lb-ft) using a 13 mm spanner, ensuring that the arrow in the body is pointing upwards.

Figure 105: Fixing the assembled bracket body



5. Fit the mounting plate to the bracket body by positioning the open-ended slots over the short bolts. Insert the remaining short bolts through the longer curved slots into the threaded holes in the bracket body. Adjust the elevation angle and tighten the bolts to a torque setting of 5.0 Nm (3.7 lb-ft) using a 13 mm spanner or socket.

Figure 106: Fixing the mounting plate and adjusting the elevation




V3000 Tilt bracket assembly with band clamps

Follow the below instructions to assemble the tilt bracket with band clamps:

1. Follow step 1 of the [V3000 tilt bracket assembly](#) procedure.
2. Feed the band clamps through the slots in the bracket body. Secure the bracket body to the pole using band clamps (not supplied by Cambium), ensuring that the arrow in the body is pointing upwards. Adjust the azimuth angle and tighten the band clamps to a torque setting of 6.0 Nm (4.5 lb-ft).
3. Fix the mounting plate to the bracket body with four of the short bolts, using a 13 mm spanner or socket. Adjust the elevation angle and tighten the bolts to a torque setting of 5.0 Nm (3.7 lb-ft).


Figure 107: Fixing the mounting plate of bracket body and adjusting the elevation angle



V5000 Pole mount bracket

1. Pass the long screws through the bracket body. The screws are located in the recess in the bracket.
2. Fit two flanged nuts to the long screws on the back of the bracket. Tighten using a 13 mm spanner.
3. Fix the bracket to the back of the radio using the four short M6 bolts, ensuring that the arrow in the plate points towards the top of the radio. Tighten the four bolts to a torque setting of 5.0 Nm (3.7 lb-ft) using a 13 mm spanner or socket.
4. Attach the pole-mount bracket to the pole using the clamp and the remaining flanged nuts. Adjust azimuth and tighten the nuts to 10 Nm (7.4 lbft) using a 13 mm spanner.


Figure 108: Fixing the V5000 pole mount bracket



V5000 Alignment

The V5000 distribution node has two sectors, situated side by side, each covering a 140-degree range in azimuth, giving a combined coverage of 280 degrees. In elevation, the antenna can beam steer in a ± 20 -degree range. The boundary between where Sector 1 ends and Sector 2 begins is the centerline/boresight from the unit.

Figure 109: V5000 alignment - Top view



V5000 Wall mount bracket

1. Install the mounting plate of the wall mount bracket securely on a vertical wall, using suitable fixing hardware.




Note

Fixing hardware is not supplied with the wall mount bracket.

2. Fix the bracket body to the back of the radio using the four short M6 bolts, ensure that the arrow in the plate points towards the top of the radio. Tighten the four bolts to a torque setting of 5.0 Nm (3.7 lb-ft) using a 13 mm spanner or socket.
3. Insert the four short M8 bolts into the sides of the bracket body.
4. Fit the bracket body to the mounting plate by positioning the short bolts into the open-ended slots.
Tighten the bolts to a torque setting of 5.0 Nm (3.7 lb-ft) using a 13 mm spanner or socket.

Figure 110: Fixing the V5000 wall mount bracket




Connect to the PSU port of the radio

Using Power over Ethernet (PoE)

1. Disassemble the gland and thread each part onto the cable (the rubber bung is split). Assemble the spring clip and the rubber bung.

Figure 111: Assembling the spring clip and the rubber bung




2. Fit the parts into the body and lightly screw on the gland nut (do not tighten it).

Figure 112: Fixing the gland nut



3. Connect the RJ45 plug into the main PSU port of the ODU (which can be either V1000, V2000, V3000, or V5000).

Figure 113: Connecting the RJ45 plug




4. Rotate the gland clockwise to tightly fit the gland on the PSU port.



Warning

Ensure that the cable clamp is not attached/ tightened at this stage, this may cause damage to the RJ45 or PCB.

Figure 114: Rotating the gland




5. Tighten the gland (cap or nut), this must be done last. Otherwise, it may damage the RJ45 or PCB.

Disconnecting drop cable from the radio

1. Loosen and remove the cable clamp by rotating anti-clockwise from the PSU port.

Figure 115: Removing the cable clamp




Warning

Loosen the cable clamp completely and then unscrew the gland. Not releasing the cable may cause damage to the RJ45 socket and/or PCB.

2. Remove the gland.

Figure 116: *Removing the gland*



3. Press tab on RJ45 plug to remove the cable from PSU port.
4. Remove the latch of the RJ45 plug to remove the cable from the PSU port.

Figure 117: *Removing the latch of the RJ45 plug*



Using AC/DC PSU

Cable joiner


A cable joiner is used to connect the wires. Insert the wires into the cable joiner by loosening the screws on the joiner.

Figure 118: Cable joining parts




Figure 119 is an example of connecting wires using the cable joining parts.

Figure 119: Connecting wires




Connecting the mini adapter

Figure 120: Mini adapter connections



Fitting the long cable gland

Figure 121: The long cable gland



Connecting the mini adapter to ODU

1. Plug the input side of the AC/DC PSU into the AC power line and tighten the gland. Tighten the cable clamp cap.

Figure 122: Connecting the input side of AC/DC PSU



2. Connect the output side of DC PSU to ODU through cable joiner and DC mini adapter.

Figure 123: Connecting the output side of AC/DC PSU



Installing the PSU

Install one of the following types of PSU:

- [Installing the 60W DC power injector](#)
- [Installing the AC/DC PSU](#)
- [Installing 15W or 30W power injector](#)

Table 40: Details of PoE injector to be used for cnWave 60 GHz products

Product	Without AUX POE Enabled	With AUX POE enabled
V1000	15W	Not applicable
V2000	30W	60W
V3000	60W	60W
V5000	60W	100W



Warning

Always use an appropriately rated and approved AC supply cord-set in accordance with the regulations of the country of use.



Attention

As the 60W DC power injector and V1000 power injector are not waterproof, locate it away from sources of moisture, either in the equipment building or in a ventilated moisture-proof enclosure. Do not locate the PSU in a position where it may exceed its temperature rating.



Attention


Do not plug any device other than a 60 GHz cnWave ODU into the ODU port of the PSU. Other devices may be damaged due to the non-standard techniques employed to inject DC power into the Ethernet connection between the PSU and the ODU.

Do not plug any device other than a Cambium 60 GHz cnWave PSU into the PSU port of the ODU. Plugging any other device into the PSU port of the ODU may damage the ODU and device.

Installing the 60W DC power injector

1. Connect the input side of the DC power injector to the AC power line.

Figure 124: 60W DC power injector and powering diagram




2. Connect 10 Gbe LAN port of the power injector to network equipment.
3. Connect 60 W 56V 10 GbE PoE port of the power injector to ODU drop cable (ODU can be either V3000 or V5000).



Note

For V2000, use the 60 W device, especially when POE Out is required, and the 5 GbE PoE (000000L142A).

Figure 125: Connecting the power injector to ODU drop cable



Installing the AC/DC PSU

1. Connect the input side of the AC/DC PSU to the AC power line.
2. Connect the output side of DC PSU to ODU through cable joiner and DC mini adapter. Refer to the [Cable joiner](#) section for connecting, installing cable joiner and mini adapter.

Figure 126: AC/DC PSU (N000000L179B)



Figure 127: Cable joiner



Figure 128: DC to RJ45 plug, mini adapter



Figure 129: AC/DC powering diagram




Figure 130: AC/DC PSU



For detailed assembly of cable joiner and mini adapter to ODU PSU port, refer to the [Cable joiner](#) section.



Note

Both short and long glands can be used to connect to outdoor PSU.


Installing 15W or 30W power injector

1. Connect the 56V Gigabit Data and power port to ODU (which can be either V1000 or V2000)

Figure 131: V1000 Power injector



Figure 132: V2000 Power injector



Note

30 W (N000000L034B) supports up to 5 GbE.

Figure 133: V1000 or V2000 Powering diagram




Figure 134: Connecting the V1000 Power injector



Figure 135: Connecting the V2000 power injector



2. Connect the Gigabit data port to the network equipment.

Connecting to the SFP+ optical module or SFP+ to the copper module to ODU

When ODU is powered through AC/DC PSU, an optical or copper Cat6A Ethernet interface can be connected to the SFP port of the ODU for the data interface.

Adapt the installation procedures in this section as appropriate for SFP interfaces, noting the following differences from a PSU interface.


Fitting the long cable gland

Optical SFP interface: Disassemble the long cable gland and thread its components over the LC connector at the ODU end as shown below.

Copper CAT6A SFP interface: Disassemble the cable gland and thread its components over the RJ45 connector at the ODU end.

1. Disassemble the long cable gland used for the optical SFP interface.

Figure 136: *Disassembling the long cable gland - optical SFP interface*



You must also disassemble the long cable gland used for the copper SFP interface.

Figure 137: *Disassembling the long cable gland - copper SFP interface*



2. Thread each part onto the cable (the rubber bung is split).

Figure 138: *Threading the part onto the cable*



3. Fit the parts into the body and lightly screw on the gland nut (do not tighten it).

Figure 139: *Fixing parts to the gland*

Optical



Copper



Inserting the SFP module

To insert the SFP module into the ODU, complete the following steps:

1. Remove the blanking plug from the SFP port of the ODU.

Figure 140: Removing the blanking plug from the SFP port



Optical SFP+ module



Copper SFP module



2. Insert the SFP module into the SFP receptacle with the label on the bottom.

Figure 141: Inserting the SFP module

Optical



Copper



3. Push the module home until it clicks into place.

Figure 142: Pushing the module home

Optical



Copper



4. Rotate the latch to the locked position.

Figure 143: Rotating the latch

Optical



Copper



Connecting the cable




Attention

The Fiber optic cable assembly is very delicate. To avoid damage, handle it with extreme care. Ensure that the fiber optic cable does not twist during assembly, especially when fitting and tightening the weatherproofing gland. Do not insert the power over Ethernet drop cable from the PSU into the copper SFP module, as this will damage the module.

1. Remove the LC connector dust caps from the ODU end (optical cable only).

Figure 144: Removing the LC connector dust caps




2. Plug the connector into the SFP module, ensuring that it snaps home.

Figure 145: Plugging the connector into the SFP module

Optical



Copper



Fitting the gland

1. Fit the gland body to the SFP port and tighten it to a torque of 5.5 Nm (4.3 lb-ft).

[Figure 146](#): *Fitting the gland body*



2. Fit the gland nut and tighten until the rubber seal closes on the cable. Do not over-tighten the gland nut, as there is a risk of damage to its internal components.

Figure 147: *Fitting the gland nut*



3. Fit the gland nut to the rubber seal on the gland body and tighten it to a torque of 5.5 Nm (4.3 lb-ft).

Figure 148: *Fitting the gland nut to the rubber seal*



Removing the cable and SFP module

Do not attempt to remove the module without disconnecting the cable, otherwise, the locking mechanism in the ODU will be damaged.

1. Remove the cable connector by pressing its release tab before pulling it out.

Figure 149: *Removing the cable connector*

Optical



Copper



2. Pull the bale clasp (latch) to the unlocked position. Extract the module by using a screwdriver.

Figure 150: *Pulling the bale clasp (latch)*

Optical



Copper




Configuring 60 GHz cnWave™

This topic explains how to configure 60 GHz cnWave products.

Nodes deployment

The configuration of cnWave nodes is handled automatically by the E2E service. However, the first PoP node must be configured manually since connectivity to the E2E controller has not yet been established. After establishing communication with the E2E controller, the nodes report a hash of their local configuration file, and the controller automatically pushes configuration changes to the nodes upon seeing any mismatches. The centralized configuration management architecture is implemented in which the E2E controller serves as the single point for configurations in the network.

Figure 151: Nodes deployment



Connecting to the unit

This section describes how to connect the unit to a management PC and power it up.


Configuring the management PC

Use this procedure to configure the local management PC to communicate with the 60 GHz cnWave devices.

Procedure:


1. Select **Properties** for the Ethernet port. In Windows 7 this is found in **Control Panel > Network and Internet > Network Connections > Local Area Connection**.
2. Select **Internet Protocol Version 4 (TCP/IPv4)**.

Figure 152: The Ethernet Properties dialog box



3. Click **Properties**.
4. Enter an IP address that is valid for the 169.254.X.X/16 network, avoiding 169.254.1.1 (for example: 169.254.1.3).

Figure 153: *The Internet Protocol Version 4 (TCP/IPv4) dialog box*



5. Enter the subnet mask value 255.255.0.0, and leave the default gateway field blank.

Connecting to the PC and powering up

Use this procedure to connect a management PC and power up the 60 GHz cnWave devices.

Procedure:

1. Check that the ODU is connected to the power supply (AC/DC according to the configuration).
2. Connect the PC Ethernet port to the LAN port of the PSU or AUX port (according to device configuration).
3. Open a web browser and type **169.254.1.1**.
4. When prompted, enter **admin/admin** to login to the UI and complete the configuration.

Using the web interface


This section describes how to log into the 60 GHz cnWave web interface and use its menus.

Logging into the web interface


Use this procedure to log into the web interface as a system administrator.

Procedure:


1. Start the web browser from the management PC.
2. Type the IP address of the unit into the address bar. The factory default IP address is **169.254.1.1** and press **Enter**.




3. Type the username and password as **admin** and **admin**. Click **Sign In**.



The **Dashboard** page appears.



Users can select the refresh time interval. Click **admin** at the top-right and select the **Refresh Interval** from the drop-down.



The Dashboard contains the following options at the top:

- Uptime
- Links
- Channels
- Wireless Throughput

Uptime

Displays the total running time of the device.

Links

Displays the total number of active links which are connected to the 60 GHz cnWave™ device.

Channels

Displays the total number of channels (Sector 1, Sector 2, etc.,) which are connected to the 60 GHz cnWave™ device.

Wireless Throughput

Displays the transmitting and receiving throughput values.

Dashboard elements

The **Dashboard** page consists of the following elements:

- Device Information
- GPS
- Sectors
- Ethernet

Figure 154: Dashboard - Device Information

Device Information	
Type	DN
Name	-
E2E Connection Status	Not Onboarded
MAC Address	00:04:56:88:31:21
Serial Number	V5WH004ZNX7V
Model	V5000
Software Version	1.0-dev12
Firmware Version	10.11.0.70
Wireless Security	None
Layer 2 Bridge	Disabled
System Time	Nov 5, 2020, 12:12:57 PM

Table 41: Elements in the Device Information section

Element	Description
Type	Displays type of the device. The device types are: <ul style="list-style-type: none">• DN• PoP DN• CN
Name	Displays the name of the device.
E2E Connection Status	Displays the connection status of the E2E controller.
MAC address	Displays the MAC address of the 60 GHz cnWave device.
Serial Number	Displays the serial number of the 60 GHz cnWave device
Model	Displays the model of the 60 GHz cnWave device. The models are:

Element	Description
	<ul style="list-style-type: none"> • V1000 • V2000 • V3000 • V5000
Software version	Displays the software version used in 60 GHz cnWave device.
Firmware version	Displays the Firmware version used in 60 GHz cnWave device.
Wireless security	Displays the security type. The types are: <ul style="list-style-type: none"> • Disabled • PSK • 802.1X
Layer 2 Bridge	Displays bridge status.
System Time	Displays current time.

GPS

The **GPS** section displays the positioning information of the site.

Figure 155: Dashboard - GPS



GPS	
Fix Type	3D
Satellites tracked	15
Latitude	12° 56' 2.163" N 
Longitude	77° 41' 39.912" E 
Height	927 m

Table 42: Elements in the GPS section

Element	Description
Fix Type	Fix Type
Satellites tracked	Number of registered satellites
Latitude	Displays latitude of the site
Longitude	Displays longitude of the site
Height	Displays height of the device

Sectors

The **Sectors** section displays the number of nodes added to the device and its information.

Figure 156: Dashboard - Sectors

Sectors		
	Sector 1	Sector 2
Channel	3	4
Sync Mode	RF	RF
MAC Address	12:04:56:88:31:21	22:04:56:88:31:21
Active Links	0	0
RX Throughput	0 kbps	0 kbps
TX Throughput	0 kbps	0 kbps

Table 43: Elements in the Sectors section

Element	Description
Channel	Displays the channel information used by the sector
Sync mode	Displays the sync mode of the sectors
MAC address	Displays the MAC address of the sectors
Active links	Displays the number of active links in connected sectors
RX Throughput	Displays RX Throughput of the individual sectors
TX Throughput	Displays TX Throughput of the individual sectors

Ethernet

The **Ethernet** section displays information about Aux, Main, and SFP ports.

Figure 157: Dashboard - Ethernet

Ethernet			
	Aux	Main	SFP
Status	1000 Mbps	10000 Mbps	10000 Mbps
RX Packets	637166	445648283	1250718835
TX Packets	777923	3983518625	109768893
RX Throughput	14.46 kbps	348.40 Mbps	974.40 Mbps
TX Throughput	28.78 kbps	4.84 Gbps	3.65 Mbps

Table 44: Elements in the Ethernet section

Element	Description
Status	Displays the speed of Ethernet ports
RX Packets	Number of packets received
TX Packets	Number of packets transmitted
RX Throughput	Displays the RX Throughput of the Ethernet
TX Throughput	Displays the TX Throughput of the Ethernet

Enabling internal E2E Controller

E2E Controller handles important management functions such as link bring-up, software upgrades and configuration management.




Note

The internal E2E controller is not required if you want to run the E2E controller On-Premise platform. For details, refer to the *60 GHz E2E Controller User Guide*.

Currently, the internal E2E controller is restricted to 31 nodes.

To enable E2E Controller to configure and establish the connection, perform the following steps:


1. Click the **E2E Controller** option on the left pane of the Dashboard.




2. Click **Enable E2E**.

The **Enable Onboard E2E** dialog box appears.

Figure 158: Dashboard



Right-click on the site pin to see additional information about the site, as shown below:



Topology

After enabling the E2E Controller, add Sites, Nodes and Links to establish the connection.

To add sites, nodes and links, perform the following steps:

1. In the main dashboard page, click **Topology** on the left navigation pane.

The **Topology** page appears. By default, the **Sites** tab is selected, as shown below:

Figure 159: The Sites page

Name	Latitude	Longitude	Devices On Site	Altitude	Accuracy
PoP-site-V5K-884938	12.933952	77.694438	PoP-V5K-884938	936.5	7.22

2. To add a DN site, click **Add New**.

The **Add Site** dialog box appears, as shown below:

Figure 160: The Add Site dialog box

Add Site

Name
DN-Site@3f69

Latitude
12.933975905668138

Longitude
77.69462584806521

Altitude
1


Accuracy
2

Save **Cancel**

3. Enter the Name, Latitude, Longitude, Altitude, Accuracy information, and click **Save**.

The new DN site information gets added to the topology, as shown below:

Figure 161: The updated Sites page with new site details



The screenshot shows the 'Topology' page with the 'Sites' tab selected. The table displays the following data:


Name	Latitude	Longitude	Devices On Site	Altitude	Accuracy	
PoP-site-V5K-884938	12.933952	77.694438	PoP-V5K-884938	936.5	7.22	
DN-Site@3169	12.933975905668138	77.69462584806521	DN-V5K-3169	1	2	

Navigation controls at the bottom of the table show page 1 of 10.

- To add a DN node, click on the **Nodes** tab in the **Topology** page.

The **Nodes** page appears, as shown below:

Figure 162: The Nodes page




The screenshot shows the 'Topology' page with the 'Nodes' tab selected. The table displays the following data:

Name	MAC Address	IPv6	Type	Status	Model	Site	PoP Node	Software Version	
PoP-V5K-884938	00:04:56:88:49:38	fd00:cecd:8849:3800::1	DN	Online Initiator	V5000	PoP-site-V5K-884938	Yes	1.2	

Navigation controls at the bottom of the table show page 1 of 10.

- Click **Add New** and provide values in the **Add Node** dialog box, as shown below:

Figure 163: The Add Node dialog box

The image shows a software dialog box titled "Add Node" with a close button (X) in the top right corner. The dialog contains several input fields and radio buttons. The "Name" field is filled with "DN-V5K-3f69". The "Site" field is a dropdown menu showing "DN-Site@3f69". Under "PoP Node?", the "No" radio button is selected. Under "Node Type", the "DN" radio button is selected. The "MAC Address (ESN)" field is filled with "00:04:56:88:3f:69". The "Platform" field is a dropdown menu showing "V5000". The "Azimuth" field is filled with "0". The "Elevation" field is filled with "0". At the bottom right, there are two buttons: "Save" (highlighted in blue) and "Cancel".

Add Node [X]

Name
DN-V5K-3f69

Site
DN-Site@3f69

PoP Node?
☐ Yes ☒ No

Node Type
☐ CN ☒ DN

MAC Address (ESN)
00:04:56:88:3f:69

Platform
V5000


Azimuth
0

Elevation
0

Save **Cancel**

6. Click **Save**.
The DN node gets added to the topology.
7. To add a link, click on the **Links** tab in the **Topology** page.
The **Links** page appears.
8. Click **Add New** and provide values in the **Add Link** dialog box, as shown below:

Figure 164: The Add Link dialog box




The 'Add Link' dialog box contains the following fields and options:

- Name:** link-PoP-V5K-884938-DN-V5K-3f69
- Link Type:** ☒ Wireless ☐ Wired
- A-Node:** PoP-V5K-884938
- Node-1 Wireless MAC:** Sector 1 - 12:04:56:88:49:38
- Z-Node:** DN-V5K-3f69
- Node-2 Wireless MAC:** Sector 2 - 22:04:56:88:3f:69
- Buttons:** Save, Cancel

9. Click **Save**.

The new link gets added to the topology, as shown below:

Figure 165: The updated Links page with the new link details



The screenshot shows the 'Links' tab in the 'Topology' section. The table below represents the data shown in the interface:


Name	A-Node	A-Node Sector	Z-Node	Z-Node Sector	Active	Uptime	Type	Ignition Attempts (1d)	Distance (m)	Ignition Status
link-DN-V5K-3f6...	DN-V5K-3f69	Sector 2	PoP-V5K-884938	Sector 1	Yes	0d 20h 14m	Wireless	6	936	Enabled

Support for renaming nodes

A node can be renamed in the topology. To rename the node, perform the following steps:

1. From the dashboard page, navigate to **Topology > Nodes**.
2. Select the required node and click in the corresponding row. Then, select **Edit Node**.
The **Edit Node** dialog box appears with information for the selected node.
3. Rename the node, as shown below:

Figure 166: The Edit Node dialog box



4. Click **Save**.

Configuration

The **configuration** page contains the following two configuration options:

- [Network configuration](#)
- [Node configuration](#)

Network configuration

Network configuration is used to configure the network. Users can modify the network settings. It has **Basic**, **Management**, **Security** and **Advanced** options for the configuration. Settings under **Network** apply to all the nodes in the network. Some apply to the **E2E Controller**. Enter the required information and click **Submit** to configure the network.

The **Network** page contains the following tabs:

- [Basic](#)
- [Management](#)
- [Radio](#)
- [Security](#)
- [Advanced](#)

Figure 167: The Network page with multiple tabs

The screenshot shows the 'Configuration' page for a 60 GHz cnWave V5000 device. The 'Network' tab is selected, and the 'Basic' sub-tab is active. The page features a sidebar with navigation icons and a main content area with several configuration sections. The 'Layer 2 Bridge' section has an 'Enable' checkbox. The 'Prefix Allocation' section includes radio buttons for 'Centralized' and 'Deterministic', a 'Seed Prefix' field, a 'Generate' button, and a 'Prefix Length' field. The 'Country' section has a 'Country' dropdown menu. The 'Channels' section has an 'Enabled Channels' field. The 'DNS' section has a 'DNS Servers' field. At the top right, there are buttons for 'Submit' and 'Cancel'. The top bar includes the device name, a 'Disable E2E Controller' button, a 'Reboot' button, and a user profile icon labeled 'admin'.

60 GHz cnWave™ V5000

Disable E2E Controller Reboot admin

Configuration

Network Nodes

Basic Management Radio Security Advanced

Submit Cancel

☐ Layer 2 Bridge

☐ Enable

By selecting this checkbox, you will be enabling Layer 2 network bridging (via automatically created tunnels) across all nodes connected to a PoP. This will facilitate bridging of IPv4 traffic across the wireless networks.

☐ Prefix Allocation

☒ Centralized ☐ Deterministic

Seed Prefix

fd00::ced:8849:3800::/56

Generate

IPv6 'seed prefix' in CIDR format from which subnet prefixes are allocated to all DNs and CNs (e.g. fdce:b00c:cafe:ba00::/56)

Prefix Length

64

Length of per-node allocated prefixes

☐ Country

Country

Other

☐ Channels

Enabled Channels

2

This configuration is used by the controller for auto config override. Channels set manually ignore this configuration.

☐ DNS

DNS Servers

DNS server list, comma separated. IPv4 is only supported when Layer 2 bridge is enabled.

Basic

By default, cnWave is an IPv6-only network. By selecting this checkbox, Layer 2 network bridging is enabled (via automatically created tunnels) across all nodes connected to a PoP. This facilitates the bridging of IPv4 traffic across wireless networks.

Figure 168: The Layer 2 Bridge section in the Basic page

This screenshot is similar to Figure 167 but highlights the 'Layer 2 Bridge' section with a yellow box. In this section, the 'Enable' checkbox is now checked. The 'Tunnel Concentrator' section below it has radio buttons for 'Best PoP' and 'Static'. The 'Prefix Allocation' section remains the same. The 'Country' section is partially visible at the bottom. The top bar and sidebar are consistent with the previous figure.

60 GHz cnWave™ V5000

Disable E2E Controller Reboot admin

Configuration

Network Nodes

Basic Management Radio Security Advanced

Submit Cancel

☐ Layer 2 Bridge

☒ Enable

By selecting this checkbox, you will be enabling Layer 2 network bridging (via automatically created tunnels) across all nodes connected to a PoP. This will facilitate bridging of IPv4 traffic across the wireless networks.

Tunnel Concentrator

☒ Best PoP ☐ Static

☐ Prefix Allocation

☒ Centralized ☐ Deterministic

Seed Prefix

2016:4321:4321:4300::/56

Generate

IPv6 'seed prefix' in CIDR format from which subnet prefixes are allocated to all DNs and CNs (e.g. fdce:b00c:cafe:ba00::/56)

Prefix Length

64

Length of per-node allocated prefixes

☐ Country

Country

The **Tunnel Concentrator** does encapsulation and de-encapsulation of GRE packets. If **Best PoP** is selected, then the node selects the best PoP as a Concentrator. If **Static** is selected, then the user can configure the external Concentrator that can be Linux machine/router/PoP.

To configure the parameters on the Basic page, perform the following steps:

1. Click **Generate** under **Prefix Allocation** to generate a unique local seed prefix automatically.

cnWave networks are given an IPv6 **seed prefix** (e.g. face:b00c:cafe:ba00::/56) from which subnet prefixes are allocated to all DNs and CNs. There are two methods for allocating node prefixes with Open/R.



Note

PoP interface IPv6 address and seed prefix should not be in the same /64 prefix range to avoid the address conflict.

- **Centralized (default)** - Centralized prefix allocation is handled by the E2E controller. The controller performs all prefix allocations, which prevents collisions and enables more sophisticated allocation algorithms. This is recommended for single PoP networks
- **Deterministic** - Deterministic prefix allocation is also handled by the E2E controller. The controller assigns prefixes to nodes based on the network topology to allow PoP nodes to take advantage of route summarization and help load balance ingress traffic. This is recommended for multi-PoP networks.

Figure 169: The Prefix Allocation section

The screenshot shows the 'Configuration' page with the 'Network' tab selected. Under the 'Prefix Allocation' section, the 'Centralized' radio button is selected. The 'Seed Prefix' field contains '2016:4321:4321:4300::/56'. A yellow box highlights the 'Generate' button. Below it, the 'Prefix Length' is set to '64'. The 'Country' dropdown is set to 'Other'. The 'Channels' section shows 'Enabled Channels' set to '2'. A note at the bottom states: 'This configuration is used by the controller for auto config override. Channels set manually ignore this configuration.'

- **Seed Prefix**

The prefix of the entire cnWave network is given in CIDR notation.

2. Select **Prefix Length**, **Country**, **Channels**, **DNS Servers**, and **Time zone** from the drop-down list.

Prefix Length

Specifies the bit-length of prefixes allocated to each node.

Country

Country for regulatory settings like the EIRP limit, allowed channels, and other elements.

Channels

Indicates the channel number required for forming a link through an onboard E2E Controller or an external E2E Controller (if deployed).

By default, Channel 2 is supported. This parameter also supports a comma-separated list of channel numbers (for example: 2,3, 4,5), which you can give to a controller for auto configuration. Manual settings (which are made using the **Node > Radio** page) do not depend on this channel setting. This channel setting is useful, especially for PTP and small meshes that use a single channel for the entire network. In such a case, set the required channel number in this field and do not override the value that you set on the **Node > Radio** page. Modifying this **Channels** parameter is sufficient for the channel change.

DNS Servers

DNS server list is used for :

- Resolution of NTP Server host name (can be IPv4 when Layer 2 bridge is enabled)
- Given to IPv6 CPE as part of router advertisement

Time Zone

Time zone for all the nodes. System time in the dashboard, time field in the Events section, Log files use this timezone.

NTP Servers


This is NTP Server FQDN or IP Address. All nodes use this NTP Server to set the time. Node time is important when 802.1X radius authentication is used as it requires certificate validation. The time is reflected in the dashboard, time field in the Events section, and Log files .

CPE Prefix Zoning

You can configure the **Summarized CPE Prefix** parameter using the **Basic** page.

The **Summarized CPE Prefix** feature restricts a PoP to advertise the IPv6 CPE prefixes of its zone alone, thereby allowing an upstream BGP router to select an optimal PoP for downstream traffic. [Figure 170](#) is an example of multi-PoP Layer 3 IPv6 topology, which is used to explain the feature in detail.

Figure 170: Multi-PoP Layer 3 IPv6 topology



In Figure 170 (which is an example), consider the following points:

- Seed Prefix is 2001::/56.
- Deterministic Prefix Allocation (DPA) is enabled and has three zones.
- An operator wants CPE Address to be in different ranges than Seed Prefix. Therefore, the user traffic can be distinguished from the traffic generated by the cnWave nodes.
- Customized CPE prefix is used with the range 3001:0:0:00XY::/64, where X contains values from 1 to 3.
- IPv6 addresses of CPEs that fall in the range of 3001:0:0:00XY::/64 prefix.

Prior to the introduction of this feature, all PoP BGP Peers advertised all the customized prefixes.

In this example (as shown in Figure 170), PoP1 BGP advertises 3001:0:0:11::/64, 3001:0:0:20::/64, and 3001:0:0:32::/64 prefixes. Similarly, PoP2 and PoP3 advertise all the three prefixes. The upstream BGP router is not able to route the packets to the best PoP. With this feature, PoP advertises the prefix of its zone alone. In the example:

- PoP1 BGP is advertising 3001:0:0:11::/64.
- PoP2 BGP is advertising 3001:0:0:20::/64.
- PoP3 is advertising 3001:0:0:32::/64.

A summarized prefix (shorter prefix) comprising of all the customized prefixes must be configured. When a PoP is down, traffic flows through another PoP. In this example, the summarized prefix is 3001::/58 (six bits from 11 to 30).

The same concept is applicable when the DHCPv6 relay is used. In that scenario, CPEs obtain IPv6 address or delegated prefix directly from the DHCPv6 server.

Configuring Summarized CPE Prefix

To configure the **Summarized CPE Prefix** feature, perform the following steps:

1. Navigate to **Network > Basic** from the home page.

The **Basic** page appears. The **Summarized CPE Prefix** text box is available in the CPE Prefix Zoning section, as shown in [Figure 171](#).

Figure 171: *The Summarized CPE Prefix text box*

The screenshot shows the 'Configuration' page with the 'Network' tab selected. Under the 'Basic' sub-tab, there is a text box for 'NTP Server hostnames or IP addresses' containing '10.110.186.32'. Below this are sections for 'Configuration Management' (with 'E2E Managed Config' checked), 'Wireless Scans' (with 'Scheduled Beam Adjustment' set to 'Disabled' and 'Scan Interval' set to '14400'), 'IPv6 Layer3 CPE Address' (with 'SLAAC' selected), and 'CPE Prefix Zoning'. The 'CPE Prefix Zoning' section contains a text box for 'Summarized CPE Prefix' with the value '3001::/58' and an information icon. A note below the text box states: 'Prefix summarizing network wide customized CPE Prefixes/Prefixes allocated by DHCPv6 Relay (that fall outside Seed Prefix range)'.

2. Type an appropriate value in the **Summarized CPE Prefix** text box.



Note

Using a customized CPE prefix and not configuring the summarized CPE prefix can result in routing loops.

Management

On the **Configuration > Network** page, click **Management** and select SNMP, SNMPv2 Settings, SNMPv3 Settings, GUI Username and password.

Figure 172: The Management page

The screenshot shows the 'Configuration' page with the 'Management' tab selected. The interface includes a sidebar with various icons and a main content area with several sections: 'SNMP', 'SNMPv2C Settings', 'SNMPv3C Settings', and 'GUI Users'. Each section contains input fields and checkboxes for configuration.

Configuration

Network Nodes

Basic Management Radio Security Advanced

☐ SNMP

☒ Enable SNMP

System Contact

No Contact

System Location

No Location

☐ SNMPv2C Settings

SNMP Community string

Public

SNMP community with read-only access to all OIDs

IPv4 Source Address

Allowed IPv4 source address subnet (Example: 10.10.10.0/24)

IPv6 Source Address

Allowed IPv6 source address prefix (Example: fdce:b00ccafe:ba00::/64)

☐ SNMPv3C Settings

SNMPv3 User

User1

Security Level

☐ None ☐ Authentication Only ☐ Authentication & Privacy

Authentication type

☐ MD5 ☐ SHA ☐ SHA-512 ☐ SHA-384 ☐ SHA-256 ☐ SHA-224

Authorization Key

☐ GUI Users

Admin User Password

Installer User Password

Monitor User Password

- **Enable SNMP** - Statistics can be read from the nodes using SNMP. This setting enables SNMP.
- **System Contact** - Sets the contact name as the System.sysContact.0 MIB-II variable.
- **System Location** - Sets the location name as the System.sysLocation.0 MIB-II variable.
- **SNMPv2c Settings:**
 - SNMP Community string - Supports read-only access to all OIDs.
 - IPv4 Source address - Specified, SNMP queries are allowed from the hosts belonging to this IPv4 address subnet.
 - IPv6 Source Address - Specified, SNMP queries are allowed from the hosts belonging to this IPv6 address prefix.
- **SNMPv3c Settings:**

- **SNMPv3 User** - Name of the SNMPv3c user responsible for managing the system and networks.
- **Security Level** - Following security levels are supported for network communication:
 - None - Implies that there is communication without authentication and privacy.
 - Authentication Only - Implies that there is communication with authentication only (without privacy).
 - Authentication & Privacy - Implies that there is communication with authentication and privacy.
- **Authentication Type** - Type of protocol used for the security of network communication. Example: MD5 and Secure Hash Algorithm) (SHA) are used for authentication.
- **Authentication Key** - A password for the authentication user.
- **For UI Users:**
 - Admin User Password - A password that you can set for GUI management.
 - Installer User Password - A password that you can set for the required installers.
 - Monitor User Password - A read-only password that you set for monitoring purposes.

Radio

The **Radio** page allows you to perform the following configurations:

- [Wireless Scan scheduling for beam adjustment](#)
- [CN Channel scanning options](#)
- [Fast Acquisition](#)
- [Asymmetric TDD](#)

Wireless Scan scheduling for beam adjustment

The **Scheduled Beam Adjustment** parameter, when enabled, allows you to make small adjustments to the selected fixed beam for optimal RF alignment in azimuth and elevation. You can select this schedule option using the **Scan Schedule Type** parameter (Day/Time or Interval schedule type).

To configure the **Scheduled Beam Adjustment** parameter, navigate to the **Wireless Scans** section on the **Configuration > Network > Radio** page (as shown in [Figure 173](#)).

A normal scan without the **Scheduled Beam Adjustment** setting does the following operations:

- Beam selection occurs only on wireless link acquisition.
- Disassociating and re-associating the link or otherwise causing the link to drop and re-acquire is needed to perform a new beam selection.
- Any degradation in wireless conditions does not trigger a new beam selection unless the link is dropped and reacquired.

The advantages of the **Scheduled Beam Adjustment scan** are:

- If the link is to acquire during heavy rain, then the optimal beam at that time may be suboptimal when the weather changes.

- If snow accumulation is present on the unit during acquisition, the optimally selected beam may be different when the snow has melted.
- Network-wide ignition in a dense deployment can cause interference when multiple nodes are acquiring. This interference can cause sub-optimal beam selection.
- Any physical change to alignment that is not severe enough to cause a link drop and subsequent beam scan can be corrected for.

The cost of Scheduled Beam Adjustment is:


- This feature causes a 50% throughput reduction for about 20 minutes, depending on the size of the network.
- Simple deployments (especially PTP links) without significant external factors such as snow may not benefit from regular beam adjustment.

To configure the wireless scan scheduling options using the device UI, perform the following steps:

1. From the home page of the device UI, navigate to **Configuration > Network > Radio**.

The **Radio** page appears with the **Wireless Scans** section, as shown in [Figure 173](#).


Figure 173: *The Wireless Scans section*



[Table 45](#) lists the parameters in the **Wireless Scans** section of the **Radio** page.

Table 45: Parameters in the Wireless Scans section

Parameter	Description
Scheduled Beam Adjustment	Allows you to enable or disable the scheduled beam adjustment feature. This parameter, when enabled, allows you to make small adjustments to the selected fixed beam for optimal RF alignment in azimuth and elevation. You can select this schedule option using the Scan Schedule Type parameter.
Scan Schedule Type	Allows you to select the scan scheduling option for beam adjustment. This parameter supports the following scan scheduling options: <ul style="list-style-type: none"> • Day/Time: This schedule option allows you to select any day (or all days) of the week and time of the day.

Parameter	Description
	<p>When you select the Day/Time option, the following parameters are applicable:</p> <ul style="list-style-type: none"> • Schedule Day(s): Select the check boxes to choose the day(s). • Schedule Time: Use the  icon to set the time of the day. <p>Apart from the interval scans, you are allowed to select any day (or all days) of the week and time of the day. This setting enables you to schedule the scan during maintenance activities.</p> <ul style="list-style-type: none"> • Interval: This scan schedule option allows you to set an interval (in seconds) for wireless scans. The default value is 3600 seconds.

2. Set the parameters based on your requirements, as shown in [Figure 173](#).
3. Click **Submit** to save the changes.

CN Channel scanning options

When a CN loses its wireless connection, it initially scans the previously configured channel. This process speeds up the link acquisition in cases where the corresponding DN has not changed its channel. However, if the DN has switched channels, the CN scans all available channels, after a timeout period, to re-establish the connection.



Note

The advantages of CN channel rescan are:

- Moving the connected DN to a different channel is automatically detected by the CN when the configured timeout period expires.
- There is more flexibility in the topology as CNs can easily be reassigned to a different DN on a different channel without CN specific channel overrides.

The main reason to disable the CN channel rescan is to have the fastest possible network recovery following an event (for example, a software upgrade or network wide power cut). In networks, which have been fully deployed and where the configuration is not being changed, there may not be a requirement for channel rescan.

Using the device UI or the cnMaestro UI, you can configure the CN channel scanning options. These configurable options enhance the adaptability and responsiveness of your cnWave network, allowing it to better accommodate varying network conditions and configurations.

Using the device UI, perform the following steps:

1. From the home page of the device UI, navigate to **Configuration > Network > Radio**.

The **Radio** page appears with the **CN Channel Re-scan** section, as shown in [Figure 174](#).

Figure 174: The CN Channel Re-scan section - Device UI

60 GHz cnWave™ V5000

Configuration

Network Nodes

Basic Management Radio Security Advanced

Submit Cancel

☒ Wireless Scans

Scheduled Beam Adjustment

☒ Enabled ☐ Disabled

Scan Schedule Type

☐ Day/Time ☒ Interval

3600

Interval between wireless scans in seconds.

☒ CN Channel Re-scan

☒ Enable ☐ Disable

CN Channel Re-scan Timeout

120

A CN without a wireless link established beyond this timeout will automatically initiate channel scanning.

Table 46 lists the parameters in the **CN Channel Re-scan** section.

Table 46: CN Channel Re-scan specific parameters

Parameter	Description
Enable	<p>By default, the Enable option is selected (enabled), as shown in Figure 174. This option allows you to disable the full channel rescan feature.</p> <p>When this option is selected, the CN scans only the configured channel while attempting to re-establish a lost connection. This option can be beneficial in stable environments where DNs are unlikely to switch channels frequently, thereby accelerating the reconnection process.</p>
CN Channel Re-scan Timeout	<p>When the rescan feature (Enable CN Channel Re-scan) is not disabled, you can set a custom timeout value (in seconds) for the CN before it initiates a full channel scan. This capability allows you to adjust the balance between quicker reconnection times (by scanning the configured channel) and broader network coverage (by scanning all channels after the timeout).</p> <p>By default, the value of this timeout option is set to 120 seconds. This option allows the value ranging from 120 to 3600 seconds</p>

- Set the CN channel re-scan functionality using **Enable** or **Disable** check boxes, as described in [Table 46](#).
By default, this parameter is enabled.
- Set the required value (in seconds) in the **CN Channel Re-Scan Timeout** text box.
- Click **Submit** to save the changes.

Fast Acquisition

During normal link acquisition, both ends of the wireless link scan multiple fixed beams to digitally steer the radio signal in the optimal direction and form a link. Aside from the Scheduled Beam Adjustment feature, the link then remains on these chosen beams and continues to point in this direction until the link is dropped and re-acquired, triggering a new beam scan.

Assuming both units stay in the same location, orientation, and the wireless conditions do not change, the same beams should be selected (in theory) every time the link is established. By saving this beam on the first successful link acquisition, the link up time can be greatly reduced by only scanning that single beam, instead of all available beams.

Reliable operation of **Fast Acquisition** requires a given responding node to know from precisely which direction to listen for an ignition attempt. A responding DN sector can potentially be ignited, from either of two igniting DNs, in different directions. Therefore, Fast Acquisition does not occur when a DN is igniting another DN and a full beam scan triggers instead.

A full beam scan, across all available fixed beams, at both ends of the link, and on all four supported channels, takes between 2 and 9 seconds to complete. A successful acquisition on a single beam on a single channel completes within 160ms approximately. A successful acquisition has the following advantages:

- Reducing the link acquisition time will reduce the overall time taken for full network recovery, following outages caused by software upgrade, configuration changes, and power cuts.
- During the beam scan, the maximum throughput capability of the scanning DN sector is halved. By reducing this time, the impact on other links sharing the same sector on the igniting DN is reduced.
- The interference profile across the network is vastly reduced, as the link is brought up only on the single optimal beam as opposed to transmitting on all available beams across the full scan range.

This section covers the following details of the feature:

- [Operation modes](#)
- [Use cases](#)
- [Setting the Fast Acquisition mode](#)

Operation modes:

The **Fast Acquisition** feature supports the following three operational modes:

- Disable (default mode)
- Compatibility Mode
- Static Mode

For detailed information about each mode, refer to [Table 47](#).

Use cases:

Consider the following use cases before configuring the **Fast Acquisition** feature:

- **What to do if a link is establishing with poor signal and requires a beam change?**
 - It is difficult to detect this scenario. Check the Beam Angle statistics for the link. This scenario may occur when the unit is moved, an obstruction has moved into or away from the radio path, or interference has been introduced or removed from the receiver.
 - To trigger a network wide rescan of all beams, reconfigure the Fast Acquisition setting to **Disabled** and back to Compatibility or Static after all wireless links have re-established.
 - To trigger a full beam scan on the next association for a single link, navigate to the **Topology > Links** UI page and select the link. Then, click **Clear Fast Acquisition Beams** and re-associate the link.
- **What to do if a link is failing to establish with either of the Fast Acquisition modes enabled?**

- All units delete their fast acquisition beams if they are offline for more than 50 minutes as part of the PoP reachability reboot.
 - In **compatibility mode**, there should be no additional risk of failing link acquisition when compared to **Disabled** mode. Therefore, the cause is unlikely to be related to this feature.
 - In **static mode**, if the saved acquisition beam is no longer valid, wireless link up may take a long time to succeed. This is the main disadvantage of this mode. Therefore, this mode must be enabled only for networks that are stable with all units fixed in location and without ongoing topology changes. If the fast acquisition beam is invalid for any reason, then use the **Clear Fast Acquisition Beams** control (available on the **Topology > Links** UI page) to trigger a full beam scan on the next association.
- **What interactions should be considered when using Fast Acquisition?**
 - DN channel rescan is not supported with the Fast Acquisition feature. Therefore, do not configure the DN channel rescan parameter.
 - When switching the role of a DN to CN, CN to DN, or relocating an existing node to another part of the network, the best practice is to factory default the node before the change. This action can be taken centrally from cnMaestro.
 - Backup CN links must not be used in combination with this feature.
 - Nodes straight from the factory, running pre-1.3.1 software, are not able to respond to a fast acquisition association. Therefore, when using the Static mode, there is a delay in achieving a successful linkup. The solution to this is to use either Disabled or Compatibility mode, or upgrade the node software to the latest before introducing into the network.



Note

cnMaestro 4.1.0 and later versions support the UI controls for configuring the **Fast Acquisition** feature.

The **Enable post acquisition beam refinement** feature is related to the Fast Acquisition feature. This feature (also previously known as Auto PBF) is present and enabled (by default) from Release 1.0.

The **Enable post acquisition beam refinement** UI control allows you to disable, if required. This feature fine tunes the beam selection, immediately, after a successful link acquisition for optimal performance. This can increase the link budget by up to 2dB. This feature is available on the **Configuration > Network > Radio** page of the device UI and the cnMaestro UI. The following minor drawbacks of this feature might lead you to disable it (using the UI):

- The beam refinement scan lasts for 1.5 seconds. During this period, the transmitting DN sector operates at half capacity. You may not notice this behaviour.
- The beam refinement can cause interference during the scan to nearby links. The solution is to implement a channel plan (which takes this into account) but the option is there to disable.

Setting the Fast Acquisition mode

You can set the **Fast Acquisition** mode using either the [device UI](#) or [cnMaestro UI](#).



Note

cnMaestro 4.1.0 and later versions support the UI controls for configuring the **Fast Acquisition** feature.

Device UI:

Using the device UI, perform the following steps:

1. From the home page of the device UI, navigate to **Configuration > Network > Radio**.

The **Radio** page appears.

2. Go to the **Fast Acquisition** section on the **Radio** page.

By default, the **Fast Acquisition** feature is disabled as shown in Figure 175.

Figure 175: Fast Acquisition settings- Device UI




Table 47 describes the operation modes supported by the Fast Acquisition feature.

Table 47: Operational modes

Mode	Description
Disable (default mode)	<p>In this mode, a traditional full beam scan is performed on every link up attempt.</p> <p>The only difference between the current and previous software is that this mode now saves the selected beam on the successful link acquisition for later use when Fast Acquisition is enabled.</p>
Compatibility Mode	<p>On every link up attempt, this mode checks to see if there is a saved beam available for the intended link and ignites on that single beam (if available). If this Fast Acquisition attempt fails, the association attempt immediately runs the full beam scan.</p> <p>This mode supports CNs configured for CN channel rescan because the full beam scan runs on all four channels.</p> <p>Note: The compatibility mode is recommended for most deployments as it offers the fast single beam acquisition where available and successful, whilst still offering the standard mode of acquisition for fallback.</p>
Static Mode	<p>In this mode, the initiator checks to see if there is a saved beam available for the intended link and ignites on that single beam (if available). If this ignition fails, the association also fails.</p>

Mode	Description
	<p>The static mode does not support the configuration of CN channel rescan. This gives the highest chance of success to fast acquisition without performing a full beam scan.</p> <p>In static mode, the fallback mechanism occasionally performs a full beam scan to prevent stranded nodes that cannot respond on the fast acquisition beam. However, this case occurs infrequently, due to which there is some delay before the successful link acquisition.</p>

3. Select the required operation mode.
4. Click **Submit** to apply the changes.

cnMaestro UI:

Using the **Monitor and Manage > Networks > Configuration > Radio** page of cnMaestro UI, you can select the required operation mode of the Fast Acquisition feature.




Note

cnMaestro 4.1.0 and later versions support the UI controls for configuring the **Fast Acquisition** feature.

Figure 176 displays the **Fast Acquisition** section located on the **Radio** page of cnMaestro UI.

Figure 176: *Fast Acquisition settings - cnMaestro UI*



For detailed information about each mode, refer to [Table 47](#).

Asymmetric TDD

The asymmetric TDD feature allows you to configure an asymmetric duty cycle instead of the default 50% downlink/50% uplink. The supported duty cycle ratios, denoted by downlink/uplink timeslot allocation, are:

- 75/25
- 70/30
- 60/40
- 50/50 (default ratio value)

- 40/60
- 30/70

Single wireless hop limitations (Standalone PTP and PMP only):

The meshing technology is designed around a 50/50 duty cycle to allow efficient synchronised communication in multi hop networks. Using asymmetrical duty cycles across a multiple wireless hop network can be counterproductive and therefore, you must avoid this configuration.

Duty cycle ratio selection:

- For downlink biased traffic, for example - Internet video streaming, choose a high downlink ratio such as 75/25.
- For uplink biased traffic, for example - video camera backhaul, sensor backhaul, or data backup, choose a high uplink ratio such as 30/70.

Configuring the asymmetric TDD split ratio


You can configure an asymmetric TDD ratio using either the [device UI](#) or [cnMaestro UI](#).

Device UI:

Using the device UI, perform the following steps:

1. Log in to the device UI and navigate to **Configuration > Network > Radio**.
The **Radio** page appears.
2. Go to the **Asymmetric TDD** section on the **Radio** page, as shown in [Figure 177](#).

Figure 177: The Asymmetric TDD section - Device UI



3. From the **Duty Cycle** drop-down list, select the required duty cycle ratio.

By default, the 50% Downlink / 50% Uplink ratio is selected.

When you modify the value of the **Duty Cycle** parameter, the **Confirm** message box prompts you to confirm the modification. You must click **Continue** to save the changes.

4. Click **Submit** to apply the changes.


cnMaestro UI:

Using the cnMaestro UI, perform the following steps:

1. Log in to the cnMaestro UI and select the **Monitor and Manage** icon on the left navigation pane.
The **Dashboard** page appears.
2. Select a network name under the **Networks** group and navigate to the **Configuration > Radio** page.

The **Radio** page appears, as shown in [Figure 178](#).

Figure 178: *Asymmetric TDD - cnMaestro UI*



3. In the **Asymmetric TDD** section, select the required TDD ratio from the **Duty Cycle** drop-down list.
By default, 50% Downlink / 50% Uplink is selected. When you modify the value of the **Duty Cycle** parameter, the **Confirm** message box prompts you to confirm the modification. You must click **Continue** to save the changes.
4. Click **Save** to apply the changes.

Security

The **Security** page allows you to set the following configurations:

- [Wireless security](#)
- [Security banner](#)

Wireless security

On the **Configuration > Network > Security** page, the **Wireless Security** section contains the following options:

- **Disabled** - There is no wireless security.
- **PSK** - WPA2 pre-shared key can be configured. A default key is used if this configuration is not present. AES-128 encryption is used for data encryption.

- **802.1X** - Nodes are authenticated using Radius server and EAP-TLS. Encryption is based on the negotiated scheme in EAP TLS. When **802.1X** is selected, the following parameters are applicable:
 - **RADIUS Server IP** - IPv4/IPv6 address of the Radius authentication server.
 - **RADIUS Server port** - Port number of the Radius authentication server.
 - **RADIUS server shared secret** - The shared secret of a Radius server.

Figure 179: The Wireless Security section

Configuration

Network Nodes

Basic Management Radio **Security** Advanced

Submit Cancel

Wireless Security

☐ Disabled ☐ PSK ☒ 802.1x

Enable wireless security and set the method

Radius server IP

IP address of auth (i.e. radius) server

Radius server port

Auth server port

Radius server shared secret

Security banner

You can enable or disable a security banner using the **Configuration > Network > Security** page.

When you enable a security banner, the login page of a device UI displays the security notice. You can view and accept (optional based on the configuration) the terms and conditions of a company before logging into the device UI.

For 60 GHz cnWave devices, the configuration of a security banner involves the following process:

1. Enable or disable the security banner option using the **Configuration > Network > Security** page of the device UI (as shown in Figure 180).

Figure 180: Configuring the security banner

60 GHz cnWave™ v5000

Disable E2E Controller Reboot admin

Configuration

Network Nodes

Basic Management Radio **Security** Advanced

Submit Cancel

Wireless Security

☒ Disabled ☐ PSK ☐ 802.1x

Enable wireless security and set the method

☒ Security Banner

Enable Security Banner during Login

☒ Enabled ☐ Disabled

Security Banner Notice

NOTICE TO USERS Test
This computer system is the property of XYZ Corporation and is for authorized users only. Unauthorized access to this system is strictly prohibited. Any unauthorized access or attempted access may result in prosecution to the fullest extent.

Accept security banner before login


☒ Enabled ☐ Disabled

2. If the **Enable Security Banner during Login** parameter is enabled, provide the security text for intended users in the **Security Banner Notice** text box. This text box supports up to 1000 characters.

3. Determine whether the users must accept the security banner before logging into the device UI using the **Accept security banner before login** parameter.
4. Click **Submit** to save the changes.

When you enable and configure the security banner settings (as shown in [Figure 180](#)), the login page of a device UI displays the security banner as shown in [Figure 181](#). The users must accept the security notice and then log into the device UI, as shown in [Figure 181](#).

Figure 181: Example of a Security Banner on the login page



The screenshot shows the login interface for the 60 GHz cnWave V5000 device. On the left, a 'Security Banner' is displayed with a red border. It contains a 'NOTICE TO USERS' regarding system ownership and data security, followed by an acceptance checkbox which is checked. On the right, the 'Sign In' section features the device name '60 GHz cnWave V5000' above a decorative header with icons of a street lamp, a bicycle, and a building. Below this are input fields for 'Username' and 'Password', and a blue 'Sign In' button.

If you have disabled the **Accept security banner before login** option for users, then the users are not forced to accept the security notice before logging in to the device UI.

Advanced


The **Advanced** page settings are for advanced users only. This page displays the merged configuration of all layers for a particular node.



Caution

The users are not recommended to modify or change settings on the **Advanced** page.

Figure 182: The Advanced page



The **Network > Advanced** page supports the configuration of the following features:

- [DN Channel rescan](#)
- [Gratuitous ARP support](#)
- [Dynamic Walking PBF](#)
- [Auto Channel and Golay Optimizers](#)

DN Channel Rescan

The DN Rescan feature optimizes the deployment and management of temporary network structures in settings such as concerts, recreational vehicle (RV) parks, and others. The feature also enables a seamless reconnection of DNs that have moved within new network environments.

How this feature works?

The DN Rescan feature comes into action when a DN loses a DN-DN link, consequently leading to a Point of Presence (PoP) being unreachable.

In a normal operation, the DN remains on the same channel and does not perform a rescan. This is due to the lost link that might be in the downstream direction where rescan does not apply or the affected sector might be serving other active links. However, the DN Rescan feature changes this behaviour under specific circumstances.

How to configure the feature?

To enable the DN Rescan feature, configure the `envParams.CAMBIUM_ENABLE_DN_CHANNEL_RESCAN` parameter using the **Configuration > Advanced** page of the device UI. By default, the value of this parameter is `false` (disabled). To enable the DN Rescan feature, set the value of this parameter to `true`.

If you set the value of this parameter to `true` and the DN is unable to detect a PoP for a certain duration (which is configurable using the `envParams.CAMBIUM_DN_CHANNEL_RESCAN_TIMEOUT` parameter), the DN resets the channel, Golay, and polarity on all its sectors by proceeding to scan all channels. This scan process facilitates the DN to form new links with an upstream PoP or DN without any manual intervention, achieving a true zero-touch experience.



Note

To set the timeout duration (in minutes) for different environments, configure the `envParams.CAMBIUM_DN_CHANNEL_RESCAN_TIMEOUT` parameter using the **Configuration > Advanced** page of the device UI. The default value of this parameter is 20 minutes, and the minimum allowed value is 10 minutes.

Use cases

The DN Rescan feature supports the movement of DNs in temporary deployments with zero touch (main use case). In addition, the feature supports the modification of the channel on the near end DN first.

The correct method is to change the far end DN channel first and then the near end. However, this feature can serve as a fail-safe in case if the near end DN channel is modified first. Note that both the ends must match, otherwise the controller does not ignite the link.

Frequently asked questions (FAQs)

The following table lists the FAQs specific to the **DN Rescan** feature.

FAQ	Answer
How the feature detects the DN-DN link loss?	The DN Rescan feature does not detect the link loss, directly. It helps in monitoring the visibility of the POP, periodically.
What happens if the DN fails to detect a PoP even after the channel, Golay, and polarity reset and rescan process?	<p>The DN continues to scan until it reaches the timeout period (configured using the <code>CAMBIUM_POP_UNREACHABLE_REBOOT_TIMEOUT_INTERVAL</code> parameter), after which it reboots.</p> <p>Note: The <code>CAMBIUM_POP_UNREACHABLE_REBOOT_TIMEOUT_INTERVAL</code> parameter is available on the Configuration > Advanced page of the device UI.</p>
Are there any impacts or disruptions to other active links in the same sector when the feature initiates a rescan process?	Yes. All the active links within the same sector goes down.
What are the prerequisites or requirements for the feature to work properly?	The DN Rescan feature does not require any specific prerequisites.
Can this feature be enabled or disabled on each DN or is it a global setting?	The DN Rescan feature can be enabled either at the node level or the network level. There are no restrictions.
Are there any caveats (cautions) when using the feature?	<p>Yes. You must consider the following:</p> <ol style="list-style-type: none">1. The DN will lose all its links and recovery will be slower, necessitating careful usage of this feature.2. If the channel is modified via the local GUI (for instance, to run Antenna Alignment), it is recommended to disable the feature first. Otherwise, the timeout might kick in and erase the set channel.3. Scanning of CB1 and CB2 channels at a time is not supported.

Gratuitous ARP support

You must enable the Gratuitous Address Resolution Protocol (ARP) support for the 60 GHz cnWave products.

Disabling the downstream broadcast at the Point of Presence (PoP) in L2 mode results in upstream nodes losing access to cnWave nodes through their IPv4 addresses. This is due to the deletion of ARP entries in the upstream routers or devices beyond the POP on their expiration.

To maintain connectivity, the support initiates Gratuitous ARP updates for the configured IPv4 management IP.

To enable (activate) the Gratuitous ARP support for DN/CN, you can set the following parameters using the **Configuration > Network > Advanced** page of the device UI or cnMaestro UI:

- `envParams.CAMBIUM_GRATUITOUS_ARP_ENABLE`: This parameter supports the following Boolean values:
 - `false`: To disable the Gratuitous ARP support. By default, the value of this parameter is `false`.
 - `true`: To enable (activate) the Gratuitous ARP support.
- `envParams.CAMBIUM_GRATUITOUS_ARP_TIME`: Specifies the time interval (in seconds) between the two Gratuitous ARP packets that are sent by the node to the upstream network. The default value of this parameter is 150 seconds.

The integer value of this parameter ranges between 20 and 6000 seconds. This parameter is applicable only when the `envParams.CAMBIUM_GRATUITOUS_ARP_ENABLE` parameter is set to `true` (enabled).



Note


The Gratuitous ARP support is not applicable when DN/CN is configured with the default IPv4 address (169.254.1.1).

Dynamic Walking PBF

The Dynamic Walking PBF feature is an enhancement over the walking PBF feature (which was introduced in Release 1.4) to facilitate more frequent updates compared to the previously supported Scheduled Beam Adjust feature. This feature is intended for deployments where very slow mobility is expected or where the optimal Line of Sight may vary at a slow rate.

The figure below illustrates how the feature functions. It depicts a typical scan range of the beamforming RF tile, with each cell representing the beam coverage for a specific beam selection.

Figure 183: *Illustration of Dynamic Walking PBF principle*



When enabled, the Dynamic Walking PBF feature iteratively refines the beams at a user-defined rate. During each iteration, the radio's current beam and its six surrounding beams are evaluated for the best link quality, and the optimal beam is selected. This allows the beam to dynamically traverse across the entire scan range, albeit at a slow rate.

This section covers the following topics:

- [Benefits](#)
- [Enabling Dynamic Walking PBF](#)
- [Key points](#)

Benefits

The key benefits of enabling Dynamic Walking PBF are:

- Connectivity of very slow-moving targets, such as connecting cranes at a container terminal or floating platforms on seabed where the radio height changes with the tide.
- Improved performance: Iteratively searching for the best beam ensures that the link remains on the best possible beam to achieve the best signal-to-noise ratio. When interference affects a particular direction,

selecting an adjacent beam may create a null in the true line-of-sight direction experiencing interference, at the cost of 1 to 2 dB of desensitization.

- **Recovery from severe weather conditions:** When a link drops due to snow, ice, or rain and subsequently recovers, the beams may reconnect on a suboptimal beam since the radio will link up at the first opportunity. Dynamic Walking PBF enables the beams to iteratively refine themselves as weather conditions improve, ensuring the connection remains on the best beam.



Note

Scheduled PBF is orchestrated by the E2E controller for the entire network, with scans issued as a single refinement at larger intervals, such as every four hours. The refinement of beams is centered on the IBF beams established during initial beamforming. The scheduled beam refinement is designed to operate on a large, fixed network.

In contrast, the Dynamic Walking PBF feature is designed to operate independently of the E2E controller. This feature works best in smaller networks, such as PTP, PMP, or distributed networks with a very small number of hops, and in scenarios with slow mobility or changing RF conditions. The beam refinement is based on the current beam the radio is operating and will iteratively improve on it.

Enabling Dynamic Walking PBF

You can enable the Dynamic Walking PBF feature through the **Advanced** page in the [device UI](#) or the [cnMaestro UI](#).



Note

Before enabling the Dynamic Walking PBF feature, ensure that the Scheduled PBF feature is disabled on the Configuration > Network > Radio page.

Device UI

Using the device UI, complete the following steps:

1. From the dashboard page, navigate to the **Configuration > Network > Advanced** page.
2. In the search box, type `configPbfInterval`.

You can view the following radio and link parameters: `radioParamsBase.fwParams.configPbfInterval` and `linkParamsBase.fwParams.configPbfInterval`.

3. Set the value of these two parameters (radio and link) to the required interval (in seconds) using the edit icon in the corresponding row, respectively.

The default value of these parameters is 0 (disabled) and the minimum interval is 2 seconds (most dynamic value). The maximum value is 120 seconds.

Figure 184: The Advanced page - Device UI

Field	Status	Value	
radioParamsBase.fwParams.configPbfInterval	modified	2	[edit icon]
linkParamsBase.fwParams.configPbfInterval	modified	2	[edit icon]

4. Click **Submit** to save the changes.

cnMaestro UI

Using the **Monitor and Manage > Networks > Configuration > Advanced** page in the cnMaestro UI, you can search for `configPbfInterval` and set the value of radio and link parameters to the required interval (in seconds).


The default value of these parameters is 0 (disabled) and the minimum interval is 2 seconds (most dynamic value). The maximum value is 120 seconds.



Note

cnMaestro 5.2.0 and later versions support the UI controls for configuring the Dynamic Walking PBF feature.

Figure 185: The Advanced page - cnMaestro UI



Key points

Note the following key points about the Dynamic Walking PBF feature:

- Dynamic Walking PBF is applicable only to a 50% Downlink / 50% Uplink duty cycle. This is because any scan or beamforming function causes the TDD configuration to fall back to the default 50:50 duty cycle. In a scheme where Walking PBF operates at relatively short intervals, the frequent switching between TDD0 and other TDD configurations would deem Asymmetrical TDD operation meaningless.
- When configured for Dynamic Walking PBF, the slot allocation for carrying data traffic is reduced to 50% for 400ms in this Interval Period to accommodate these scans.
- Even when configured for Dynamic Walking PBF, priority is still given to ignition requests from the controller. When the controller issues an ignition request to ignite a link, the Dynamic Scan is blocked for 25 seconds. The scan will resume (re-establish) once the 25-second timeout expires. In a distributed (mesh) network, a scan block out on a DN sector propagates to all wirelessly connected DN sectors and their clients.
- Enable Dynamic Walking PBF only at the network level and only after all nodes have been upgraded to Release 1.5 or later, which supports this feature. For a standalone PTP link connected to the rest of the network through a relay, the feature can be enabled as a node-level advanced configuration.
- When there is only one link in a sector (for example, PTP), Dynamic Walking PBF will run at intervals of `configPbfInterval` seconds. When multiple links are present in the sector, the scans are synchronized with the control superframe, and each link performs its scan at intervals of `configPbfInterval * 16` seconds.

Auto Channel and Golay Optimizers

The Auto Channel and Golay Optimizer features provide installers with a good starting point for channel planning in an established network.

Channel and Golay planning are crucial aspects of CnWave 60 GHz network design. In a network that has grown organically, it may be necessary to optimize channels and Golay settings at various stages of growth to update the channel and Golay allocation, ensuring the best resiliency against self-interference.

This section covers the following topics:

- [Channel Optimizer](#)
- [Golay Optimizer](#)
- [Key points](#)
- [Executing Auto Channel and Golay Optimizers](#)

Channel Optimizer

With the Auto Channel Optimizer, the controller estimates the interference profile for the entire network by utilizing site coordinates and the antenna beam profiles for each hardware variant. Based on this information, channels and Golays are allocated. Channel changes are coordinated across the network by the E2E Controller without requiring input from the installer.



Note


In Fast Acquisition static mode, if the backup link is used for backhaul, running channel optimization may cause the CN to lose connectivity because the backup link's channel remains fixed and does not adjust during the optimization process. To avoid this issue, channel optimization should not be performed in static mode when the backup link is in use.

Clearing user overrides for channel assignments

User overrides refer to manual configurations made by a network administrator or installer, such as assigning specific nodes to use a particular channel.


There is an option (or flag) that can be set to clear these overrides. When the flag is enabled, manual settings are erased, and the system automatically adjusts channels based on its interference analysis. However, there may be scenarios where the user prefers to retain overrides, such as when a long-range link (a connection over a long distance) relies on a specific channel for example, channel 4). In such cases, the installer would leave the flag disabled to preserve the manual override settings. For example, the figure below shows that all are in channel 1 and manual channel override is configured in Backup-PoP_V5K.

Figure 186: Manual channel override settings before clearing user assigned channels



When the channel overrides are cleared (using device UI or cnMaestro UI), the devices get automatically from the controller. Channel 2 is optimized between Backup-PoP_V5K and V5K-DN2 by the controller (as shown in [Figure 187](#)).

Figure 187: Optimized channel after clearing user-assigned channels



Golay Optimizer


Golay codes are used in CnWave 60 GHz for PHY training and synchronization. Different Golay codes are necessary to prevent false correlations in the presence of interference. They help protect links from early-stage weak interference and situations where channel discrimination is not possible because the interfering link belongs to the same link group. Since Golay is a link-based parameter and not a link group-based parameter like channel, different heuristics are applied during the optimization process.

Clearing user overrides for Golay assignments

Similar to channel assignments, there is also a flag for Golay codes that allows you to clear any user-set overrides. When enabled, the optimizer ignores manual Golay assignments and recalculates them based on the interference profile.


For example, the figure below shows the link between Primary-PoP_V5K and Backup-PoP_V5K has Golay 2. In this case, Backup-PoP_V5K is configured with Golay 2 override.

Figure 188: Golay assignment before clearing user overrides



When the Golay overrides are cleared (using device UI or cnMaestro UI), the devices get Golay code automatically from the controller. The figure below shows the optimized Golay. In this case, the devices have received the Golay code as 1 from the controller, automatically.

Figure 189: Optimized Golay assignment after clearing user overrides



Key points

Note the following key points specific to Auto Channel and Golay Optimizer:

- When optimizing the network for channels and Golay codes, channel optimization should be performed first, followed by Golay optimization.
- It is important to note that channel changes do not cause a minion restart. The links will attempt the channel change without dropping the link; however, if the RF channel conditions differ significantly, the links may drop and then re-establish.
- The Channel Optimizer requires all links to be online for the network to compute and apply channel changes. If any links are offline, channel changes for the group containing the offline link will be skipped. This prevents the offline DN from being stranded after a channel change.
- Only channels from the enabled channel list and those permitted by the regulatory region will be used. Check the enabled channel list (using the Advanced UI page) to ensure that the required channels are available.
- The interference profile is calculated based on the node's coordinates and antenna beam pattern. For DNs and CNs with a GPS, the coordinates are automatically available. However, for V1000s, which do not have a built-in GPS, the coordinates must be manually entered to reflect the node's position with reasonable accuracy, ensuring that the synthesized interference profile is representative.
- The Channel Optimizer assumes that all links in the network use CB1 channels only. CB2 channels are not included in the channel or Golay optimization.

Executing Auto Channel and Golay Optimizers

You can enable the Auto Channel and Golay Optimizer features through the **Advanced** page in the device UI or the cnMaestro UI.



Note

cnMaestro 5.2.0 and later versions support the UI controls for executing Auto Channel and Golay Optimizer features.


cnMaestro UI

Using the cnMaestro UI, perform the following tasks:

1. From the dashboard page, navigate to the **Monitor and Manage > Networks > Configuration > Advanced** page.
2. Click **Optimization** on the Advanced page.


The drop-down list displays Optimize Golay Allocation, Optimize Channel Allocation, and other options.

Figure 190: Auto channel and Golay optimizers - cnMaestro UI




3. To execute the Channel Optimizer feature, complete the following steps:
 - a. Select **Optimize Channel Allocation** from the **Optimization** drop-down list.
The Optimize Channel Allocation configuration box appears.
 - b. Select the **Clear user-assigned Channels** checkbox and click **Confirm**.

Figure 191: The Optimize Channel Allocation configuration box



4. To execute the Golay Optimizer feature, complete the following steps:
 - a. Select **Optimize Golay Allocation** from the **Optimization** drop-down list.
 - b. Select the **Clear user-assigned Golays** checkbox and click **Confirm**.

Figure 192: The Optimize Golay Allocation configuration box




Device UI

Using the device UI, perform the following tasks:

1. From the dashboard page, navigate to the **Configuration > Network > Advanced** page.
2. Click **Action** on the Advanced page.

The drop-down list displays Optimize Golay Allocation, Optimize Channel Allocation, and other options.

Figure 193: Auto channel and Golay optimizers - Device UI



3. To execute the Golay Optimizer feature, select Optimize Golay Allocation from the **Action** drop-down list. Then, Select the **Clear user-assigned Golays** checkbox and click **Confirm**.
4. To execute the Channel Optimizer feature, select Optimize Channel Allocation from the **Action** drop-down list. Then, Select the **Clear user-assigned Channels** checkbox and click **Confirm**.

Node configuration

Node configuration is used to configure the nodes via E2E Controller. E2E Controller can modify the node settings. Select the node(Radio) on the left pane to modify the settings.

The **Node** configuration contains the following tabs:

- [Radio](#)
- [Networking](#)
- [VLAN](#)
- [Security](#)
- [Advanced](#)

Radio

To configure the Radio page, navigate to **Nodes > Radio** page from the **Configuration** page. The **Radio** page settings apply to individual nodes selected in the left side panel. Select the required options for Transmit Power, Adaptive Modulation, Sector 1, Sector 2 from the drop-down. Enable **Force GPS Disable** to establish the link between indoor nodes.

Figure 194: The Radio page

The screenshot displays the 'Radio' configuration page within a network management system. The interface includes a left-hand navigation pane with a tree view showing the hierarchy: PoP-V5K-884938 > DN-V5K-3f69. The main configuration area is divided into several sections:

- EIRP:** Contains a 'Maximum EIRP' field set to 38, with a note 'Allowed range is 13 dBm to 38 dBm'. Below it is the 'IBF Transmit Power' section with two radio buttons: 'Short range (<25m) optimized' and 'Long range optimized' (which is selected). A note states 'Initial Beam Forming transmit power setting'.
- Adaptive Modulation:** Includes 'Minimum MCS' (set to 2) and 'Maximum MCS' (set to 12), both with range notes of '[2, 12]'.
- Sector 1:** Features a descriptive note about channel/polarity changes. Below is a table for configuration overrides:

Override	Name	Auto Config	Node Config
<input checked="" type="checkbox"/>	Channel	1	1
<input type="checkbox"/>	Polarity	Even	
- Sector 1 Link (s) Golay:** Contains a table for link configuration:

Override	Name	Auto Config (Rx/Tx)	Node Golay Rx	Node Golay Tx
<input type="checkbox"/>	link-DN-V5K-3f69-PoP-...	2/2		


 An 'Override All' link is present below the table.
- Sector 2:** Similar to Sector 1, with a descriptive note and an empty override table.
- Sector 2 Link (s) Golay:** Shows an empty table with the note 'No Data'.
- GPS:** Includes a 'Force GPS Disable' checkbox and a note: 'When checked, the radio will use internal sync rather than GPS sync'.

The top right of the configuration area contains 'Submit' and 'Cancel' buttons.

The **Radio** page contains the following elements:

Table 48: Elements in the Radio page

Elements	Description
EIRP	Transmit power of the radio <ul style="list-style-type: none"> • Maximum EIRP - The maximum EIRP transmitted by the radio. Range differs based on the platform and country selected (in the Network page). • IBF Transmit power - Transmit power using during initial beam forming. When all the links are in short-range, high transmit power can cause interference. Selecting short-range optimized will prevent this. Post beam forming, automatic power control will make sure the radio transmits at optimal power.
Adaptive	Select minimum and maximum coding scheme ranging from 2 to 12.

Elements	Description
Modulation	
Sector 1	<ul style="list-style-type: none"> Select the frequency channel and polarity. Channel and Polarity - When a link is created in topology, the controller automatically sets the sector's channel and polarity. To manually override, click the check box and select the channel in the node configuration. Note that changing channel/polarity breaks the link. It is important to change for leaf nodes first and then higher up on DNs.
Sector 1 Link(s) Golay	<p>Golay codes help in avoiding inter-sector interference. In rare scenarios, individual links might require separate Golay codes. In most scenarios, all the links belonging to a sector are configured same Golay code. The controller automatically sets the Golay code. To manually override, select the check box and set the Golay from the drop-down. Override All button helps in setting the same Golay code for all the links.</p> <div>  <div> Note Golay codes and frequency on both ends of the link should match. </div> </div>
Sector 2	Select the frequency channel and polarity.
Sector 2 Link(s) Golay	Golay code.
GPS	If enabled, the radio uses internal sync rather than GPS sync. In some scenarios like lab setups, it may be necessary to disable GPS.



Caution

60 GHz cnWave V1000 and V3000 devices has only **Sector 1**.

V3000 Small dish support

The software allows the selection of smaller 40.5 dBi antenna dish. To select V3000 small dish, navigate to **Configuration > Nodes > Radio**. The **Antenna** section is available in the Radio page.

Figure 195: The Antenna section

The screenshot shows the 'Configuration' page with the 'Nodes' tab selected. On the left, a list of nodes is shown: V3K-416b-PoP (selected), V3K-DN-5419, V3K-CN@7049, and V3K-DN2-6f97. The main area displays the 'Radio' configuration for the selected node. The 'Antenna' section is expanded, showing the following settings:

- EIRP**
 - Maximum EIRP: 51 (Allowed range is 35 dBm to 55 dBm)
 - IBF Transmit Power: ☐ Short range (<25m) optimized, ☒ Long range optimized
 - Initial Beam Forming transmit power setting
- Antenna**
 - Antenna Dish Gain: 44.5 dBi
- PTP Deployment Range**
 - PTP Deployment Range: Up to 1.5 km
 - Deployment range applicable in Point to Point deployment. Please change for the far end node first.
- Adaptive Modulation**
 - Minimum MCS: 2
 - Range: [2, 12]

Buttons for 'Submit' and 'Cancel' are located at the top right of the configuration area.



Caution

Small dish is supported only for 60 GHz cnWave V3000.

Networking

Using the **Nodes > Networking** page, you can set the following configurations:

- [Configuring static IPv4 management and other network settings](#)
- [Configuring DHCPv4 client on PoP nodes](#)
- [Enabling the DHCP Option 82 feature](#)
- [Configuring Monitor IPV4 Gateway](#)
- [Setting the Out of Band \(OOB\) interface](#)
- [Configuring PTP External failover](#)

Configuring static IPv4 management and other network settings

To configure static IPv4 management, PoP interface, and other network settings, perform the following steps:

1. From the home page of device UI, navigate to **Nodes > Networking**.
The **Networking** page appears.
2. In the **IPv4 Management** section, enter the local IPv4 address.

Figure 196: The IPv4 Management section in the Networking page

Configuration

Network Nodes

Search

PoP-V5K-884938

DN-V5K-3f69

Radio Networking VLAN Security Advanced

Submit Cancel

☐ IPv4 Management

IPv4 Address

169.254.1.1

Subnet Mask

255.255.0.0

Gateway IP Address

☐ PoP Configuration

PoP Routing

☐ Border Gateway Protocol (BGP) Routing ☒ Static Routing

PoP Interface

☐ Aux ☐ Main ☒ SFP ☐ Disabled

IPv6 address on the interface that the PoP node uses to communicate with the upstream router. Prefix length is fixed as 64.

Table 49: Elements in the IPv4 Management section

Elements	Description
IPv4 Address	Static IPv4 address of the individual node. Node's GUI /CLI can be opened using this IP address when directly connected over Ethernet. For Over the air access, L2 Bridge should be enabled. Its predominantly used on PoP nodes with the onboard controller.
Subnet Mask	Subnet mask for the IPv4 address.
Gateway IP Address	IPv4 Gateway address.

- In the **PoP Configuration** section, select the options for **PoP Routing**, **PoP Interface**, and click **Generate** to generate **PoP Interface IP Address**.

Figure 197: The PoP Configuration section in the Networking page

Configuration

Network Nodes

Search

PoP-V5K-884938

DN-V5K-3f69

Radio Networking VLAN Security Advanced

Submit Cancel

☐ PoP Configuration

PoP Routing

☐ Border Gateway Protocol (BGP) Routing ☒ Static Routing

PoP Interface

☐ Aux ☐ Main ☒ SFP ☐ Disabled

IPv6 address on the interface that the PoP node uses to communicate with the upstream router. Prefix length is fixed as 64.

PoP Interface IP Address

2604:0:0:2c00:2

Generate

IPv6 address on the interface that the PoP node uses to communicate with the upstream router. This IPv6 address should not be in the same subnet as Seed Prefix

IPv6 Gateway Address

2604:0:0:2c00:1

A configured IPv6 Gateway Address must be reachable from the PoP for the system to function. This address can be left blank when layer 2 bridging is enabled.

☐ BGP Configuration

Table 50: Elements in the PoP Configuration section

Elements	Description
PoP	PoP nodes connect to the upstream IPv6 router in one of two ways:

Elements	Description
Routing	<ul style="list-style-type: none"> • Border Gateway Protocol (BGP) Routing - PoP acts as a BGP peer • Static routing - IP gateway address should be specified on the PoP and static route should be added on the upstream router. <p>When the system is targeted for L2 traffic (Layer 2 bridge enabled) and an onboard controller is used, this configuration is of not much significance, recommended to set to static routing.</p>
PoP Interface	The wired interface on which PoP communicates to an upstream router or switch when the L2 bridge is enabled.
PoP Interface IP Address	IPv6 address on the interface that the PoP node uses to communicate with the upstream router.
IPv6 Gateway Address	Gateway address. It can be left empty when the L2 bridge is enabled and no IPV6 services like NTP /Radius are used.

4. Under **E2E Controller Configuration**, enter E2E IPV6 Address (Address of E2E Controller). When using the onboard controller on the same node, it can be left empty and GUI automatically fills the POP IPv6 address.



Note

If PoP DN is V5000/V3000 then, IPv6 both address is same.

Table 51: Elements in the E2E Controller Configuration section

Elements	Description
E2E IPv6 Address	Address of E2E Controller. When using the onboard controller on the same node, it can be left empty and GUI automatically fills the POP IPv6 address.
E2E Network Prefix	Seed Prefix in the CIDR format followed by a comma and the prefix length. Should be specified when BGP is used. Otherwise, optional.
IPv6 CPE Interface	IPv6 SLAAC provides IP prefix to downstream CPE devices. Keep it disabled when L2 Bridge is active.

5. Select the required BGP configuration.

Figure 198: *The BGP Configuration section*

Table 52: Elements in the BGP Configuration section

Elements	Description
Local ASN	Local ASN
KeepAlive	The BGP keepalive period in seconds.
Neighbour ASN	Upstream router's ASN
Neighbour IPv6	Upstream router's IPv6 address
Specific Network prefixes	Specifically allocated network prefixes to be advertised via BGP

6. Enable the required Ethernet ports. Individual Ethernet ports can be turned off with this configuration.

Figure 199: *The Ethernet Ports section*

7. Select the required options for **Layer 2 Bridge**, **IPv6 Layer 3 CPE**, **Aux PoE** (enable to power on Aux port), and **Multi-PoP / Relay Port**. By default, this option is disabled and PoP floods any unknown unicast ingress packets on all the L2 GRE tunnels. When the option is enabled, PoP drops such packets.

Figure 200: The Layer 2 Bridge section in the Networking page

The screenshot shows the 'Configuration' page for a network device, specifically the 'Networking' tab. On the left, a sidebar lists several nodes: 'node-V5000-886cf5' (selected), 'node-V5000-030405', 'node-V5000-778899', 'node-V5000-883088', and 'DN'. The main content area is titled 'Layer 2 Bridge' and contains the following options:

- ☐ Layer 2 Bridge
 - ☐ Disable Broadcast Flood
Broadcast packets (except DHCP Offer and DHCP Ack) in the downlink direction including client to client packets will be dropped.
 - ☐ Disable Unknown Unicast Flood
 - ☐ Disable IPv6
 - ☐ Monitor IPv4 Gateway
In Layer 2 bridging with multiple POP nodes, enabling this feature will configure this POP to periodically ARP ping the configured IPv4 Gateway. If the ARP pings are to fail, all other nodes within the mesh network will choose one of the other available POP nodes to route to
- DHCP Option 82
 - ☐ Enabled
 - ☒ Disabled

DHCP option 82 will be inserted in the DHCP requests.

Table 53: Elements in the Layer 2 Bridge section

Elements	Description
Layer 2 Bridge	<p>It has three options:</p> <ul style="list-style-type: none"> • Disable Broadcast Flood • Disable Unknown Unicast Flood • Disable IPv6 • Monitor IPv4 Gateway <p>For information on Monitor IPv4 Gateway, refer to Configuring Monitor IPv4 Gateway,</p>
Aux PoE	<p>Enable PoE out (25 W) on V5000/V3000 aux port. 802.3af and 802.3at compliant devices could be powered up, passive PoE devices cannot be powered up. Note that the aux port cannot power another V5000/V3000.</p>
Multi-PoP / Relay Port	<p>Indicates the wired interfaces (or Ethernet) on which OpenR is running. This element must be used:</p> <ul style="list-style-type: none"> • When DNs are connected back-to-back. • When multiple PoPs are in the network. This allows PoP nodes to forward traffic to other PoP nodes via a wired connection when the routing path of the other PoP node is closer to the traffic destination <p>The following options are supported:</p> <ul style="list-style-type: none"> • Aux • Main • SFP • Disabled

Configuring DHCPv4 client on PoP nodes

When you configure DHCPv4 on the PoP nodes, the DHCP client simplifies and automates the process of network configuration for devices. A manual configuration of the network settings is not required. The DHCP client automates the process by interacting with DHCP servers on the network. The DHCP client uses the information received from the DHCP server to configure its network interface, including obtaining an IP address, subnet mask, default gateway, DNS server addresses, and other relevant settings.



Note

The DHCP configuration is available only for the PoP nodes. It is not available for CN and DN nodes.

To set the DHCP configuration, perform the following steps:

1. From the home page of device UI, navigate to **Nodes > Networking**.

The **Networking** page appears.

2. In the **IPv4 Management** section, select **DHCP** from the IP Assignment parameter options, as shown in [Figure 201](#).

Figure 201: DHCPv4 Configuration - device UI

60 GHz cnWave™ V2000

Reboot admin

Configuration

Radio Networking VLAN Security Advanced

Submit Cancel

IPv4 Management

IP Assignment

☐ Static ☒ DHCP

IPv4 Address

10.110.206.132

IPv4 Management address is not accessible over Relay port (except for PoP interface), OOB interface and IPv6 CPE interface.

Subnet Mask

255.255.0.0

Gateway IP Address

10.110.206.253



Note


You can also use the cnMaestro UI (Configuration > Network page) to set the DHCP configuration.

3. Click **Submit** to apply the changes.

When you set the DHCP configuration, the IPv4 address, Subnet mask, and Gateway IP address are automatically obtained from the DHCP server.

The dashboard page in both the device UI (running the Onboard Controller) and cnMaestro display the IPv4 address. [Figure 202](#) shows the dashboard page of a device UI.

Figure 202: The dashboard page displaying the IPv4 address



Enabling the DHCP Option 82 feature

When the **DHCP Option 82** feature is enabled, 60 GHz cnWave intercepts DHCPv4 REQUEST and DISCOVER packets and inserts option 82 fields.



Note

This feature is supported in the L2 bridge mode.

In addition, you can also configure **Circuit ID** and **Remote ID** fields. Use the following wildcards to configure **Circuit ID** and **Remote ID** fields:

- **\$nodeMac\$** - MAC address of the node in ASCII format without colons. This is a default option.
- **\$nodeName\$** - Topology name of the node.
- **\$siteName\$** - Name of the site.
- **\$networkName\$** - Network name as shown in cnMaestro.

Multiple wildcards can be combined with a **:** delimiter. The total length of the option (after replacing wildcards with corresponding values) is truncated to 120 characters. You can also configure a custom string, which must not start with a **\$** character. For example, a customer's phone number.



Note


You cannot use the customized string and predefined wildcards together as a single sub option (Circuit ID / Remote ID).

To enable the **DHCP Option 82** feature, perform the following steps:

1. Navigate to **Nodes > Networking** from the home page.

The **Networking** page appears. The **DHCP Option 82** feature is available in the Layer 2 Bridge section, as shown in [Figure 203](#).

Figure 203: *The DHCP Option 82 feature*



The enabled status of **DHCP Option 82** implies that the feature is activated.

2. Type appropriate values in **Circuit ID** and **Remote ID** text boxes.
3. To save the configuration, click **Submit**.

Configuring Monitor IPv4 Gateway

The **Monitor IPv4 Gateway** parameter is applicable when static routing and Layer 2 bridge are enabled in the device UI.

When you enable this parameter using the device UI, the IPv4 gateway is monitored. In Layer 2 bridging with multiple PoP nodes, this parameter (when enabled) configures the PoP to periodically ARP ping the configured IPv4 gateway. If the ARP ping fails for consecutive 12 seconds, all the other nodes (within the mesh network) choose one of the other available PoP nodes to route.

The **Monitor IPv4 Gateway** configuration results in failover of Layer 2 tunnels to next best PoP when the PoP cannot reach the IPv4 gateway. This configuration is applicable when static routing is used and IPv4 gateway is configured.

Before configuring the **Monitor IPv4 Gateway** parameter, perform the following configurations using the device UI:

- Enable the **Layer 2 Bridge** parameter using the **Configuration > Network > Basic** page. This action enables Layer 2 network bridging (through automatically created tunnels) across all nodes connected to a PoP. This action also facilitates the bridging of IPv4 traffic across the wireless networks.
- Set the value of **PoP Configuration** parameter to Static Routing for the required PoP using the **Configuration > Nodes > Networking** page. This action results in failover of Layer 2 tunnels to next best PoP when the PoP cannot reach the IPv4 gateway. This configuration is applicable when static routing is used and IPv4 gateway is configured.

To enable and configure the **Monitor IPv4 Gateway** parameter, perform the following steps:

1. From the home page, navigate to **Configuration > Nodes > Networking**.

The **Networking** page appears. The **Monitor IPv4 Gateway** check box is available in the **Layer 2 Bridge** section, as shown in [Figure 204](#).

Figure 204: *The Monitor IPv4 Gateway parameter*

The screenshot shows the 'Configuration' page with the 'Nodes' tab selected. Under 'Nodes', a list of nodes is shown on the left, including 'node-V5000-886cf5', 'node-V5000-030405', 'node-V5000-778899', 'node-V5000-883088', and 'DN'. The 'Networking' tab is selected, and the 'Layer 2 Bridge' section is expanded. The 'Monitor IPv4 Gateway' checkbox is checked and highlighted with a red box. The description for this option states: 'In Layer 2 bridging with multiple POP nodes, enabling this feature will configure this POP to periodically ARP ping the configured IPv4 Gateway. If the ARP pings are to fail, all other nodes within the mesh network will choose one of the other available POP nodes to route to'. Other options in the 'Layer 2 Bridge' section include 'Disable Broadcast Flood', 'Disable Unknown Unicast Flood', and 'Disable IPv6'. The 'DHCP Option 82' section is also visible, with 'Enabled' and 'Disabled' radio buttons.

2. Select the **Monitor IPv4 Gateway** check box to enable the parameter.
3. Click **Submit** to save the changes.

Setting the Out of Band (OOB) interface

Out of band (OOB) management interface to access the device. Management VLAN is bypassed, and data traffic will not be routed or bridged on this interface. The OOB management interface is supported at PoP. A separate IPv4 address should be configured by bypassing the Management VLAN. Navigate to **Configuration > Nodes > Networking > OOB** and select the required option. Enter the IPv4 address and Subnet Mask to access the device.

Figure 205: *The OCB section in the Networking page*

The screenshot shows the 'Configuration' page with the 'Nodes' tab selected. Under 'Nodes', a list of nodes is shown on the left, including 'PoP-V5K-884938' and 'DN-V5K-3f69'. The 'Networking' tab is selected, and the 'OOB' section is expanded. The 'OOB Interface' section is visible, with the 'Aux' radio button selected. The 'IPv4 Address' field is set to '10.110.186.179' and the 'Subnet Mask' field is set to '255.255.255.0'. The 'Multi-PoP / Relay Port' section is also visible, with the 'Disabled' radio button selected.

Configuring PTP External failover

The **PTP External Failover** feature supports the failover of a 60 GHz cnWave RF link using external devices such as PTP450 and ePMP.



Note


System Release 1.2.2 and later subsequent release versions support the external failover link feature for Point-to-Point (PTP) links. The external failover interface must not be same as PoP, Relay, or Out of Band (OOB) interface.

This feature does not support V1000 (which contains only one port).

Figure 206 shows how a 60 GHz cnWave PTP link is backed up with a PTP450 link. You can consider the 60 GHz link (as shown in Figure 206) as the primary link and 5 GHz link as the secondary link.


Figure 206: Backing up the 60 GHz cnWave PTP link

Scenario 1:



Note: Enable AUX PoE Power on V3000.

Scenario 2:



Note: Disable AUX PoE Power on V3000.

Whenever a 60 GHz link is up or active, traffic flows through the 60 GHz cnWave link. When the 60 GHz link is down, traffic fails over (shifts) to the 5 GHz link (PTP450). When the 60 GHz link is back (up), the traffic shifts instantly over to the 60 GHz cnWave link.

You can configure the external failover link feature using the [device UI](#) or the [cnMaestro UI](#).

Using the device UI:

To enable and configure the external failover link feature using the device UI, perform the following steps:

1. From the home page of the device UI, navigate to the **Configuration > Nodes > Networking** page.
The **Networking** page appears.
2. In the **PTP External Failover** section (as shown in [Figure 207](#)), set the following configurations:
 - a. To set the Ethernet interface for a node connected to external failover link, select either **Aux** or **Main** (Ethernet ports) from the **External Failover Link** parameter.
By default, the **Disabled** option is selected.

Figure 207: The PTP External Failover section in the device UI

- b. Enter either IPv4 or IPv6 address of the external failover device In the **External Failover Device IPv4 or IPv6 Address** text box.



Note

Ensure that IPv6 is enabled in the external failover device.

3. Click **Submit** to save the changes.

Using the cnMaestro UI

To configure the external failover link feature, add and manage the following configurations in the **Advanced** page of cnMaestro UI:

- **Ethernet interface for each node:** Configure the Ethernet interface in PoP and CN, which are connected to the failover link. You must select the Ethernet port to which the external device is connected. Open/R protocol runs on this interface.

- **External failover interface address (IP address):** An optional configuration that is required only if you want to access the AP or SM UI from upstream. You must configure the IP address of external devices (for example, PTP450 or ePMP). This IP address must be in a different subnet other than node IP address or seed prefix.


The IP address can be either IPv4 or IPv6. However, ensure that external failover devices have IPv6 enabled.

- **Remote external failover node address:** Configure the remote external failover node address. You can access the external failover device UI using `http://<cnwave node IP>:50080/` or `https://<cnwave node IP>:50443/`.

To configure the external failover link feature using the cnMaestro UI, perform the following steps:

1. From the dashboard page of the cnMaestro UI, navigate to the **Monitor and Manage > Networks > Configuration > Node > Advanced** page.
The **Advanced** page appears.
2. To add and manage the Ethernet interface for each node (PoP and CN), Click **Add New** located at the right side of the page.
The **Add new field** page appears.
3. In the **Field Name** text box, provide `envParams.CAMBIUM_EXTERNAL_FAILOVER_IFACE` (in String format) for each node, as shown in [Figure 208](#).

Figure 208: The Add new field page in the cnMaestro UI




4. In the **Value** field, enter an appropriate value.
5. Click **Save**.
The **Advanced** page is updated the new entry that you added.
6. Click **Submit** located on the right side of the **Advanced** page.

Similarly, you must add and manage the following configurations, separately, using the **Add New** button on the **Advanced** page:


- For external failover interface address (IP address), provide `envParams.CAMBIUM_EXTERNAL_FAILOVER_IFACE_ADDR` (in String format) in the **Field Name** text box, as shown in [Figure 209](#).

Figure 209: Configuring the external failover interface address



- For remote external failover node address, provide `envParams.CAMBIUM_EXTERNAL_FAILOVER_NODE_ADDR` (in String format) in the **Field Name** text box, as shown in Figure 210.

Figure 210: Configuring the remote external failover node address



Then, you must ensure to provide an appropriate value in the **Value** text box for each configuration. Finally, you must save and submit each configuration.



Note

Following limitations are observed in this release specific to the external failover feature:

- There is no representation of an external failover link on the **Map** page.
- There are no statistics available on the external failover link.
- No other UI or cnMaestro used for configuring the external failover interface and address. This feature can be configured only through the **Configuration > Nodes > Advanced** page.

VLAN

Data VLAN

The following 802.1Q features are supported per port:

- Adding single VLAN tags to untagged packets
- Adding QinQ/double-tag to untagged packets
- Adding QinQ outer tag to single tagged packets
- Transparently bridge single/double-tagged packets (default behavior)
- Remarking VLAN ID
- Remarking 802.1p priority
- Option to allow only the selected range of VLAN IDs
- Option to drop untagged packets
- Option to drop single tagged packets
- Option to select the ethertype of the outer tag

These options are per Ethernet port.



Note

VLAN configuration is applicable only when Layer 2 bridge is enabled.

Port Type

Figure 211: The port types




Transparent

By default, the Ethernet port is in transparent mode. Packets will be transparently bridged without any 802.1Q processing.

Q

Q mode allows adding a single C-VLAN tag to untagged packets.


Figure 212: Native VLAN ID and priority



The form contains two input fields. The first field is labeled "Native VLAN ID" and contains the value "23". Below it, a text label reads "Allowed range is 1 - 4094". The second field is labeled "Native VLAN Priority" and contains the value "2". Below it, a text label reads "Allowed range is 0 - 7".

Native VLAN ID and priority fields define the C-VLAN tag properties.

Figure 213: Allowed VLANs



The form contains a single input field labeled "Allowed VLANs" with the value "2". Below the field, a text label reads "List of allowed VLANs. Comma separated, and/or range. e.g 100, 210-220. Filter based on outer tag."

Allow only the listed range of VLAN IDs.

Figure 214: Untagged types




The form is titled "Untagged Packets". It contains two radio button options: "Allow" (which is unselected) and "Drop" (which is selected).

This option allows the dropping of untagged packets. Native VLAN properties are not necessary to fill when untagged packets are dropped.

QinQ

QinQ mode allows adding a double tag to untagged packets and outer S-VLAN to single-tagged packets.


Figure 215: Native C-VLAN ID and priority



The form contains two input fields. The first field is labeled "Native C-VLAN ID" and contains the value "23". Below it, a text label reads "Allowed range is 1 - 4094". The second field is labeled "Native C-VLAN Priority" and is currently empty. Below it, a text label reads "Allowed range is 0 - 7".

These are the C-VLAN tag properties of added tag.


Figure 216: Native S-VLAN ID and priority



The form contains two sections. The first section is titled 'Native S-VLAN ID' and features a text input field with the value '34'. Below the input field, it states 'Allowed range is 1 - 4094'. The second section is titled 'Native S-VLAN Priority' and features an empty text input field. Below this input field, it states 'Allowed range is 0 - 7'.

These are the S-VLAN tag properties of the added outer tag.


Figure 217: Untagged and Single tagged packets



The form has two sections. The first section is titled 'Untagged Packets' and contains two radio buttons: 'Allow' (which is selected) and 'Drop'. The second section is titled 'Single Tagged Packets' and also contains two radio buttons: 'Allow' (which is selected) and 'Drop'.

In QinQ mode, the above options allow dropping untagged/single-tagged ingress packets. Native C-VLAN fields are not necessary only when dropping single-tagged packets. Native S-VLAN fields are not necessary when dropping untagged and single tagged packets.


Figure 218: Allowed VLANs



The form has a section titled 'Allowed VLANs' with a text input field containing the value '2'. Below the input field, there is a note: 'List of allowed VLANs. Comma separated, and/or range. e.g 100, 210-220. Filter based on outer tag.'

Allow only the listed range of VLAN IDs. VLAN ID of the outer tag is used for this check.



Figure 219: QinQ EtherType



The form has a section titled 'QinQ EtherType' with a dropdown menu showing '0x8100 (802.1Q)'. Below the dropdown, there is a note: 'EtherType indicates which protocol is encapsulated in the payload of an Ethernet Frame.'

QinQ EtherType is used while adding an outer tag. There are no other checks for EtherType.

Figure 220: VLAN ID Remarking

VLAN Remarking		
Ingress VLAN	Remark VLAN	
10	100	 
Add New		



VLAN ID of the ingress packet is remarked. In the above example, if a packet with VLAN ID 10 enters an Ethernet port, it is remarked to 100. In the egress path, the reverse remarking occurs. VLAN ID 100 is remarked to 10 and egresses the ethernet port.

The VLAN ID of the outer tag is used for remarking. For a double-tagged packet, S-VLAN ID gets remarked and for a single-tagged packet, C-VLAN ID.

802.1p overriding

The Priority field in the (outer) VLAN tag of ingress packet can be overwritten using this option.


Figure 221: VLAN Priority Override

VLAN Priority Override		
Ingress VLAN	Override Priority	
20	7	 
Add New		

Management VLAN

A Single tag or double tag can be added to Management traffic.

Figure 222: The Management section



The Management configuration form includes the following fields and options:


- Management** (Section Header)
- ☒ Enabled ☐ Disabled
- VLAN ID**
Input field: 2
Allowed range is 1 - 4094
- VLAN Priority**
Input field: 1
Allowed range is 0 - 7
- ☒ Add Outer Tag
- S-VLAN ID**
Input field: 3
Allowed range is 1 - 4094
- S-VLAN Priority**
Input field: 2
Allowed range is 0 - 7

Security

In the **Security** tab, enter **Private key password** and **Radius user password**.

- Private key password
- Radius user password

Figure 223: The Security page



The Security configuration page shows the following configuration details:

- Configuration** (Page Header)
- Network** (Tab)
- Nodes** (Tab)
- Search** (Input field)
- Nodes List:**
 - PoP-VSK-884938
 - DN-VSK-3f69
- Security Tab:**
 - Radius user identity: cambium
 - Private key password: [Redacted]
 - Radius Private key password: [Redacted]
 - Radius user password: [Redacted]
 - Radius user password: [Redacted]
- Buttons:** Submit, Cancel

Controller UI configuration

This Controller GUI configuration to be made on each DN.

Figure 224: Elements specific to Controller configuration

Configuration

NetworkNodes

Search

POP

DN

RadioNetworkingVLANSecurityAdvanced

Radius user identity

test

Private key password

Radius Private key password

Radius user password

Radius user password

Node UI configuration

You can configure the **Security** page for a single node. The **Security** page is available on the single node UI.

Figure 225: Elements specific to node configuration

Private key password

Radius Private key password

Radius server shared secret

Radius user password

Radius user password

CA Certificate

ca.pem

Browse

Certificates sent by radius server are verified against this CA certificate

Client Certificate

client.pem

Browse

Private key with which client will encrypt

Client Private Key

client.key

Browse

Private key with which client will decrypt



Note
Both the configurations are important for a successful authentication.

RADIUS Server configuration

Any RADIUS server can be used for authentication. Perform the following steps to configure the RADIUS Server:

- 1. Ensure that RADIUS packets from IPv6 subnet (IP subnet) is accepted in RADIUS configuration.
- 2. Configure EAP-TLS for RADIUS Server and setup server certificate, key.



Note

Server certificate is signed by CA uploaded in node configuration.

3. Set the CA certificate which signed the client certificate installed on each node.

Advanced

These settings are for advanced users only.



Caution

Users are not recommended to do these settings.

Figure 226: The Advanced page - Node configuration

The screenshot shows the configuration interface for a 60 GHz cnWave v3000 device. The top bar includes the device name, a search bar, and buttons for 'Disable E2E Controller', 'Reboot', and 'admin'. The left sidebar contains navigation icons. The main area is titled 'Configuration' and has tabs for 'Network' and 'Nodes'. The 'Nodes' tab is selected, showing a list of nodes with 'node-V3000-8830da' selected. The 'Advanced' settings page is displayed, showing a table of configuration parameters. A warning message states: 'All the settings below are for advanced users only.'

Field	Status	Value	Actions
snmpConfig.contact	set	No Contact	Help, Copy, Edit
snmpConfig.location	set	No Location	Help, Copy, Edit
popParams.POP_STATIC_ROUTING	modified	1	Help, Copy, Edit
popParams.POP_IFACE	modified	nic2	Help, Copy, Edit
popParams.VPP_ADDR	unset		Help, Copy, Edit
popParams.NAT64_POP_ENABLED	set	0	Help, Copy, Edit
popParams.POP_BGP_ROUTING	modified	0	Help, Copy, Edit
popParams.NAT64_IPV6_PREFIX	unset		Help, Copy, Edit
popParams.POP_ADDR	modified	fd00:ba5e:0068:30da::8830da	Help, Copy, Edit
popParams.GW_ADDR	unset		Help, Copy, Edit
popParams.NAT64_IPV4_ADDR	unset		Help, Copy, Edit

Configuration options under **Network > Advanced** and **Node > Advanced** are for advanced users who understand the cnWave configuration model well. It is not recommended to use these options. Shows the merged configuration from the Base layer to the Network override layer.

cnWave is based on Facebook's Terragraph architecture. It follows a layered configuration model, with a node's "full" configuration computed as the union of all layers in the following order:

- **Base configuration** - The default configuration, which is tied to a specific software version and is included as part of the image. The controller finds the closest match for a node's software version string and falls back to the latest if no match was found.
- **Firmware-specific base configuration** - The default configuration is tied to a specific firmware version, which is also included as part of the image. Values are applied on top of the initial base configuration layer.
- **Hardware-specific base configuration** - The default configuration is tied to a specific hardware type, which is also included as part of the image. Each hardware type supplies configuration that changes with software versions. Values are applied on top of the firmware-based configuration layer.
- **Automated node overrides** - Contains any configuration parameters for specific nodes that were automatically set by the E2E controller.

- **Network overrides** - Contains any configuration parameters that should be uniformly overridden across the entire network. This takes precedence over the base configuration and automatic overrides.
- **Node overrides** - Contains any configuration parameters that should be overridden only on specific nodes (e.g. PoP nodes). This takes precedence over the network overrides.

The E2E controller manages and stores separate configuration layers. The cnWave nodes have no knowledge of these layers, except the base configuration on the image. The nodes copy the latest base version (via natural sort order) if the configuration file on disk is missing or corrupt.

Click **Submit** to apply the changes.

Operation

Software upgrade


The **Software Upgrade** page is used to upgrade the installed software. This page contains the following three tabs:

- **Node Upgrade** - to upgrade the node
- **Images** - to upgrade the software images
- **Node Upgrade Status** - displays the upgrade status

To upgrade a node, perform the following steps:


1. From the main dashboard page, click **Software upgrade** on the left navigation pane.

The **Software Upgrade** page appears, as shown below:



By default, the **Node Upgrade** tab is selected.

2. In the **Node Upgrade** page, select the required device for which you want to upgrade the node and click **Prepare** (as shown below).



The **Prepare Nodes** dialog box appears.

3. In the **Prepare Nodes** dialog box, select the required image file for the node and click **Save**.


You can also set additional options, if required, such as Upgrade Timeout, Download options, and Download Timeout.

4. Click **Commit** to upgrade the node.

5. To upgrade the software image, click on the **Images** tab in the **Software Upgrade** page.

The **Images** page appears, as shown below:

Figure 227: *The Images page*



6. In the Images page, click **Upload Image**.


You must browse and select the required image file from your machine. Example: Software image or package (cnWave60-<release>.tar.gz). The selected image file gets uploaded.

You can also delete an existing image file in the **Images** page.

7. To view the node upgrade status, click on the **Node Upgrade Status** tab in the **Software Upgrade** page.

The **Node Upgrade Status** page appears, as shown below:

Figure 228: *The Node Upgrade Status page*



You can view the upgrade status for the required device nodes.

Diagnostics

The **Diagnostics** page contains the following tabs:

- [Events](#)
- [DA Logs](#)
- [Engineering logs](#)

Events

The **Events** page displays the running and completed task list. These events can be exported. To export the event list, click **Export**.

60 GHz cnWave™ V3000						Disable E2E Controller	Reboot	admin
Diagnostics								
Events								
						Export		
Time	Level	Node Name	Event ID	Source	Reason			
Sep 14, 2022, 6:28:26 AM	Info	v2k_cn	Scan resp	minion-app-DRIVER_APP	Received scan response View Details			
Sep 14, 2022, 6:28:26 AM	Info	node-V3...	Scan resp	minion-app-DRIVER_APP	Received scan response View Details			
Sep 14, 2022, 6:28:25 AM	Info	v2k_cn	Scan resp	minion-app-DRIVER_APP	Received scan response View Details			
Sep 14, 2022, 6:28:25 AM	Info	node-V3...	Scan resp	minion-app-DRIVER_APP	Received scan response View Details			
Sep 14, 2022, 6:28:24 AM	Info	v2k_cn	Driver link status	minion-app-IGNITION_APP	Received LINK_UP for neighbor 12:04:56:88:42:23 on interface terra0 (42:cb... View Details			
Sep 14, 2022, 6:28:24 AM	Info	v2k_cn	Node info	minion-app-STATUS_APP	Minion is online View Details			
Sep 14, 2022, 6:28:22 AM	Info	node-V3...	Link status	ctrl-app-TOPOLOGY_APP	link-node-V3000-884223-v2k_cn is UP View Details			

DA Logs

60 GHz cnWave™ V3000

Disable E2E Controller

Reboot

admin

Diagnostics

Events

DA Logs

Engineering Logs


Download

Refresh

```
{ "file": "e2e.go:110", "func": "e2e.(*E2E).Invoke", "level": "error", "msg": "Post \ http://[::1]:8080/internal/local/getDeviceInfo\ : dial tcp [::1]:8080: connect: connection refused", "name": "e2e", "time": "2022-09-13T11:36:09Z"}
{"file": "init.go:52", "func": "e2e.(*E2E).Init", "level": "error", "msg": "Post \ http://[::1]:8080/internal/local/getDeviceInfo\ : dial tcp [::1]:8080: connect: connection refused", "name": "e2e", "time": "2022-09-13T11:36:09Z"}
{"file": "init.go:206", "func": "agent.(*Agent).Init", "level": "error", "msg": "Unable to initialize the controller Error: Post \ http://[::1]:8080/internal/local/getDeviceInfo\ : dial tcp [::1]:8080: connect: connection refused", "name": "agent", "time": "2022-09-13T11:36:09Z"}
{"file": "main.go:118", "func": "main.main", "level": "info", "msg": "Will retry in sometime", "name": "main", "time": "2022-09-13T11:36:09Z"}
{"file": "main.go:102", "func": "main.main", "level": "info", "msg": "Configuration Loaded Successfully", "name": "main", "time": "2022-09-13T11:36:14Z"}
{"file": "e2e.go:824", "func": "e2e.(*E2E).GetSerialNo", "level": "info", "msg": "onboard e2e getDeviceInfo API (Type:POP Name:node-V3000-884223 Mac:00:04:56:88:42:23 Msn:VSXC036Q2FDB Model:V3000)", "name": "e2e", "time": "2022-09-13T11:36:16Z"}
{"file": "conn.go:84", "func": "agent.(*Agent).routerConnect", "level": "info", "msg": "Connecting to router: https://10.110.186.92/cns-onboarding/device? &type=cnAgent&serialNo=VSXC036Q2FDB&mac=00:04:56:88:42:23&mode=e2e&deployment=onboard", "name": "agent", "time": "2022-09-13T11:36:16Z"}
{"file": "conn.go:85", "func": "agent.(*Agent).routerConnect", "level": "info", "msg": "User-agent header: cNDA/1.0 (e2e/1.2.2-dev185-1-gc04bc9e(W); DA/1.2.1-r8)", "name": "agent", "time": "2022-09-13T11:36:16Z"}
{"file": "conn.go:281", "func": "agent.(*Agent).connect", "level": "info", "msg": "Redirecting to Server: https://10.110.186.92/device", "name": "agent", "time": "2022-09-13T11:36:17Z"}
{"file": "e2e.go:930", "func": "e2e.(*E2E).GetMgmtAddress", "level": "info", "msg": "onboard e2e minionConfigGet API (PopParams:{PopAddr:fd00:ba5e:0088:4223::88:4223 GwAddr: EnvParams:{MgmtIPv4Addr:169.254.1.1}})", "name": "e2e", "time": "2022-09-13T11:36:17Z"}
{"file": "conn.go:188", "func": "agent.(*Agent).serverConnect", "level": "info", "msg": "Connecting to Server: https://10.110.186.92/device? deviceId=hlXlIbXgFACvYFFyIKHFYVVKFsfv7dIWqYgIXUAZIsfst_H4Y5d50uXtPeuF403FpmZkch8XrmR280tW&type=cnAgent&serialNo=VSXC036Q2FDB&mac=00:04:56:88:42:23&mode=e2e&deployment=onboard", "name": "agent", "time": "2022-09-13T11:36:17Z"}
{"file": "msg_handler.go:211", "func": "agent.(*Agent).msgHandlerUnManaged", "level": "warning", "msg": "cnMaestro (16630869978) and agent(1663069997) time are not in sync", "name": "agent", "time": "2022-09-13T11:36:18Z"}

```


Engineering logs



Statistics

The **Statistics** menu contains the following options:

- [Links](#)
- [Ethernet](#)
- [GPS](#)
- [Radio](#)
- [Performance](#)
- [Prefix Zone Statistics](#)
- [Border Gateway Protocol \(BGP\)](#)

Links

The **Links** page contains Uplink and Downlink statistical data. It displays TX and RX data of the reporting nodes from A to Z and Z to A. The page also displays statistics (for example, Rx/Tx Throughput and Rx/Tx Airtime %) that provide the necessary insights to manage and optimize cnWave networks effectively.


Based on the filters that you select using the  icon (as shown in [Figure 229](#)), the **Links** page displays the relevant elements and statistics.

Figure 229: The Links page

Link Name	Reporting Node	A Node Sector MAC	Z Node Sector MAC	RSSI	Link Fade Margin	Rx SNR	Rx MCS	RX PER	EIRP	Tx MCS	RX Through	TX Through	Rx Airtime %	Tx Airtime %	TX PER	Rx Beam Azimuth Angle	Tx Beam Azimuth Angle	Rx Beam Elevation Angle	Tx Beam Elevation Angle
link-V5K_DN...	V5K_DN	12:04:56:88:...	12:04:56:88:...	-52	41	22	9	0	13	9	1.69 ...	11.4...	100	100	0	10.2	10.2	20	20
link-V5K_DN...	node-V5000...	12:04:56:88:...	12:04:56:88:...	-55	38	19	9	0.83...	13	9	11.4...	1.69 ...	100	100	0	21.8	21.8	2.2	2.2

The **Links** page displays the following elements:

Table 54: Elements in the Links page

Element	Description
Link Name	Link name
Reporting Node	Name of the reporting node for which the statistics are available.
A Node Sector MAC	MAC address of the initiator node.
Z Node Sector MAC	MAC address of the responder node.
RSSI	The Receiver Signal Strength Indicator (RSSI) value
Link Fade Margin	<p>The statistic value (in dB) available for each RF link</p> <p>The Link Fade Margin statistic values help operators to quickly assess any additional system gain or low marginal RF links (if any), which must be addressed.</p> <p>The Link Fade Margin statistic value calculation is based on:</p> <ul style="list-style-type: none"> • Checking the RSSI received from a remote transmitter, • Assessing the availability of TX power (from the remote transmitter), and • Considering the RSSI value that is calculated based on how far away it is from an established receiver sensitively floor of -72 dBm.
Rx SNR	Signal to Noise Ratio
Rx MCS	Modulation Code Scheme of Receiver
RX PER	Receiver packer error rate
TX Power Index	Transmitter power index
EIRP	The Effective Isotropic Radiated Power (EIRP) value.
TX MCS	Modulation Code Scheme of Transmitter
TX PER	Transmitter packer error rate
RX Errors	Receiver errors

Element	Description
RX Frames	Receiver frames
TX Errors	Transmitter errors
TX Frames	Transmitter frames
Rx Throughput	The receive throughput as received by the reporting node.
Tx Throughput	The throughput transmitted by the reporting node. Monitoring this metric can clarify the data transmission rate, providing a clearer view of the network's outbound data performance.
Rx Airtime %	The percentage of airtime allocated by the scheduler to each link in the Rx direction from the perspective of reporting node. This metric is relevant for a DN as it indicates how airtime is shared across multiple links.
Tx Airtime %	The percentage of airtime allocated by the scheduler to each link in the Tx direction from the perspective of reporting node. Similar to Rx Airtime % , this metric provides insights into how airtime is distributed among links when transmitting data. This metric is only relevant for a DN.
Following replace Rx Scan Beams and Tx Scan Beam elements:	
Rx Beam Azimuth Angle	The angle of the selected fixed beam (in degrees) in the azimuth direction for each link. The selected beam is independent of transmit and receive directions. For more information on Tx/Rx azimuth beam angle statistics, refer to the Link diagnostics - Beam angle statistics section.
Tx Beam Azimuth Angle	
Rx Beam Elevation Angle	The angle of the selected fixed beam (in degrees) in the elevation direction for each link. The selected beam is independent of transmit and receive directions. For more information on Tx/Rx azimuth beam angle statistics, refer to the Link diagnostics - Beam angle statistics section.
Tx Beam Elevation Angle	


To download the statistics in .xls format, click **Download Statistics**.

Link diagnostics - Beam angle statistics

To understand Tx/Rx azimuth and elevation beam angle statistics, let's consider the following examples:


- In [Figure 230](#), the reported beam angle is relative to the reporting nodes boresight and not a bearing from North. Therefore, an **elevation angle** of +5 degrees is from the unit's perspective, choosing a fixed beam pointing of 5 degrees above the horizontal axis (towards the sky). An **azimuth angle** of +5 degrees is from the centre line or boresight of the unit with 5 degrees counting clockwise. An azimuth angle of -5 degrees is from the centre line or boresight of the unit with 5 degrees counting anti-clockwise.

Figure 230: An example of V5000 azimuth angles relative to boresight



- In Figure 231, a V1000 has been pole mounted with 0 degrees elevation tilt and is pointing approximately 20-30 degrees to the left of the target node (which is located on the tower, as shown in Figure 231). The location of the remote node is at the top of the cell tower therefore it has a higher elevation.

Figure 231: An example of V1000 installation



From V1000 CN's perspective, the reported beam angles are as follows:

- Tx Beam Azimuth Angle: +25.2 degrees
- Rx Beam Azimuth Angle: +25.2 degrees
- Tx Beam Elevation Angle: +14.3 degrees
- Rx Beam Elevation Angle: +14.3 degrees

Table 55 lists the fixed beam scan ranges for 60 GHz cnWave products.

Table 55: Fixed beam scan ranges

Product	Azimuth scan range	Elevation scan range
V1000	-45 degrees to +45 degrees	- 20 degrees to +20 degrees
V2000	-12 degrees to +12 degrees	-6 degrees to +4 degrees
V3000	-2.3 degrees to +2.3 degrees	-2 degrees to +1 degrees
V5000 (both sectors combined)	-140 degrees to +140 degrees	- 20 degrees to +20 degrees

The Tx/Rx x/Rx beam azimuth and elevation angle statistic help in:

- identifying links, which are operating near the boundary of the scan range, for example, within 5 degrees of +/- 140 degrees on a V5000. This implies that the link can be aligned off the edge of the sector and possibly requires the realignment.
- analysing whether interference affects the beam selection -
 - when the physical node alignment matches LINKPlanner but the beam angles are significantly out from what is predicted, and/or
 - when there is considerable variability in the beam angles used from linkup to linkup.
- determining whether signal obstruction, signal multipath, or interference causes an issue when there is a significant difference between the Tx and Rx beam angle for the same link at the same node.
- On a CN with only one wireless link to align, aiming at an azimuth beam angle close to 0 degrees is optimal.

Ethernet

The **Ethernet** page displays Transmitting and receiving data of the nodes.

Figure 232: The Ethernet page

60 GHz cnWave™ V5000

Disable E2E Controller Reboot admin

Statistics

Links Ethernet GPS Radio Performance Prefix Zones BGP

Download Statistics

Search

Aux Main SFP

Device Name	Device Model	Status	RX Packets	TX Packets	RX Bytes	TX Bytes	RX Errors	TX Errors	RX Dropped	TX Dropped	RX PPS	TX PPS	RX Throughput	TX Throughput
DN2@Po...	V5000	Down	0	0	0	0	0	0	0	0	0	0	0 kbps	0 kbps
Prim-PoP...	V5000	Down	0	0	0	0	0	0	0	0	0	0	0 kbps	0 kbps
DN1@Po...	V5000	10000 M...	1847	224256	86636	34573546	0	0	0	0	0	0	0 kbps	0 kbps
DN3@Po...	V5000	Down	0	0	0	0	0	0	0	0	0	0	0 kbps	0 kbps
DN4@Po...	V3000	Down	0	0	0	0	0	0	0	0	0	0	0 kbps	0 kbps

<< < 1 > >> 10

The following elements are displayed on the **Ethernet** page:

Table 56: Elements in the Ethernet page

Elements	Description
Device Name	Name of the device
Device Model	Model of the device.
Status	Status of Ethernet link
RX Packets	Receiver packets
TX Packets	Transmitter packets
RX Bytes	Receiver bytes
TX Bytes	Transmitter bytes
RX Errors	Receiver errors
TX Errors	Transmitter errors
RX Dropped	Receiver dropped
TX Dropped	Transmitter dropped
RX PPS	Receiver Packets Per Second
TX PPS	Transmitter Packets Per Second
RX Throughput	Receiver throughput
TX Throughput	Transmitter throughput

GPS

The **GPS** page displays geographical data of the nodes.

Figure 233: The GPS page

The following elements are displayed on the **GPS** page:

Table 57: Elements in the GPS page

Elements	Description
Device Name	Name of the device
MAC Address	MAC address of the device
Fix Type	GPS fix type. The fix status indicates the type of signal or technique being used by the GPS receiver to determine its location. The fix status is important for the GPS consumer, as it indicates the quality of the signal, or the accuracy and reliability of the location being reported.
Satellites tracked	The number of satellites tracked
Latitude	Latitude of the device
Longitude	Longitude of the device
Height	Height of the device

Radio

The **Radio** page displays the radio data of the nodes.

Figure 234: The Radio page

Device Name	MAC Address	Sync Mode	Channel	Security	Error Association	Channel Last State	RX Throughput	TX Throughput
DN2@PeP2@3009	12:04:56:88:30:09	GPS	1	PSK	0	0	2.77 kbps	2.88 kbps
DN2@PeP2@3009	22:04:56:88:30:09	GPS	3	PSK	0	0	7.58 kbps	10.80 kbps
Prim-PoP@3000_1	12:04:56:88:30:0c	GPS	3	PSK	0	0	12.49 kbps	12.29 kbps
Prim-PoP@3000_1	22:04:56:88:30:0c	GPS	1	PSK	0	0	24.69 kbps	12.99 kbps
DN1@PeP1@3000	12:04:56:88:30:00	GPS	1	PSK	0	0	10.22 kbps	21.82 kbps
DN1@PeP1@3000	22:04:56:88:30:00	GPS	4	PSK	0	0	16.47 kbps	5.40 kbps
DN3@PeP1@309D	12:04:56:88:30:9d	GPS	4	PSK	0	0	6.46 kbps	15.49 kbps
DN3@PeP1@309D	22:04:56:88:30:9d	GPS	1	PSK	0	0	11.03 kbps	4.64 kbps
DN4@PeP2@30f7	12:04:56:88:30:f7	GPS	1	PSK	0	0	6.83 kbps	5.58 kbps

The **Radio** page has the following elements:


Table 58: Elements in the Radio page

Elements	Description
Device Name	Name of the device
MAC Address	MAC address of the device
Sync Mode	<ul style="list-style-type: none"> • GPS sync: <ul style="list-style-type: none"> • <i>Entry condition:</i> Valid samples from GPS have been received for a few consecutive seconds (typically 2 seconds). • <i>Exit condition:</i> Valid samples from GPS have not been received for a few consecutive seconds (typically 10 seconds). • RF sync: Not in “GPS sync”, but is reachable to a DN with “GPS sync” over wireless links (1-2 hops away). <ul style="list-style-type: none"> • <i>Entry condition:</i> Conditions for “GPS sync” have not been met, but a link exists to at least one other DN from which to derive timing. • <i>Exit condition:</i> Conditions for “GPS sync” have not been met and no links to other DNs exist from which to derive timing. • No sync: Neither in GPS sync nor RF sync. This is the default state. <ul style="list-style-type: none"> • <i>Entry condition:</i> Conditions for “GPS sync” or “RF sync” are not met. • <i>Exit condition:</i> Condition for “GPS sync” or “RF sync” are met.
Channel	Operating channel
Security	Security type
Error Association	Error Association
Channel Last State	Channel Last State
RX Throughput	Receiver throughput
TX Throughput	Transmitter throughput

Performance

The **Performance** page displays the performance graph.

Figure 235: The Performance page




The **Performance** page contains the following graphs:

Table 59: Elements in the Performance page

Elements	Description
RSSI	Receiver Signal Strength Indicator. It is a measurement of the power present in a received radio signal
Transmit Power	Transmitting power
SNR	Signal to Noise Ratio
MCS Index	Modulation and Coding Scheme (MCS) Index Values can be used to determine the likely data rate of your wireless connection. The MCS value essentially summarizes the number of spatial streams, the modulation type and the coding rate that is possible when connecting your wireless access point.
Packet Error Ratio	Packet error ratio. It is the ratio, in percent, of the number of Test Packets not successfully received by the node to the number of Test Packets sent to the node by the test set.
Received Frames	The number of frames received at the node.
Transferred Frames	The number of frames transferred from the node.


RSSI graph

Figure 236: RSSI graph




Transmit Power graph

Figure 237: Transmit Power graph




SNR graph

Figure 238: SNR graph




MCS Index graph

Figure 239: MCS Index graph




Packet Error Ratio graph

Figure 240: Packet Error Ratio graph



Received Frames graph

Figure 241: Received Frames graph




Transferred Frames graph

Figure 242: Transferred Frames graph



Prefix zone Statistics


In the multi-PoP deployments, the mesh is divided into prefix zones. Prefix zone statistics are available on the **Statistics > Prefix Zone** page.



Note

You can view the prefix zone statistics only when Deterministic prefix (DPA) is enabled. With CPA enabled, the **Prefix Zone** tab is not visible on the **Statistics** page.

Figure 243: The Prefix Zones page




Border Gateway Protocol (BGP)

The BGP is the protocol used throughout the Internet to exchange routing information between networks. It is the language spoken by routers on the Internet to determine how packets can be sent from one router to another to reach their final destination. BGP has worked extremely well and continues to be protocol that makes the Internet work.

The **BGP** page displays routing information. This page also contains the details of routes advertised by PoPs to their peers and the routes received by the peers.


Figure 244: The BGP page



Maps

The **Maps** page displays the topology and location/sites of the deployed nodes in the cnWave network. Click the **Maps** icon on the left panel to display the nodes.

Figure 245: The Map page



Interference Scan

Interference Scan (also known as Interference Management (IM) Scan) is an end-to-end, Controller-coordinated scan that aims at performing real-time measurements of interference affecting a specific interfered link (referred to as the victim link). The Controller filters the network topology to identify potential interfering links (known as aggressor links).

The Controller then issues batches of scan requests to the filtered aggressor nodes or sectors. These requests are transmitted using the antenna beams and transmit power intended for their data links. Meanwhile, the victim receiver listens for these scan requests (transmissions). The extent to which the victim receiver detects these scan requests determines the level of interference exerted by the aggressor links on the victim receiver.

This section covers the following topics:

- [Output of Interference Scan](#)
- [formance](#)
- [Running the Interference Scan tool in cnMaestro](#)

Output of Interference Scan

Using the cnMaestro UI, you can run the Interference Scan tool. The scan results show the victim link and its corresponding receiver MAC address (which serves as a unique identifier for the network devices).

It also provides a list of aggressor links along with their corresponding Signal-to-Noise Ratio (SNR) values relative to the victim receiver. SNR indicates the measurement of a signal strength compared to background noise, with higher values indicating better signal quality.

Impact on link performance

The interference from aggressor links impacts the maximum data rate that the victim link can achieve, determined by the Modulation and Coding Scheme (MCS). For instance, achieving MCS9 requires an SNR of at least 10 dB. However, if interference from an aggressor link reduces the SNR to 6 dB, the victim link will be limited to MCS4 or lower, resulting in slower data rates.

If the SNR is less than 0 dB, the interference is minimal and the aggressor links are unlikely to impact the victim link's performance.

Running the Interference Scan tool in cnMaestro

You can run the Interference Scan tool using the **Map** page in cnMaestro UI only.



Note


cnMaestro 5.2.0 and later versions support the UI controls for running the Interference Scan X feature (tool).

To run the Interference Scan tool, complete the following steps:

1. Log in to the cnMaestro UI and navigate to the **Map > Networks** page.
2. Select a cnWave network and click on the link for which you want to run the interference Scan tool.

The **Details** section on the right side of the **Map** page displays the selected link information. For example, there is a Backup-POP_V5K linked to V5K-DN2 in the figure below.


Figure 246: Selecting a link to run the Interference Scan tool



3. Click the ... icon next to the link name and select **Interference Scan X** from the drop-down list.


For example, Interference Scan is used for the link highlighted between Backup-POP_V5K linked to V5K-DN2 in the figure below.

Figure 247: Selecting the Interference Scan X tool



When **Interference Scan X** is selected, the **Interference Scan** section appears with the victim node names on the right side of the Map page.


Figure 248: The **Interference Scan** section on the Map page



4. Select the required victim node and click **Start**.

The Interference Scan tool detects neighbouring interfering links with wireless settings that may affect your network. The Interference Scan tool can be executed on any of the victim nodes. In the figure below, Interference Scan is executed on the first victim node *Backup-POP_V5K*. If no aggressor is found, a message appears stating that **no interference found**.

Figure 249: When no aggressors are found




When you run the Interference Scan test on the second victim node (for example, V5K-DN2), the aggressor (if any) details are displayed as shown in the figure below. In this case, Backup-POP_V5K to V5K-DN2 uses channel 1 and V5K-DN2 to V5K-DN1 uses channel 1. The SNR values need to be analysed.



Note

The cnMaestro UI displays both a map view and a list view of the victim-aggressor relationship. The map is color-coded to show the severity of interference. The lower the SNR from aggressor links, the greater the interference on the victim link.

Figure 250: When aggressors are found



5. View the scan result for the selected victim node and take appropriate actions.

Tools


The **Tools** page contains the following tabs:

- [Factory Reset](#)
- [Field Diags](#)
- [Antenna Alignment](#)
- [Remote Command](#)
- [Ping](#)
- [Quick PTP Setup](#)
- [iPerf](#)

Factory reset

The **Factory Reset** page is used to set the default settings.

Figure 251: The Factory Reset page




Warning

Factory reset is followed immediately by a system reboot. You must carefully configure the factory reset settings as the device comes up with the default settings. All the existing configurations are lost when the system comes up.

Field diags


The **Field Diags** tab is used to view and download the error logs. To download the DN logs, select the DN node from the **Select Node** drop-down and click **Download Logs** (as shown in Figure 252).

Figure 252: The Field Diags page



To download the logs for a self-node, click **Download Logs** at the bottom of the page. Save the log file.

Figure 253: Saving log files



Antenna alignment

The Antenna Alignment tool assists in optimizing the alignment of V3000 to V3000, V5000, V2000, or V1000. This feature helps you to install and align the devices to achieve optimal performance.



Warning

The antenna alignment tool is not a substitute for optical alignment. The optical alignment is the key for getting the signal within the +/-2 degree azimuth and +/-1 degree Elevation window. At this window level, the tool can be used to get away from the edge, corner or spurious beams to ensure optimal alignment.

Prerequisite tasks:

- Complete a Link Plan with Link Planner from Cambium Networks. This prerequisite task provides the information on the RSSI expected for the PTP link. This must be used as a target while using the antenna alignment feature.
- Enter the PTP topology in cnMaestro or the UI of a device (with the Onboard Controller on it). Then, perform the following steps:
 - Create two Sites and nodes.
 - Set up the wireless link between the two nodes.
- Ensure that the nodes are already mounted at the sites.
- An installer must have access to the UI of the device.



Note

When the antenna alignment test is executed between the following devices, ensure that GPS is disabled at the CN side:

- V3000 PoP and V1000 CN
- V3000 PoP and V2000 CN

- V3000 PoP and V3000 CN


Using the Antenna Alignment tool

To use the Antenna Alignment tool, perform the following steps:

1. From the home page of the device UI, navigate to **Tools > Antenna Alignment**.

The Antenna Alignment page appears, as shown in [Figure 254](#).

[Figure 254](#): The Antenna Alignment page




Note

If the alignment is initiated from a CN, ensure that the operating channel is set on the radio (before alignment). If the channel is not set, you must set the required channel in the **Configuration** page of the V3000 single node UI.

2. Click the **Start Alignment** button located at the top left side of the Antenna Alignment page.

The **Confirm** message box appears (as shown in [Figure 255](#)), indicating that the link will be disrupted. For running the antenna alignment tool, the auto ignition needs to be disabled. If a link has been established already, it is disassociated at this level.

Figure 255: The Confirm message box in the Antenna Alignment page



3. In the **Confirm** message box, click **Continue** to start the antenna alignment process.

The antenna alignment process begins.




Note

If the alignment is initiated from a device (which is not running with Onboard Controller), perform the following actions:

- a. Disable the ignition of the link at the Controller.
- b. Send Dis-assoc for the link from the Controller.
- c. When the alignment starts, select the required node from the **Remote Node Model** drop-down list.

The **Time Frame** section populates the RSSI time series as shown in [Figure 256](#).

Figure 256: The RSSI time series



The following details explain about the RSSI time series that populates in the Antenna Alignment page:

- The **Local Node** section (located at the left side of the Antenna Alignment page) displays the direction of arrival angle with respect to the local (PoP) device.
- The **Remote Node** section (located at the right side of the Antenna Alignment page) displays the direction of arrival angle with respect to the remote device.
- In **Local Node** and **Remote Node** sections, a cell marks the direction of arrival. The color of the cell represents the RSSI based on the heatmap scale given on the left side.
- The **Time Frame** section (located at the bottom of the Antenna Alignment page) displays the RSSI time series, along with the peak RSSI time and the latest data point (on the right end of the plot).

The RSSI time series and the heatmap plots get updated every six seconds. This is due to the processing time taken for a complete sweep of all the combinations of beams and channels.

During the alignment phase, the transmit power used is the maximum configured power and the transmit power control is disabled.




Note

If the installer has enabled the short-range installation in the radio configuration, the transmit power control is set to the minimum configured power.

4. Adjust the optimal RSSI that must be reached when the beams are close to the central region, as shown in Figure 257.

Figure 257: The optional RSSI alignment



The RSSI time series must be close to the Link planner's predicted RSSI (the receive level when aligning, as shown in Figure 258), with an error of +/-5dB. Consider the following points when adjusting the optional RSSI:

- If the time series reporting RSSI is more than 10dB from that of the Link Planner's expected RSSI, then the device has been aligned incorrectly and is being picked up by the sidelobes or spurious beams.
- If a cell is highlighted and the time series reporting RSSI is more than 10dB off the expected RSSI, then it is necessary to sweep beyond the current position of both azimuth and elevation, in turn to ride past the sidelobes.


Figure 258: An example of the receive level when aligning - Link planner

Radio Commissioning Notes for CN	
Model	V3000
Maximum EIRP	60 dBm
Minimum MCS	MCS 2
Maximum MCS	MCS12 (16QAM 0.75 Sngl)
Channel	64.80 GHz (Channel 4)
Polarity	Auto
Predicted Receive Power	-46 dBm \pm 5 dB while aligning
Operational EIRP	46 dBm
Operational Receive Power	-60 dBm \pm 5 dB
Predicted Link Loss	116.25 dB \pm 5.00 dB

5. Make use of the direction of arrival information (if there is any elevation or azimuth mismatch) to physically align the radio antennas.


- When there is an elevation mismatch (as shown in [Figure 259](#)):

[Figure 259](#): Example of the elevation mismatch




In [Figure 259](#), the angles are exaggerated to show the point. In this example, consider that the radio has been misaligned by a down-tilt of 2 degrees behind the unit (from an installer's view side). This means that the angle of the beam selected might be in the +2 degrees direction in the elevation due to beamforming. The aim is to get the optimal boresight beam. Therefore, the radio must be up tilted in the elevation direction by 2 degrees. The selected beam is now closer to the boresight beam, as shown in [Figure 260](#).

[Figure 260](#): On correcting the elevation mismatch




- When there is an azimuth mismatch (as shown in [Figure 261](#)):

[Figure 261](#): Example of the azimuth mismatch



In [Figure 261](#), the angles are exaggerated to show the point. In this example, consider that the radio has been misaligned in azimuth by 2 degrees to the right behind the unit (from an installer's view side). This means that the angle of the beam selected might be in the -2 degrees direction due to beamforming. The aim is to get the optimal boresight beam. Therefore, the radio must be tilted in the azimuthal direction to the left by 2 degrees. The selected beam is now closer to the boresight beam, as shown in [Figure 262](#).

[Figure 262](#): On correcting the azimuth mismatch




6. When you achieve the desired alignment and RSSI, click the **End Alignment** button located at the top left side of the Antenna Alignment page.

If you do not click the **End Alignment** button, the alignment cycle ends automatically after 15 minutes. When the alignment cycle ends, the ignition state (disabled earlier) is enabled to auto ignition and the link is established.

[Figure 263](#) shows how the Antenna Alignment dashboard page looks on completing the antenna alignment task.

Figure 263: The updated Antenna Alignment dashboard page



Remote Command

The **Remote Command** tool page supports the following commands:

- [Show SFP power details](#)
- [Show ipv4 neighbors](#)
- [Show ipv6 neighbors](#)
- [Show Wired Interface State Changes](#)

Show SFP power details

The **Show SFP Power Details** command is available on the **Tools** page. When you execute this remote command from the Onboard Controller UI or the node CLI, the command provides the SFP power details (as an output) for the required SFP ports and interfaces.



Note

Currently, the **Show SFP Power Details** remote command is not available in cnMaestro.


To execute the **Show SFP Power Details** remote command, perform the following steps:

1. From the home page of the device UI, navigate to **Tools > Remote Command**.
The **Remote Command** page appears.
2. Select the required node from the **Select Node** drop-down list.
3. Select **Show SFP Power Details** from the **Select Command** drop-down list.

4. Click **Execute**.

The **Output** section displays the SFP power details for the selected node, as shown in [Figure 264](#).

Figure 264: The UI supported output - SFP Power details



[Table 60](#) lists and describes each parameter in the output.

Table 60: Output details

Output Parameter	Description
Status	<p>Determines whether the output is valid.</p> <p>If the Status field contains OK, it implies that the rest of the output is valid.</p> <p>If the Status field does not contain OK, it implies that only the Status field is valid. In such cases, the Status field provides the reason for not being able to read the laser powers.</p>
CalibrationType	<p>Indicates the measurement type that is calibrated over the criteria, such as the following (for example):</p> <ul style="list-style-type: none"> Specified transceiver temperature, Transceiver supply voltage, TX output power, and RX received optical power. <p>The value of this parameter is Internal.</p>
Units	<p>Indicates the unit of measurement.</p> <p>The value of this parameter is micro-watts (mW).</p>
txPwr	Indicates the TX output power in mW.
rxPwr	Indicates the RX received optical power in mW.

Output Parameter	Description
rxPwrMeasType	Indicates whether the received power measurement represents an average input optical power. The value of this parameter is Average.
txPwr_dBm	Indicates the TX output power in dBm.
rxPwr_dBm	Indicates the RX received optical power in dBm.

5. To download the output, click the download icon located at the top left side of the **Remote Command** page.

You can also execute the **Show SFP Power Details** command by using the device CLI. Log on to the device and open the CLI. At the command prompt, provide the `Show SFP` value and hit **Enter** on your keyboard. The command displays the output, as shown in [Figure 265](#).

Figure 265: The CLI supported output - SFP Power details

```
CLISH>show sfp
{
  "status": "OK",
  "calibrationType": "Internal",
  "units": "micro-watts",
  "txPwr": 564.3,
  "rxPwr": 557.1,
  "rxPwrMeasType": "Average",
  "txPwr_dBm": -2.485,
  "rxPwr_dBm": -2.541
}
CLISH>
```

Show ipv4 neighbors

The **Show ipv4 neighbors** remote command reveals the Address Resolution Protocol (ARP) table for IPv4 addresses in the network. The ARP table, also known as the neighbour table for IPv4, links IP addresses to MAC addresses for devices within the same local network.


When you execute the **Show ipv4 neighbors** command using the **Tools > Remote Command** page, you can view information of the active IPv4 neighbours in the output. In addition, the output information can also aid in identifying potential network anomalies or connectivity issues.

To execute the **Show ipv4 neighbors** command, perform the following steps:

1. On the **Tools > Remote Command** Page, select the required node from the **Select Node** drop-down list.
2. Select **Show ipv4 neighbors** from the **Select Command** drop-down list.
3. Click **Execute**.

The **Output** section displays the IPv4 neighbor details for the selected PoP or CN, as shown in [Figure 266](#).

Figure 266: The Show ipv4 neighbors command output



You can use the  icon to download the output (in .txt format).


Show ipv6 neighbors


The **Show ipv6 neighbors** remote command displays the neighbour table for IPv6 addresses, analogous to the IPv4 ARP table but for IPv6 addresses. As the adoption of IPv6 continues to rise, the visibility into these connections becomes more critical.

When you run the **Show ipv6 neighbors** command from the **Tools > Remote Command** page, the command unveils the relationship between IPv6 addresses and MAC addresses within a local network. In addition, the command enables effective monitoring and troubleshooting of IPv6 network issues.

On selecting the required node from the **Select Node** drop-down list and **Show ipv6 neighbors** from the **Select Command** drop-down list, click **Execute**. The **Output** section displays the IPv6 neighbor details for the selected node, as shown in Figure 267.

Figure 267: The Show ipv6 neighbors command output



To download the output (in .txt format), use the  icon.

Show Wired Interface State Changes

The **Show Wired Interface State Changes** remote command displays up or down events on wired interfaces. This command is useful for debugging and troubleshooting network events.


This remote command enables network administrators to identify and analyze Ethernet port state changes, and provides insights into network events such as connection issues or device status changes.

To execute the **Show Wired Interface State Changes** command, perform the following steps:

1. On the **Tools > Remote Command** Page, select the required node from the **Select Node** drop-down list.
2. Select **Show Wired Interface State Changes** from the **Select Command** drop-down list.
3. Click **Execute**.

The **Output** section displays the up or down events for the selected criteria, as shown in [Figure 268](#).

Figure 268: The Show Wired Interface State Changes output



To download the output, use the  icon.

Ping

The **Ping** tool provides information that is used to identify the reachability between the required node and another node or destination (for IPv4 and IPv6). The ping tool is useful in troubleshooting radio links.

To use the ping tool, perform the following steps:

1. From the home page of the device UI, navigate to **Tools > Ping**.

The **Ping** page appears.

2. Set the parameters with the required values, as described in [Table 61](#).

Table 61: List of parameters in the Ping page

Parameter	Description
Source Node	<p>The source node for which you want to find the reachability with another node or destination.</p> <p>Select the required source node from the drop-down list.</p>
Destination Type	<p>The required node or destination address (IPv4 or IPv6) that for which the reachability has to be identified.</p> <p>Following options are supported:</p> <ul style="list-style-type: none"> • Node • IPv4

Parameter	Description
	<ul style="list-style-type: none"> IPv6 Select the required option (mandatory).
Number of Packets (-c)	Number of times that a packet is transmitted to find the reachability. Default value: 3 This parameter supports values between 1 (minimum) and 10 (maximum). Type an appropriate value in the text box.
Buffer Size (-s)	Size (in bytes) of the packet. Default value: 56 This parameter supports values between 1 (minimum) and 65507 (maximum). Type an appropriate value in the text box.

3. Click **Start Ping**.

The **Ping Result** section displays the information for the selected criteria, as shown in [Figure 269](#).

Figure 269: *The Ping page*

60 GHz cnWave™ v5000

Tools

Factory Reset Field Diags Antenna Alignment Remote Command Ping Quick PTP Setup

Source Node
PoP1@300c

Destination Type
☒ Node ☐ IPv4 ☐ IPv6

DN1@3000

Number Of Packets (-c)
3
Min = 1, Max = 10


Buffer Size (-s)
56
Min = 1, Max = 65507

Start Ping

Ping Result

PING 2020:1122:2222:2202::1(2020:1122:2222:2202::1) 56 data bytes
64 bytes from 2020:1122:2222:2202::1: icmp_seq=1 ttl=64 time=6.78 ms
64 bytes from 2020:1122:2222:2202::1: icmp_seq=2 ttl=64 time=5.20 ms
64 bytes from 2020:1122:2222:2202::1: icmp_seq=3 ttl=64 time=3.52 ms

--- 2020:1122:2222:2202::1 ping statistics ---
3 packets transmitted, 3 received, 0% packet loss, time 2003ms
rtt min/avg/max/mdev = 3.515/5.163/6.776/1.331 ms
CNPDI FTFD

You can use the  icon to download the ping result.

Quick PTP setup

Quick PTP Setup is a simple user-friendly tool used for quickly creating a PTP link between the PoP and the CN. This option eliminates the long process of creating a PTP link with Onboard Controller in the **Topology** UI page.



Note

The Quick PTP Setup option is supported only on V1000, V2000, and V3000 products.

With the **Quick PTP Setup** option, you can skip the long process of creating a PTP link that involves the following actions:

1. Enabling Onboard Controller on the required node that can also act as a PoP node.
2. Adding a site for the CN node.
3. Adding a node for the CN node.
4. Creating a link between the PoP and the CN nodes.

The **Quick PTP Setup** option enables you to create the PTP link using the simple process on the **Tools** page of the device UI.

To create the PTP link quickly for the required nodes, perform the following steps:

1. Navigate to **Tools > Quick PTP Setup** from the home page of device UI.

The **Quick PTP Setup** page appears, as shown in [Figure 270](#).

Figure 270: The Quick PTP Setup tab on the Tools page

Tools

Factory Reset Field Diags Antenna Alignment Remote Command Ping Quick PTP Setup

CN MAC Address

Missing mandatory field.

Please input the remote CN MAC address and click start to automatically create a new topology and establish the wireless link. The previous topology will be removed.

Start PTP SetUp

2. In the **CN MAC Address** text box, enter the MAC address of the required CN node (which is connected).



Note

You can also access the MAC address of the connected CN in the **Device Information** section of the main **Dashboard** page (of the device UI).

3. Click **Start PTP Setup**.

This action creates the PTP link between the PoP and the CN nodes, quickly.

When you configure **Quick PTP Setup**, the unit turns to a DN running E2E Controller with Layer 2, and default IPv4 address of 169.256.1.1. When the client onboards, E2E Controller pushes the configuration to a CN with the IPv4 address of 169.254.1.2.

You can view the connected PoP and CN details on the **Topology** page of the device UI.

iPerf

The **iPerf** tool is a user-friendly tool for conducting network performance tests using the device UI. The tool makes network performance testing more accessible and manageable. It helps you with tools required for effective measuring

and understanding the network's performance.

The iPerf tool is built around the widely recognized iPerf testing tool (open source) and provides a graphical UI for conducting the network performance tests with ease.

The following are the features of the iPerf tool:

- **Server Node and Client Node selection:** The iPerf tool allows you to easily select the server and client nodes for your network performance tests. The node selection sets up the endpoints required for the test. In addition, the test traffic is unidirectional, flowing from the client to the server.
- **Time and Parallel Streams selection:** You can specify the time in seconds to customize the duration of the tests. You can also select the number of parallel streams to run during the test, providing more granular control over the testing parameters.
- **TCP, IPv6 Layer 3 Traffic Profile:** Network performance tests are conducted using a TCP, IPv6 Layer 3 traffic profile. The iPerf tool internally handles the selection and implementation of the traffic profile, and simplifies the test process.
- **Network performance profiling:** The iPerf tool allows you to profile the performance of your network on a link-by-link basis. This tool is instrumental in identifying performance blockers and optimizing network performance.
- **Coexisting with customer data:** The iPerf tool tests traffic that competes with customer data, rather than blocks or stops. There is no prioritization given to either data, ensuring that the test results reflect real-world network conditions.
- **Complete iPerf output display:** On conducting the network performance test, you can view the entire iPerf output in a dedicated panel on the **Tools > iPerf** page. This tool offers an easy and a convenient way to interpret the results (within the interface).



Note

The throughput, measured by the iPerf tool, must only be used as a guideline. Using traffic testing software onboard the radio carries additional processing overheads, which are not present in the normal operation.

To use the **iPerf** tool, perform the following steps:

1. From the homepage of the device UI, navigate to **Tools > iPerf**.

The **iPerf** page appears.

2. Set the values for the parameters, as described in [Table 62](#).

Table 62: Parameters required for running the iPerf tool

Parameter	Description
Server Node	<p>The server node for which you want to conduct the network performance test.</p> <p>Select the required server node from the drop-down list.</p> <p>Note: You can use the ↔ icon to reverse the server and client node names.</p>
Client Node	<p>The client node for which you want to conduct the network performance test.</p> <p>Select the required client node from the drop-down list.</p>

Parameter	Description
	Note: You can use the ↔ icon to reverse the server and client node names.
Duration (Seconds)	<p>Period (in seconds) that you want to set for the test.</p> <p>Type an appropriate value (in seconds) in the text box.</p> <p>Default value: 10 seconds</p> <p>Note: This parameter supports values from 1 to 300 (in seconds).</p>
Parallel Streams	<p>Number of parallel streams that you want to run during the test.</p> <p>Default value: 4</p> <p>Type the required value in the text box.</p> <p>Note: This parameter supports values from 1 to 4.</p>

3. Click **Start iPerf**.

The **Server Node Results** section and the **Client Node Results** section display the results for the selected criteria, as shown in [Figure 271](#).

Figure 271: The iPerf tool page

The screenshot shows the iPerf tool page in the cnMaestro interface. The top navigation bar includes 'Tools', 'Factory Reset', 'Field Diags', 'Remote Command', 'Ping', and 'iPerf'. The configuration section on the left includes fields for 'Server Node' (node-V5000-886d3d), 'Client Node' (v2k_cn), 'Duration (Seconds)' (10), and 'Parallel Streams' (4). The 'Start iPerf' button is highlighted. Below the configuration, the 'Server Node Result: node-V5000-886d3d' and 'Client Node Result: v2k_cn' sections display detailed test results in a table format. Both sections include a download icon (a square with a downward arrow) next to the result header.

To download the server and client node results (in .txt format), use the ↓ icon on the **iPerf** page.


cnMaestro support for Onboard Controller

The Onboard E2E controller can be managed by cnMaestro 2.5.0 (On-Premises) for network management.

1. After the Onboard E2E controller is enabled from UI, enter the cnMaestro URL. If **Cambium ID based authentication** option is enabled in cnMaestro, then enter the Cambium ID and onboarding key.


2. Click **Enable E2E** on **Onboard E2E Controller** in UI.

Figure 272: The Onboard E2E Controller page




3. Enter the cnMaestro management configuration information.
 - Remote Management - Select the required remote management option
 - cnMaestro URL - cnMaestro address
 - Cambium ID - Cambium ID of the device
 - Onboarding key - Password to onboard the device

Figure 273: The cnMaestro section




4. Click **Enable**.
5. A new E2E Network appears in cnMaestro. Click **Approve** to manage it.

Figure 274: Information on the new E2E network




6. The **Network Onboard** window appears and provides an option to edit the network name.
7. Click **Save**.

Figure 275: The 60 GHz cnWave - Network Onboard



After the successful onboarding of the E2E Network, it can be managed through cnMaestro.


Figure 276: The Onboard 60 GHz cnWave E2E dashboard page



Backup CN link


If a link between Pop or DN and CN gets disconnected, then a backup CN link (if enabled using the cnMaestro UI) provides connectivity from PoP or DN to a particular CN. CNs can form only one link but additional backup links can be provided for use when the primary link is unavailable (for at least 300 seconds).

To add and enable the backup CN link, perform the following actions:

1. From the landing page of the device UI, navigate to Networks > required link name and select the  icon.

A drop-down list appears with multiple options, as shown in Figure 277.

Figure 277: The drop-down list with the Add Link option



2. From the drop-down list, select **Add Link** as shown in Figure 277.

The **Add Link** page appears with the **Backup CN Link** checkbox, as shown in Figure 278.

Figure 278: The Backup CN Link checkbox


A screenshot of the 'Add Link' form. The form has a title bar 'Add Link' with a close button (X). Below the title bar, there is a 'Link Type' section with two radio buttons: 'Wireless' (selected) and 'Wired'. Below this, there are four dropdown menus arranged in two rows. The first row has 'A-Node' (selected 'CN-83') and 'A-Node Sector' (selected 'Sector 1 (12:04:56:88:31:83)'). The second row has 'Z-Node' (selected 'DN-39') and 'Z-Node Sector' (empty). At the bottom of the form, there is a checkbox labeled 'Backup CN Link' which is checked, followed by an information icon (i).

You must configure the required node-specific parameters, such as A-Node, A-Node Sector, and Z-Node, before enabling the backup CN link.

3. Select the **Backup CN Link** checkbox.

On the **Maps** page, backup CN links are shown in a dash line format (as shown in [Figure 279](#)).

[Figure 279](#): Representation of the backup CN links on the Maps page



Auto Manage IPv6 Routes (External E2E Controller)

E2E Controller communicates with all nodes over IPv6. PoP nodes use IPv6 address of the statically configured interface to communicate with E2E Controller. CNs and DNs use the IPv6 address derived from Seed Prefix.



Note

The **Auto Manage Routes** feature requires cnMaestro 3.0.4.

The **Auto Manage Routes** feature adds and manages the IPv6 routes at E2E Controller. These IPv6 routes are required for routing the IPv6 packets to CNs and DNs.

The feature is applicable only when PoP and E2E Controller are in the same subnet.


Single PoP network

When the feature is disabled, you must add the IPv6 route by performing the following steps:

1. From the landing page of the device UI, navigate to **Tools > Settings > IPv6 Routes > Add new**.

The Add Route page appears, as shown in the [Figure 280](#).

Figure 280: The Add Route page in the cnMaestro UI

A modal dialog box titled "Add Route" with a close button (X) in the top right corner. It contains two text input fields. The first field is labeled "Destination" and contains the text "2001:470:c31b:200::/56". The second field is labeled "Gateway" and contains the text "2403:0:529:d:a00:27ff:fe01:2121". At the bottom of the dialog are two buttons: "Add" (highlighted with a blue border) and "Cancel".

2. Type the seed prefix value in the **Destination** text box.
3. Type the required PoP's interface IP address in the **Gateway** text box.
4. Click **Add**.


The IPv6 route is added.

When the feature is enabled, all the above steps (described from step 1 to step 5 in this section) are not required and IPV6 routes are added automatically.

5. Select the **Auto Manage Routes** check box in the IPv6 Routes page.

Figure 281 shows the location of the **Auto Manage Routes** check box in the IPv6 Routes page.

Figure 281: The Auto Manage Routes check box

A screenshot of the "Tools" section in the cnMaestro UI, specifically the "IPv6 Routes" settings page. The page has a top navigation bar with links: Dashboard, Notifications, Configuration, Links, Statistics, Report X, Software Update, Map, and Tools (active). Below this is a sub-navigation bar with links: Operations, Diagnostics, Debug, Remote Command, Services, and Settings (active). The main content area is titled "Network Configuration" and includes a text input for "E2E Controller IPv6 Address (eth1)" with the value "2001:3001::100/64". Below this is a warning message: "Changing IPv6 Address will disconnect all the nodes. E2E Controller Address configured in the PoP nodes should match." Under the "IPv6 Routes" section, there is a checkbox labeled "Auto Manage Routes" which is checked and highlighted with a red box. To the right of the checkbox is a small 'X' icon. Below the checkbox is a descriptive text: "Automated IPv6 Routes to DNS and CNs based on topology and PoP nodes status. Applicable only if PoP nodes and E2E Controller are in same Network/Prefix length."

Multi-PoP network

In a multi-PoP network, the **Auto Manage Routes** feature allows you to avoid a BGP v6 router under the following conditions:

- When the Layer 2 bridge is enabled (which implies that the BGP v6 router is not required for managing data traffic).
- When PoPs and E2E Controller are in the same subnet or L2 broadcast domain.

In a multi-PoP network, Deterministic Prefix Allocation (DPA) is used. The mesh gets divided into zones. Each PoP is the best gateway to reach nodes in its zone. When a PoP is down, a different alive PoP must be used as a gateway to reach zones. When the **Auto Manage Routes** feature is enabled, it performs the following functions in a multi-PoP network:

- Understands the network topology of 60 GHz cnWave,
- Keeps a track of aliveness of PoPs, and
- Dynamically builds and manages the routing table.

Figure 282 is an example of an IPv6 route table that is built automatically by the feature for a four PoP network.

Figure 282: Example of IPv6 route entries in the IPv6 Routes page





Figure 283 shows how the cnMaestro dashboard diagrammatically displays the routes taken by E2E Controller and the traffic controlled by cnWave nodes.

Figure 283: Diagrammatic representation of IPv6 routes and traffic control



Unconnected PoPs

In a multi-PoP network, PoPs must be able to exchange openR packets either on wired or wireless path. Otherwise, DNs might not receive the IPv6 address allocation and might not onboard to E2E Controller. This is observed when Controller sends the Prefix Allocation message to one of the PoPs and expects the message to reach other PoPs through openR.

In some cases, PoPs might be isolated temporarily, especially while building the network. [Figure 284](#) is an example that shows two unconnected zones.

Figure 284: *Unconnected zones due to isolated PoPs*



To facilitate such a scenario, a new configuration parameter **flags.enable_pop_prefix_broadcast** has been introduced in this release. This parameter supports the following Boolean values:

- **true** - When the value of this parameter is set to true, E2E Controller sends the prefix allocation message to all PoPs individually.
- **false** - When the value of this parameter is set to false, E2E Controller sends the prefix allocation message to one of the PoPs.

The default value of this parameter is false (default setting).



Note

You must set this parameter's flag to false when there is a wired or wireless path between PoPs.


You can modify the **flags.enable_pop_prefix_broadcast** parameter in the UI of 60 GHz cnWave.

To configure the parameter, perform the following steps:

1. From the landing page of the device UI, navigate to **Configuration > E2E Controller**.

The E2E Controller page appears. The **flags.enable_pop_prefix_broadcast** parameter is available on the E2E Controller page, as shown in [Figure 285](#).

Figure 285: The `flags.enable_pop_prefix_broadcast` parameter



2. Modify the value of the parameter.
3. Click **Save** to save the configuration changes.

High Availability (HA) support for Onboard E2E Controller

You can configure the high availability (HA) support for Onboard E2E Controller.

Using cnMaestro, you can enable and configure HA support in a Multi-PoP Onboard E2E Controller that is running 60 GHz cnWave devices in a mesh network. This HA support configuration allows you to configure a primary (active mode) and a backup or secondary (passive mode) E2E Controller from cnMaestro.

If the active primary E2E Controller, with HA enabled and functioning, goes down, then the backup E2E Controller is active and manages the 60 GHz cnWave devices. All the devices report to the backup E2E Controller until the primary E2E Controller comes back.

This topic covers the following sections:

- [Theory of operation](#)
- [Configuring HA support using cnMaestro](#)
- [Caveats of HA configuration](#)

Theory of operation

E2E Controllers use the high-availability protocol (primary-backup) and support the HA configuration. In such a primary-backup setup, two controllers (peers) run on separate PoP nodes and are designated as either *primary* or *backup*. If the primary controller catastrophically fails (for example, power outage, network failure, hardware failure), the backup controller assumes control of the cnWave 60 GHz network.

The HA configuration supports the following operational mechanisms for Onboard E2E Controller:

1. **Role designation:** At setup, one controller is statically designated as primary, and the other as backup. This designation determines their initial operational roles during network management.
2. **Initial state:** The primary controller starts in an active state, overseeing network configuration and collecting network statistics. The backup controller remains in a passive state, prepared to assume control if needed.
3. **Health monitoring:** Both primary and backup controllers monitor each other's status through regular heartbeat messages, sent every five seconds. These messages are crucial for detecting any disruptions or failures in the primary (active) controller.

4. **Data synchronization:** Both primary and backup controllers periodically synchronize topology and configuration data. This synchronization is key to enabling a fast and seamless transition from passive to active state, ensuring the backup controller can immediately manage the network with up-to-date settings and configurations.
5. **Failover process:** If the primary (active) controller fails, detected by a loss of heartbeat messages for 20 seconds, the backup controller automatically transitions from passive to active. This change ensures continuous network management without manual intervention.
6. **Recovery and Reversion:** After the failed primary controller is repaired and comes back online, it starts in a passive state. It remains in this passive state until it has successfully exchanged heartbeat messages for 150 seconds, ensuring stability. Following this period, a role reversal occurs where the primary controller transitions back to active and the backup controller reverts to passive.

Configuring HA support using cnMaestro



Note

The HA support is applicable only to cnMaestro X accounts. Consider the following key points:


- The Onboard E2E Controller must be managed using cnMaestro.
- The Onboard network must have at least two PoP nodes to enable HA.
- The two PoP nodes are selected to host Primary. The backup controllers should be able to communicate over wire/ethernet.
- For HA, all the DN/CN nodes in network are expected to have a route to report to both the HA peers.
- The HA feature is supported in a network when devices are running software version 1.4 or later version.

To enable HA support for E2E Controller, complete the following steps:

1. From the Home page of cnMaestro, navigate to **Monitor and Manage > E2E Network > Configuration > High Availability X**.

The **Enable High Availability** checkbox appears.


Figure 286: The *Enable High Availability* check box - cnMaestro UI



2. To enable HA support for E2E Controller, select the **Enable High Availability** checkbox.

The **High Availability X** page displays options to configure the backup Controller.

Figure 287: The HA support configuration options



By default, the current Onboard Controller is selected as the primary controller.

- From the **Backup E2E Controller** drop-down list, select the required node that is connected to the complete network.


You can check the IP addresses (read only) of primary and backup controllers.

- Click **Save** to apply the changes.
- When you configure the HA support, ensure to check the **HA Status** parameter.

The **HA Status** parameter must display the green button, indicating that the HA support is functioning and data is in sync. If **HA Status** displays the red button, then it indicates that the HA support is not functioning.

You can also view the HA status in the **High Availability X** section on the **Dashboard** page.

Figure 288: Viewing the HA status on the Dashboard page - cnMaestro UI



The **Primary** field displays the primary node name. The **Backup** field displays the backup node name. Green bullets in **Primary** and **Backup** fields show the online or offline status of nodes. The keyword **Active** toggles between **Primary** and **Backup** fields, indicating that the respective node is currently functioning as the active controller, managing the network, and is connected to cnMaestro.

Caveats of HA configuration

Consider the following caveats of the HA configuration for 60 GHz cnWave devices:

Configuration	Caveats
Configuration backup and restoration	<ul style="list-style-type: none"> The configuration backups are supported when the HA is enabled. The backup collected from a non-HA network can only be restored in a non-HA network. The backup collected from an HA enabled network is restored only in a HA enabled network. When HA is enabled, the restoration is allowed only when the primary node is active, managing the network and connected to cnMaestro.
Software update flow	<ul style="list-style-type: none"> When HA is enabled, it is recommended to update the nodes when primary is functioning as the active controller. It is recommended to run the HA pairs on the same version to avoid HA functionality issues. Avoid downgrading the device version to less than 1.4 when HA is enabled in the network. Avoid updating the device software from a device UI when HA is enabled. You must update the software from cnMaestro.
Device UI	<ul style="list-style-type: none"> It is recommended to make changes to the network only from cnMaestro. Making changes through device UIs may have issues in HA functionality.
cnMaestro X to Essentials downgrade	<ul style="list-style-type: none"> The HA functionality will be disabled leaving the current active controller that is connected to cnMaestro as the only controller in the network. The HA functionality can be enabled back when the subscription is enabled.
Connecting an HA enabled E2E Controller network to an Essential cnMaestro account	<ul style="list-style-type: none"> The HA functionality will be disabled leaving the current active controller (which is connected to cnMaestro) as the only controller in the network. The HA functionality can be enabled back when the network is connected to the cnMaestro X account.

For more information on configuring the HA support using cnMaestro, refer to the cnMaestro 5.1.0 User Guide.

Regulatory Information

This chapter provides regulatory notifications.



Caution

Intentional or unintentional changes or modifications to the equipment must not be made unless under the express consent of the party responsible for compliance. Any such modifications could void the user's authority to operate the equipment and will void the manufacturer's warranty.



Attention

Les changements ou modifications intentionnels ou non intentionnels à l'équipement ne doivent pas être effectués sauf avec le consentement exprès de la partie responsable de la conformité. De telles modifications pourraient annuler l'autorisation de l'utilisateur à faire fonctionner l'équipement et annulera la garantie du fabricant.

The following topics are described in this chapter:

- Compliance with safety standards lists the safety specifications against which the 60 GHz cnWave family of ODU's has been tested and certified. It also describes how to keep RF exposure within safe limits.
- Compliance with radio regulations describes how the 60 GHz cnWave family of ODU's complies with the radio regulations that are in force in various countries.

Compliance with safety standards

This section lists the safety specifications against which the 60 GHz cnWave™ platform family is tested and certified. It also describes how to keep RF exposure within safe limits.

Electrical safety compliance

The 60 GHz cnWave platform family hardware is tested for compliance to the electrical safety specifications listed in following [Safety compliance specifications](#) table.

Table 63: Safety compliance specifications

Region	Specification
USA	UL 62368-1, UL 60950-22
Canada	CSA C22.2 No.62368-1, CSA C22.2 No. 60950-22
Europe	EN 62368-1, EN 60950-22
International	CB certified IEC 62368-1 Edition 2 IEC 60950 -22

Electromagnetic Compatibility (EMC) compliance

The EMC specification type approvals that are granted for 60 GHz cnWave platform family are listed in following table.

Table 64: EMC compliance

Region	Specification
USA	FCC Part 15 Class B
Canada	RSS Gen
Europe/International	EN 301 489-1 V2.2.3, EN 301 489-17 V3.2.4

Human exposure to radio frequency energy

Relevant standards (USA and EC) applicable when working with RF equipment are:

- ANSI IEEE C95.1-2005, IEEE Standard for Safety Levels with Respect to Human Exposure to Radio Frequency Electromagnetic Fields, 3 kHz to 300 GHz
- Council recommendation of 12 July 1999 on the limitation of exposure of the general public to electromagnetic fields (0 Hz to 300 GHz) (1999/519/EC) and respective national regulations
- *Directive 2013/35/EU - electromagnetic fields* of 26 June 2013 on the minimum health and safety requirements regarding the exposure of workers to the risks arising from physical agents (electromagnetic fields) (20th individual Directive within the meaning of Article 16(1) of Directive 89/391/EEC) and repealing Directive 2004/40/EC.
- US FCC limits for the general population. See the FCC web site at <http://www.fcc.gov>, and the policies, guidelines, and requirements in Part 1 of Title 47 of the Code of Federal Regulations, as well as the guidelines and suggestions for evaluating compliance in FCC OET Bulletin 65
- Health Canada limits for the general population. See the Health Canada web site at <https://www.canada.ca/en.html>.
- EN 62232: 2017 Determination of RF field strength, power density and SAR in the vicinity of radiocommunication base stations for the purpose of evaluating human exposure (IEC 62232:2017)
- EN 50385:2017 Product standard to demonstrate the compliance of base station equipment with radiofrequency electromagnetic field exposure limits (110 MHz - 100 GHz), when placed on the market
- ICNIRP (International Commission on Non-Ionizing Radiation Protection) guidelines for the general public. See the ICNIRP web site at <https://www.icnirp.org/cms/upload/publications/ICNIRPemfgdl.pdf> and Guidelines for Limiting Exposure to Time-Varying Electric, Magnetic, and Electromagnetic Fields.

Power density exposure limit

Install the radios for the 60 GHz cnWave platform family of wireless solutions to provide and maintain the minimum separation distances from all persons.

The applicable FCC power density exposure limit for RF energy in the 57 - 66 GHz frequency bands is 10 W/m². For more information, see [Human exposure to radio frequency energy](#).

Calculation of power density

The following calculation is based on the ANSI IEEE C95.1-1991 method, as that provides a worst-case analysis.

Peak power density in the far field of a radio frequency point source is calculated as follows:

$$S = \frac{P \cdot G}{4\pi d^2}$$

Where:

S: power density in W/m²

p: maximum average transmit power capability of the radio, in W

G: total Tx gain as a factor, converted from dB

d: distance from point source, in m

Rearranging terms to solve for distance yields:

$$d = \sqrt[3]{P \cdot G / 4\pi S}$$

Calculated distances and power compliance margins

The following table displays recommended calculated separation distances, for the 60 GHz cnWave™ for Europe the USA and Canada. These are conservative distances that include compliance margins.



Note

Les tableaux suivants indiquent les distances de séparation recommandées calculées pour le cnWave™ 60 GHz pour l'Europe, les États-Unis et le Canada. Ce sont des distances prudentes qui incluent des marges de conformité.

At these and greater separation distances, the power density from the RF field is below generally accepted limits for the general population.



Note

À ces distances de séparation et à des distances supérieures, la densité de puissance du champ RF est inférieure aux limites généralement acceptées pour la population générale.

60 GHz cnWave™ Platform Family ODU adheres to all applicable EIRP limits for transmit power when operating in MIMO mode. Separation distances and compliance margins include compensation for the antenna configuration of each product.



Note

L'ODU de la famille de plates-formes cnWave™ 60 GHz respecte toutes les limites EIRP applicables pour la puissance de transmission lors d'un fonctionnement en mode MIMO. Les distances de séparation et les marges de conformité incluent la compensation de la configuration d'antenne de chaque produit.

Table 65: Calculated distances and power compliance margins

Product	Countries	EIRP (dBm)	EIRP (W)	Maximum power density (W/m ²)	Compliance distance (m)
V1000	USA, Canada, EU	38	6.3	10	0.22
V2000	USA, Canada, EU	49	79.4	10	0.9
V3000	USA, Canada	60.5	1122	10	3.0
V3000	EU	55	316.2	10	1.6
V5000	USA, Canada, EU	38	6.3	10	0.22



Note

The regulations require that the power used for the calculations is the maximum power in the transmit burst subject to allowance for source-based time-averaging.

The calculations above are based upon platform maximum EIRP and worst case 100% duty cycle.



Remarque

Les réglementations exigent que la puissance utilisée pour les calculs soit la puissance maximale de la rafale d'émission sous réserve de la moyenne temporelle basée sur la source.

Les calculs ci-dessus sont basés sur la PIRE maximale de la plate-forme et le pire des cas, un cycle de service de 100%.

Compliance with radio regulations

This section describes how the 60 GHz cnWave platform family complies with the radio regulations that are in force in various countries.



Caution

Where necessary, the end user is responsible for obtaining any national licenses required to operate this product and these must be obtained before using the product in any particular country. Contact the appropriate national administrations for details of the conditions of use for the bands in question and any exceptions that might apply.



Attention

Le cas échéant, l'utilisateur final est responsable de l'obtention des licences nationales nécessaires pour faire fonctionner ce produit. Celles-ci doivent être obtenus avant d'utiliser le produit dans un pays particulier. Contactez les administrations nationales concernées pour les détails des conditions d'utilisation des bandes en question, et toutes les exceptions qui pourraient s'appliquer.



Caution

Changes or modifications not expressly approved by Cambium Networks could void the user's authority to operate the system.

**Attention**

Les changements ou modifications non expressément approuvés par les réseaux de Cambium pourraient annuler l'autorité de l'utilisateur à faire fonctionner le système.

Type approvals

The system is tested against various local technical regulations and found to comply. The [Radio specifications](#) section lists the radio specification type approvals that is granted for the 60GHz cnWave products.

Some of the frequency bands in which the system operates are “license exempt” and the system is allowed to be used provided it does not cause interference. In these bands, the licensing authority does not guarantee protection against interference from other products and installations.

Region	Regulatory approvals	FCC ID	IC ID
USA	Part 15C	QWP-60V1000 QWP-60V2000 QWP-60V3000 QWP-60V5000	-
Canada	ISED RSS-210	-	109AO-60V1000 109AO-60V2000 109AO-60V3000 109AO-60V5000

Federal Communications Commission (FCC) compliance

The 60 GHz cnWave V1000, V2000, V3000 and V5000 comply with the regulations that are in force in the USA.

**Caution**

If this equipment does cause interference to radio or television reception.

FCC Notification

This device complies with part 15C of the US FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Innovation, Science and Economic Development Canada (ISED) compliance

The 60 GHz cnWave V1000, V2000, V3000 and V5000 comply with the regulations that are in force in Canada.

**Caution**

If this equipment does cause interference to radio or television reception.



Attention

Si cet équipement cause des interférences à la réception radio ou télévision.

60 GHz cnWave example product labels

Figure 289: 60 GHz cnWave™ V5000 Distribution Node






<p>Model No/HVIN:V5000 Part No:C600500A004A SERIAL NO (MSN):##### MAC (ESN):##### This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation IMPORTANT: See the System User Guide before connecting to AC Power. The Guide is available online at www.cambiumnetworks.com/guides MADE IN CHINA X-SZHO-H</p>	<p> Cambium Networks™ Ashburton, TQ13 7UP, UK 60GHz cnWave V5000 Distribution Node VIN: 42.5-57V IMAX: 1.41A E112443 COMPLIES WITH UL62368-1 / CSA C22.2 No. 62368-1-14 UL60950-22 / CSA C22.2 No. 60950-22-17 FCC ID: QWP-60V5000 IC: 109AO-60V5000    </p>
--	--

Figure 290: 60 GHz cnWave™ V3000 Client Node Radio only






<p>Model No/HVIN:V3000 Part No:C600500C024A SERIAL NO (MSN):##### MAC (ESN):##### This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation IMPORTANT: See the System User Guide before connecting to AC Power. The Guide is available online at www.cambiumnetworks.com/guides MADE IN CHINA X-SZHO-H</p>	<p> Cambium Networks™ Ashburton, TQ13 7UP, UK 60GHz cnWave V3000 Client Node Radio Only VIN: 42.5-57V IMAX:1.29A E112443 COMPLIES WITH UL62368-1 / CSA C22.2 No. 62368-1-14 UL60950-22 / CSA C22.2 No. 60950-22-17 FCC ID: QWP-60V3000 IC: 109AO-60V3000    </p>
--	--

Figure 291: 60 GHz cnWave™ V2000 Client Node with no power cord




Figure 292: 60 GHz cnWave™ V1000 Client Node with no cord




Figure 293: 60 GHz cnWave™ V1000 with US cord




Table 66: Details of accessories, radio nodes, and part numbers

Accessories	Radio nodes	Cambium Part Number
60 GHz cnWave™ V5000 Distribution Node	V5000	C600500A004B
60 GHz cnWave™ V3000 Client Node radio only	V3000	C600500C024B
60GHz cnWave V2000 Client Node no power supply, no power cord	V2000	C600500C030B
60 GHz cnWave™ V1000 Client Node with no cord	V1000	C600500C014B
60 GHz cnWave™ V1000 with US cord	V1000	C600500C001B

Troubleshooting


This section describes the troubleshooting steps and addresses frequently asked questions related to 60 GHz cnWave product deployment.

- [Field diagnostics logs](#)
- [Setup issues in IPv4 tunneling](#)
- [Link is not established](#)
- [PoP not online](#)
- [Link is not coming up](#)
- [Link is not having expected throughput performance](#)
- [Factory reset](#)

Field diagnostics logs


Download the logs to view more information about the error. To download the error logs select the node from the drop-down and click **Download Logs**.

Figure 294: The Logs tab in the Tools page



On clicking **Download Logs**, the status for download is displayed.

Figure 295: Downloading the logs




To download the logs for a self node, click **Download Logs** at the bottom and save the log file.

Setup issues in IPv4 tunneling

In IPv4 tunneling, if setup issues occur then perform the following steps:

1. Click **Configuration** on the left pane, navigate to **Network > Basic > Layer 2 Bridge** and verify **Enable Layer 2 bridge** is selected.



The screenshot shows the configuration interface for a 60 GHz cnWave V3000 device. The left sidebar contains various icons for navigation. The main panel is titled 'Configuration' and has tabs for 'Network' and 'Nodes'. Under the 'Network' tab, there are sub-tabs for 'Basic', 'Management', 'Security', and 'Advanced'. The 'Basic' sub-tab is selected, and within it, the 'Layer 2 Bridge' section is highlighted with a red border. This section contains a checkbox labeled 'Enable Layer 2 bridge' which is checked. Below this checkbox is a descriptive text: 'By selecting this checkbox, you will be enabling Layer 2 network bridging (via automatically created tunnels) across all nodes connected to a PoP. This will facilitate bridging of IPv4 traffic across the wireless networks.' Below the text is a 'Tunnel Concentrator' section with two radio buttons: 'Best PoP' (selected) and 'Static'. Below the 'Layer 2 Bridge' section is a 'Prefix Allocation' section with a radio button for 'Centralized' (selected) and 'Deterministic'. Below this is a 'Seed Prefix' text input field containing 'fd00:ceed:8830:da00::/56'. Below the input field is a 'Generate' link and a note: 'IPv6 'seed prefix' in CIDR format from which subnet prefixes are allocated to all DNs and CNs (e.g. face:b00c:cafe:ba00::/56)'. Below the note is a 'Prefix Length' text input field containing '64'. At the bottom of the 'Prefix Allocation' section is the text 'Length of per-node allocated prefixes'.

60 GHz cnWave™ V3000

Configuration

Network Nodes

Basic Management Security Advanced

☒ Layer 2 Bridge

☒ Enable Layer 2 bridge

By selecting this checkbox, you will be enabling Layer 2 network bridging (via automatically created tunnels) across all nodes connected to a PoP. This will facilitate bridging of IPv4 traffic across the wireless networks.

Tunnel Concentrator

☒ Best PoP ☐ Static

☐ Prefix Allocation

☒ Centralized ☐ Deterministic

Seed Prefix

fd00:ceed:8830:da00::/56

[Generate](#)


IPv6 'seed prefix' in CIDR format from which subnet prefixes are allocated to all DNs and CNs (e.g. face:b00c:cafe:ba00::/56)

Prefix Length

64

Length of per-node allocated prefixes

2. On the same page under **Configuration Management**, verify **E2E Managed Config** is selected.



60 GHz cnWave™ V3000

Configuration

Network Nodes

Basic Management Security Advanced

This configuration is used by the controller for auto config override. Channels set manually ignore this configuration.

☐ DNS

DNS Servers

DNS server list, comma separated. IPv4 is only supported when Layer 2 bridge is enabled.

☐ Time

Time Zone

NTP Servers


NTP Server hostnames or IP addresses, comma separated. IPv4 is only supported when Layer 2 bridge is enabled.

☐ **Configuration Management**

☒ E2E Managed Config

Determines whether the controller should manage the node's configuration.

3. Click **Configuration > Nodes > PoP DN > Networking > Layer 2 Bridge** and verify **Disable Broadcast Flood** and **Disable IPv6** are disabled.



60 GHz cnWave™ V5000

Disable E2E Controller Reboot admin

Configuration

Network Nodes

Search

node-V3000-884223

v2k_cn

Radio Networking VLAN Security Advanced

☐ Ethernet Ports

☒ Enable Main

☒ Enable Aux

☒ Enable SFP

☐ **Layer 2 Bridge**

☐ Disable Broadcast Flood

Broadcast packets (except DHCP Offer and DHCP Ack) in the downlink direction including client to client packets will be dropped.

☐ Disable Unknown Unicast Flood

☐ Disable IPv6



☐ Monitor PoP Interface

Layer 2 tunnels will failover to next best PoP when the backhaul interface of this PoP is down. The configuration is applicable when static routing is used and IPv4 gateway is configured.

DHCP Option 82

☐ Enabled ☒ Disabled

4. Ensure that PoP DN and DNs are in the same subnet and verify gateway is correct.




Link is not established

If a link is not established between the nodes, then verify the below options:


1. Click **Configuration** on the left navigation pane of the home UI page.
2. Navigate to **Nodes > Radio**. Verify Sector 2 PoP DN and DN's polarities, frequency, and Golay codes.

Figure 296: The Sector 2 section in the Radio page



3. Select **DN > Networking > Ethernet Ports** and ensure that specific Ethernet ports are enabled.

Figure 297: The Ethernet Ports section in the Networking page



- From the left navigation pane, navigate to **Topology > Nodes** and verify the Status is **Online Initiator**.

Figure 298: Status of nodes in the Topology page

Name	MAC Address	IP-v6	Type	Status	Model	Site	PeP Node	Software Version
Pop DN	00:04:56:88:31:21	fd00:ce:ed:08:11:2100:1	DN	Online Initiator	V5000	Point A	Yes	1.0-dev12
DN	00:04:56:88:31:24	fd00:ce:ed:08:11:2101:1	DN	Online Initiator	V5000	Point B	No	1.0-dev12

- From the left navigation pane, go to **Statistics > Links** and verify **RSSI**, **MCS**, and **TX Power Index**.

Figure 299: Link details in the Statistics page

Link Name	A-Node	Z-Node	RSSI	Link Fade Margin	Rx SNR	Rx MCS	RX PER	RX Scan Beams	TX Power Index	EIRP	Tx MCS	TX PER	TX Scan Beams	RX Errors	RX Frames	TX Errors	TX Frames
link-node-V30...	12:04:56:88:31:...	12:04:56:88:70:...	-38	59	32	9	0	57	6	35	10	0	74	20	7540	1195	7101
link-node-V30...	12:04:56:88:70:...	12:04:56:88:31:...	-37	60	32	9	0	42	6	35	10	0	55	1611	41266	1041	6543

- Go to **Performance** and verify the graphs.

Figure 300: Graphs in the Performance page



7. Go to **Radio** and monitor the throughput capacity.

Figure 301: Monitoring the throughput in the Radio page

Device Name	MAC Address	Sync Mode	Channel	Security	Error Association	Channel Last State	RX Throughput	TX Throughput
Pop DN	120456083121	RF	2	None	0	0	2.05 kbps	1.61 kbps
Pop DN	120456083121	RF	1	None	0	0	0 kbps	0 kbps
DN	120456083126	RF	1	None	0	0	0 kbps	0 kbps
DN	120456083126	RF	2	None	0	0	0.69 kbps	4.66 kbps

8. If internal GPS is used, then verify **Configuration > Nodes > Radio > GPS > Force GPS Disable** is enabled.

Figure 302: Verifying the Force GPS Disable check box

Configuration
Network Nodes

Radio Networking Security Advanced

Minimum MCS: 2
Range: (2, 12)

Maximum MCS: 12
Range: (2, 12)

☒ Sector 1

Override	Name	Auto Config	Node Config
<input type="checkbox"/>	Channel	2	
<input type="checkbox"/>	Polarity	Even	

☐ Sector 1 Link (a) Golay

Override	Name	Auto Config (Rx/Tx)	Node Golay Rx	Node Golay Tx
<input type="checkbox"/>	link-DN-Pop-DN	2/2		

Override All

☐ Sector 2

Override	Name	Auto Config	Node Config
<input type="checkbox"/>	Channel		
<input type="checkbox"/>	Polarity		

☐ Sector 2 Link (b) Golay

Override	Name	Auto Config (Rx/Tx)	Node Golay Rx	Node Golay Tx
No Data				

☒ GPS

☒ Force GPS Disable
When checked, the radio will use internal sync rather than GPS sync

Copyright © 2020 Cadence Networks, Ltd. All rights reserved. | [Contact Us](#) | [Support](#)

PoP not online from E2E or cnMaestro UI

This usually means that the PoP node is not able to talk to the E2E controller. Ensure that the PoP node has the E2E IPv6 configured properly. Also ensure that there is a route between the E2E controller and the PoP node, if they are not in the same VLAN. Try to ping the E2E from the PoP node (by logging in to SSH).

Link is not coming up

1. Ensure that the two ends of the radios can see each other (clear line of sight in between). If the link is using V3000, ensure that they are properly aligned.
2. Ensure that the MAC address of the radios is configured correctly in the E2E Controller.
3. Ensure that GPS sync is not enabled if indoor and ensure that GPS sync is enabled if outdoor.
4. Ensure that both ends of the link have the same software version.

5. Ensure to configure country code on the E2E GUI.
6. Ensure that the two ends of the link use opposite polarity and Golay codes that matches each other.
7. Ensure that the remote ends can reach the E2E Controller - IPv6 configuration (if beamforming is successful but the remote end cannot reach back to the E2E Controller, the E2E Controller/cnMaestro GUI displays link status as up, but the remote radio is offline).
8. If you already have experience in setting up a link and you are trying to set up a daisy chain, ensure that there is no any interference caused by the existing link. Example: Make sure that the two neighboring links use different Golay code.

Link does not come up after some configuration change

There is a possibility that the remote unit could be in a state that it uses different channel/Golay code/polarity from the near-end unit. Try to factory default the remote radio if possible.

On the E2E Controller/cnMaestro, it shows that the link is up, but the remote radio is NOT online - This means that link is established but the remote end radio cannot reply to the E2E Controller. Check the E2E configuration to make sure that the IPv6 default gateway is configured correctly to allow a route between the E2E controller and the remote radio.

Link is not having expected throughput performance


- Check the radio GUI to ensure that the link is running as the expected MCS mode when user data is passing through.
- Check to ensure that the Ethernet ports of the radios and the testing devices are negotiated to expected data rate (10Gbps).
- Ensure that your testing devices are capable of handling the throughput - run data throughput test by bypassing the radio link.
- Do not use radio internal iperf tool to test throughput.

Factory reset

Recovery mode is used to reset the configuration to the factory settings. To reset the configuration, perform the following steps:

1. From the main home page, navigate to **Tools > Factory Reset**.

The **Factory Reset** page appears, as shown in the following figure:




Warning

Factory reset is followed immediately by a system reboot. You must carefully configure the factory reset settings as the device comes up with the default settings. All the existing configurations are lost when the system comes up.

2. Click **Factory Reset and Reboot**.

The **Confirm** message box appears, as shown in the following figure:



3. Click **Yes** to confirm the factory reset of the system.

The system reboots immediately following the factory reset.

4. When the reboot is complete, access the device using **169.254.1.1** (IP address).



Note

After factory reset, all configurations are set to default mode.

Cambium Networks

Cambium Networks delivers wireless communications that work for businesses, communities, and cities worldwide. Millions of our radios are deployed to connect people, places and things with a unified wireless fabric that spans multiple standards and frequencies of fixed wireless and Wi-Fi, all managed centrally via the cloud. Our multi-gigabit wireless fabric offers a compelling value proposition over traditional fiber and alternative wireless solutions. We work with our Cambium certified ConnectedPartners to deliver purpose built networks for service provider, enterprise, industrial, and government connectivity solutions in urban, suburban, and rural environments, with wireless that just works.

Installation and User Guides	http://www.cambiumnetworks.com/guides
Technical training	https://learning.cambiumnetworks.com/learn
Support website (enquiries)	https://support.cambiumnetworks.com
Main website	http://www.cambiumnetworks.com
Sales enquiries	solutions@cambiumnetworks.com
Warranty	https://www.cambiumnetworks.com/support/standard-warranty/
Telephone number list to contact	http://www.cambiumnetworks.com/contact-us/
Address	Cambium Networks Limited, Unit B2, Linhay Business Park, Eastern Road, Ashburton, Devon, TQ13 7UP United Kingdom



Cambium Networks and the stylized circular logo are trademarks of Cambium Networks, Ltd. All other trademarks are the property of their respective owners.

© Copyright 2025 Cambium Networks, Ltd. All rights reserved.